







12SA7

12SK7


12SQ7 .003. 35L6GT



1941-42



NOTE: ALL VOLTAGES MEASURED FROM TUBE SOCKET
TO "B" NEGATIVE, WITH METER OF 1000-
PER VOLT, ON HIGHEST READABLE RANGE.



ALIGNMENT: To align the chassis a well shielded oscillator and a suitable output meter are required. The meter may be connected to the speaker voice coil terminals. The volume control should be set in the full-on position and the weakest possible input signal used that will give readable output. Proceed as shown in the table.

No.	Dummy Antenna	Connection of Signal Generator to Receiver	Signal Generator Frequency	Receiver Dial Setting	Trimmers to be Adjusted	Description of Adjustment
1. .1 mid cond.	Stator connection of antenna section of gang rear	455 kc	Anywhere that does not affect the signal	2nd I.F.	Peak both transformers for maximum output, then repeat until no further increase in output is obtained	
2. .1 mid cond.	Stator connection of antenna section of gang rear	1500 kc.	1500 kc.	1st I.F.	Adjust to bring in signal	
3. Standard Dummy or 200 mmf. cond.	Antenna Wire	1500 kc	Tune to 1500 kc signal	Ant. trimmer on section of gang	Adjust for maximum output	

MODEL
5006

STEWART-WARNER

DATA SHEET 118