

STR-AV270X/AV370X

SERVICE MANUAL

AEP Model
STR-AV270X/AV370X

UK Model
E Model
STR-AV370X



Photo: STR-AV370X

SPECIFICATIONS

Amplifier section

Continuous RMS power output (8 ohms, at 1 kHz less than 0.8% total harmonic distortion)

STR-AV270X : 30W+30W
STR-AV370X : 50W+50W

Dynamic power (at 1 kHz IHF)
55W+55W (8 ohms)

Harmonic distortion

Less than 0.8% at rated output

Frequency response

PHONO: RIAA equalization curve ± 0.5 dB

CD

VIDEO

TAPE

10Hz - 50kHz: ± 2 dB

Inputs

	Sensitivity	Impedance	S/N (weighting network, input level)
PHONO	2.5mV	50 kilohms	74 dB 72 dB* (A, 2.5 mV)
CD VIDEO TAPE	150mV	50 kilohms	95 dB 80 dB* (A, 150 mV)

* '78 IHF

Outputs

REC OUT, VIDEO (AUDIO) OUT	Voltage 150 mV Impedance 10 kilohms
SPEAKER A, B	Accepts speakers of 8 - 16 ohms
HEADPHONES	Accepts low and high impedance headphones

Tone controls

BASS: ± 10 dB at 100 Hz

TREBLE: ± 10 dB at 10 kHz

Muting

- 20 dB

DBFB

+12 dB at 70Hz

Tuner section

	FM tuner section	AM tuner section
Tuning range	87.5 - 108 MHz	531 - 1,602 kHz (with the AM tuning interval set at 9 kHz) 530 - 1,710 kHz (with the AM tuning interval set at 10 kHz) (E model)
Antenna terminals	300 ohms, balanced 75 ohms, unbalanced	External antenna terminal

- Continued on next page -

FM STEREO/FM-AM RECEIVER
SONY®



Sensitivity at 50 dB quieting	18.3 dBf, 4.5 μ V (mono) 38.3 dBf, 45 μ V (stereo)	—
Usable sensitivity	11.2 dBf, 2 μ V (IHF)	Loop antenna: 500 μ V (at 1,000 kHz)
Signal-to-noise ratio	76 dB (mono) 70 dB (stereo)	54 dB (at 50 mV/m)
Harmonic distortion	0.3% (mono), 0.5% (stereo) at 1 kHz	0.5% (at 50 mV/m, 400 Hz)
Selectivity	60 dB at 400 kHz	40 dB at 10 kHz
Separation	45 dB at 1 kHz	—
Frequency response	30 Hz — 15 kHz ± 0.5 dB	—

General System

- Tuner section: PLL quart-locked digital synthesizer system
- Preamplifier section: low-noise NF type equalizer amp
- Power amplifier section: quasi-complementary SEPP
- Power requirements
 - AEP, Germany models: 220V AC, 50/60 Hz
 - UK model: 240V AC, 50/60 Hz
 - E model: 110-120V, 220-230V, 240V AC, adjustable, 50/60 Hz
- Power consumption
 - STR-AV270X: 60W
 - STR-AV370X: 115W
 - In standby condition: 5W (STR-AV370X)
- AC outlets
 - One switched (100W) (STR-AV370X)
- Dimensions
 - Approx. 430 × 122.5 × 300mm (w/h/d)
 - (17 × 4 7/8 × 11 7/8 inches)
 - including projecting parts and controls
- Weight
 - STR-AV270X: Approx. 5.5 kg (12 lb 2 oz)
 - STR-AV370X: Approx. 6.5 kg (14 lb 5 oz)
- Accessories supplied
 - FM wire antenna (1)
 - AM loop antenna (1)
 - Remote Commander (1) (STR-AV370X)
 - Sony batteries SUM 3(NS) (2)


Design and specifications subject to change without notice.

TABLE OF CONTENTS

Section	Title	Page
	Specifications	1
	Model Identification	2
1.	GENERAL	
	Location and Function of Controls	3
	Receiving FM/AM Broadcasts	4
2.	ELECTRICAL ADJUSTMENTS	6
3.	DIAGRAMS	
3-1.	Block Diagram	7
3-2.	Printed Wiring Boards — Main Section — ..	11
3-3.	Schematic Diagram — Main Section —	15
3-4.	Printed Wiring Boards — Tuner Section — ..	19
3-5.	Schematic Diagram — Tuner Section —	20
3-6.	Explanation of IC301 (μ PD75206)	23
4.	EXPLODED VIEWS	25
5.	ELECTRICAL PARTS LIST	27

MODEL IDENTIFICATION

— Specification Labels —




- AEP, Germany model: AC: 220 — 230 V~50/60Hz
- UK model: AC: 240 V ~50/60 Hz
- E model: AC: 120/220/240 V ~50/60 Hz
115 W

SAFETY-RELATED COMPONENT WARNING!!
COMPONENTS IDENTIFIED BY MARK OR DOTTED LINE WITH MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

This section is extracted from instruction manual.


SECTION 1 GENERAL

Location and Function of Controls



- 1 POWER switch
- 2 SHIFT button
- 3 Remote sensor (STR-AV23/AV370X/AV570X)
- 4 Display window
- 5 BAND selectors
- 6 TUNING +/- buttons
- 7 PRESET +/- buttons
- 8 FM MODE button
When an FM stereo program is noisy or hard to receive, press this button. The STEREO indicator goes out (the sound is heard in monaural, but the reception will be improved). To return to the stereo mode, press again or change the frequency.
- 9 VOLUME control and Indicator (STR-AV370X)
- 10 SPEAKERS selectors
Depress to select which speaker system to drive. For both speaker systems, depress A and B.
- 11 HEADPHONES jack (stereo phone jack)
Connect the headphones to this jack for private listening.
- 12 Function selectors
- 13 Numeric buttons
- 14 TONE controls
Turn the TREBLE control to adjust the high frequency sound. Turn BASS control to adjust the low frequency sound.
- 15 MEMORY button
- 16 BALANCE control
Adjust to correct stereo imaging, when the speaker position is not symmetrical.
- 17 DIRECT TUNING button
- 18 DBFB (Dynamic Bass Feed Back) button and Indicator
To reinforce the bass frequency sound, press this button.
- 19 MUTING button and indicator (STR-AV370X)
Press to attenuate the sound level immediately (-20 dB attenuation). Pressing this button makes the indicator be lighted. To restore the sound level, press again.
- 20 SURROUND button and indicator
To obtain the surround effect, press this button.

Remote Commander RM-S103 (STR-AV370X)



- 1 POWER button
- 2 DBFB button
- 3 TUNER PRESET +/- and SHIFT buttons
- 4 VOLUME +/- buttons
- 5 SURROUND button
- 6 MUTING button
- 7 CD player operation buttons
D. (disc) SKIP: When your CD player is equipped with a multi-disc changer, use this button to select loaded disc.
CD ►: Selects the CD function and starts CD playback.
- 8 DECK B operation buttons (also for single tape deck)
DECK B ◀▶ Select tape function and start tape playback on deck B.
- 9 DECK A operation buttons
DECK A ◀▶ Select tape function and start tape playback on deck A.
- 10 Function select buttons

Notes on the remote commander


For the functions other than the receiver's own ones, the remote commander is effective only with Sony components having a remote sensor with a  mark.

Receiving FM/AM Broadcasts

How to receive a broadcast

When you know the frequency	See "Direct Access Tuning".
When you do not know the frequency	FM: See "Automatic Tuning". AM: See "Manual Tuning".
Tuning in a preset frequency	See "Preset Tuning".


Direct Access Tuning




Select SPEAKERS A or B.

- 1 Press TUNER.
- 2 Select FM or AM.
- 3 Press TUNING DIRECT.
- 4 Press the appropriate numeric buttons to enter the frequency. (See examples below.)
- 5 Adjust the volume.

Example 1: FM 108.00 MHz



Example 2: AM 1350 kHz



For entering AM frequencies

You do not need to enter the last "0".

Correcting the entered frequency

Repeat the above steps from the beginning.

If the frequency figures flash in the display window

The entered number is outside the receiver's frequency range (FM 87.5 to 108 MHz; AM 530 to 1710 kHz). Enter the correct frequency.

Changing the AM tuning interval


The AM tuning interval is preset to 9 kHz. To use the receiver where the frequency allocation system is based on a 10 kHz interval, make the following adjustments.

- 1 Turn on the power and tune in any AM station.
 - 2 Turn off the power.
 - 3 Press POWER while pressing PRESET "+" or "-".
- To reset the AM tuning interval, repeat the above steps.

Caution

When the interval is changed, all preset stations which you have memorized will be erased. After changing the interval, be sure to preset the stations again.

Automatic Tuning (for FM reception)



Select SPEAKERS A or B.


- 1 Press TUNER.
- 2 Select FM.
- 3 Press + or - TUNING.

When a station is received, automatic tuning stops automatically. To change the station, press + or - again.

- 4 Adjust the volume.

When sweeping does not stop at the desired station

The signal strength is weak. Tune in the station as described in "Direct Access Tuning".

Manual Tuning (for AM reception)


Select SPEAKERS
A or B.

- 1 Press TUNER.
- 2 Select AM.
- 3 Press + or - TUNING.


Each time + or - is pressed, the frequency will change by 10 kHz. To change the frequency continuously, keep the button pressed.

- 4 Adjust the volume.

Quickly tuning in a roughly known frequency
Proceed as the following example.
Example: The station between AM 700 and AM 800 kHz.

**Preset Tuning**

A total of 30 FM/AM stations can be memorized in any desired sequence.

Memorizing a Station

Select SPEAKERS A or B.

- 1 Tune in the desired station. (See 'Automatic Tuning', 'Manual Tuning' or 'Direct Access Tuning'.)
- 2 Press SHIFT to select the memory page (A, B or C).
- 3 Press MEMORY.
Memory indicator appears for a few seconds.
- 4 Press the desired numeric button (1 to 0), while the MEMORY indicator is displayed.

Repeat above steps for presetting other desired stations.

Use of memory pages

The memory pages (A, B and C) can be used to classify stations according to the music category, station band, etc.

Replacing a preset station

Preset another station on the number of the station to be replaced. The previously preset station will be erased.


Tuning In a Preset Station**Method A: Direct**

- 1 Press TUNER.
- 2 Press SHIFT to select memory page (A, B or C).
- 3 Press the preset numeric button.
- 4 Adjust the volume.

Method B: Scan

- 1 Press TUNER.
- 2 Press + or - PRESET.

Each time you press + or -, the preset station of the next higher or lower number is tuned in.



- If you keep pressing + or -, preset stations are successively tuned in. Release the button when the desired preset station is tuned in.

- 3 Adjust the volume.


SECTION 2

ELECTRICAL ADJUSTMENTS

FM SECTION

• FM Discriminator (NULL) Adjustment

Setting :




Procedure :

1. Tune the set to 98MHz.
2. Adjust T21 for 0V reading on the VOM.

Note : FM Tuning Level adjustment should be made after FM discriminator adjustment.

• FM Stereo Operation Level Adjustment

Setting :




Procedure :

1. Tune the set to 98MHz.
2. Adjust RV24 so that the STEREO LED goes on.


Note on Ceramic Filter (CF1, 2, 3) Replacement.

This set employs two ceramic filters (CF1, 2, 3) which should have the same color marking to identify their center frequency. Therefore FM IF offset adjustment by (* A, * B) connection is necessary to match the center frequency of the ceramic filters used with FM intermediate frequency.



• FM Stereo Separation Adjustment

Setting :



Procedure :

Tune the set to 98MHz.

FM stereo signal generator output channel	VTVM connection	VTVM reading (dB)
L-CH	L-CH	Ⓐ
R-CH	L-CH	Ⓑ ^a Adjust RV21 for minimum reading.
R-CH	R-CH	Ⓒ
L-CH	R-CH	Ⓓ ^b Adjust RV21 for minimum reading.

L-CH Stereo separation : Ⓐ - Ⓑ

R-CH Stereo separation : Ⓒ - Ⓓ

The separations of both channels should be equal.

○ : short

× : open

Ceramic filter		Connection		FM intermediate frequency (MHz)
Color mark	Center frequency (MHz)	* A (D326)	* B (D327)	
White	10.750	×	○	10.750
Red	10.700	×	×	10.700
Black	10.650	○	○	10.650


SECTION 3 DIAGRAMS

3-1. BLOCK DIAGRAM

AM SECTION



• AM Meter Adjustment


Setting :




Procedure :

1. Set loop antenna A so that the loop antenna B input level becomes 50.1mV (94dB/m)
2. Tune the set to 999kHz.
3. Adjust the RV23 so that the 5 point segment of the signal meter goes on.






• CIRCUIT BOARDS LOCATION




• Semiconductor Lead Layouts


STK4162MK2
STK4192MK2



LB1493
μ PC4570HA-1



μ PD75206GF-715-3BE



DTA114ES
DTA124ES
DTC114ES
DTC124ES
2SC2603-EF
2SC2669-OY
2SC3623A-LK




2SA988-FA



2SA1175-HFE
2SC2785-HFE



2SB734-34




2SC3113-AB



2SD809-K



2SD2012




2SK246-GR3



RBA-402



SEL3810A-C



HZS4ALL
HZS6C3L
RD27ESB2
UZ-4.3BSB
UZ-6.2BSC
UZ-15BSB
UZ-16BSB
1N4148M
11ES2



3-2. PRINTED WIRING BOARDS


- MAIN SECTION -


• Semiconductor Location

Ref. No.	Location	Ref. No.	Location
D301	D-3	IC301	E-8
D302	D-3	IC302	E-3
D303	D-3	IC303	E-6
D304	D-3	IC304	E-13
D305	D-3	IC401	C-17
D306	D-3	IC402	C-18
D307	D-3	IC501	I-6
D308	D-4	IC601	F-23
D309	D-4		
D311	F-13	Q301	E-2
D312	F-12	Q302	B-10
D313	F-7	Q303	B-11
D314	F-11	Q304	B-10
D315	F-11	Q305	D-11
D316	E-3	Q306	D-11
D317	B-10	Q307	D-11
D318	B-11	Q401	C-20
D319	B-9	Q402	D-20
D322	D-4	Q403	C-20
D323	D-4	Q451	C-20
D324	D-4	Q452	D-20
D326	D-12	Q501	I-7
D327	D-11	Q502	J-7
D328	F-11	Q504	I-7
D401	C-22	Q505	J-7
D402	C-22	Q506	J-7
D403	H-19	Q551	I-7
D502	J-6	Q552	I-8
D601	G-20	Q601	G-20
D602	K-22	Q602	G-20
D603	H-20	Q603	H-20
D604	H-19	Q604	H-20
D605	G-16	Q605	H-21
D651	G-20	Q651	G-20
D702	E-17	Q701	F-17
D703	G-17	Q702	E-18
D704	E-19	Q703	B-23
D705	E-18	Q704	B-23
D706	B-23	Q705	B-23
D707	B-24	Q706	B-22
D708	B-23	Q707	B-22
D709	B-22	Q708	B-22
D801	D-22	Q709	H-18
D803	C-23	Q801	C-22
D814	C-23		
D815	C-23		
D816	C-22		
D817	C-23		
D818	C-23		
D819	C-23		


Note:

-  : parts extracted from the component side.
-  : parts mounted on the conductor side.
-  : indicates side identified with part number.
- *, *A, *B: See page 6 for Note on Ceramic Filter (CF1, 2, 3) Replacement.






【MAIN BOARD】




C
—
D
—
E
—
F
—
G
—
H
—
I
—
J
—
K
—
L
—
M
—
N
—
O
—





3-4. PRINTED WIRING BOARDS – TUNER SECTION – • See page 11 for Note.

● Semiconductor Location


Ref. No.	Location	Ref. No.	Location
IC21	I-3	Q23	I-5
IC81	F-7	Q24	I-5
		Q81	H-6
Q1	F-5	Q82	H-6
Q2	F-4	Q83	H-6
Q21	M-6	Q84	F-6
Q22	M-6		







8 | 9 | 10 | 11 | 12 | 13 | 14 | 15

[TUNER BOARD]







**IC601 STR4162MK2 (AV270X)
STK4192MK2 (AV370X)**





IC401, IC501 μ PC4570HA



IC21 LA1851N





IC301 μ PD75206

3-4. PRINTED WIRING BOARDS – TUNER SECTION – • See page 11 for Note.


● Semiconductor Location

Ref. No.	Location	Ref. No.	Location
IC21	I-3	Q23	I-5
IC81	F-7	Q24	I-5
		Q81	H-6
Q1	F-5	Q82	H-6
Q2	F-4	Q83	H-6
Q21	M-6	Q84	F-6
Q22	M-6		






IC304 LB1639





MUTING
BOARD
(1/3)

MAIN BOARD


IC303 LB1493





IC601 STR4162MK2 (AV270X)
STK4192MK2 (AV370X)

IC401, IC501 μ PC4570HA

IC21 LA1851N





8

9

14

1


1

1



14


19


[TUNER BOARD]



3-3. SCHEMATIC DIAGRAM - MAIN SECTION -








*	IC601	④	- 43.8	- 42.8		- 45.7	- 33.1	- 30.4
		⑪	45.6	44.3		47.6	34.1	31.4
		⑫	43.6	43.0		45.8	32.8	29.8
		⑭	- 45.8	- 44.8		- 47.5	- 34.7	- 31.5
	Q602	⑤	- 45.8	- 44.8		- 48.4	- 34.7	- 31.2
		⑥	4.8	4.9		4.9	4.8	4.8
		⑦	- 45.3	- 44.5		- 47.5		- 31.3

(DC Voltage)

UNIT: V

Model	STR-AV370X					STR-AV270X	
	AEP	UK	Germany	E (110V)	E (220V)	AEP	Germany
**	3.2	3.2		3.6	3.8	3.2	3.2
***	69.0	67.0		65.6	70.4	51.0	47.8

(AC Voltage)



E MODEL

AV370X E MODEL

Note:

- * , *A , *B: See page 8 for Note on Ceramic Filter (CF1, 2, 3) Replacement.
- All capacitors are in μF unless otherwise noted. pF: μpF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}$ W or less unless otherwise specified.
- $\triangle$: internal component.
- $\square$: nonflammable resistor.

Note: The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.

- $\square$: adjustment for repair.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
no mark : PHONO (Main Section)
: FM (Tuner Section)
() : AM (Tuner Section)
- Voltages are taken with a VOM (Input impedance 10 M Ω). Voltage variations may be noted due to normal production tolerances.
- Signal path.
 $\Rightarrow$: PHONO
 $\Rightarrow$: FM

AV270X

A

B

C

D

E

F

G

H

I


J

K

L

M

N



UNIT: V


Model			STR-AV370X				STR-AV270X	
Mark	Point		AEP	UK	Germany	E	AEP	Germany
*	IC601	④	- 43.8	- 42.8		- 45.7	- 33.1	- 30.4
		⑪	45.6	44.3		47.6	34.1	31.4
		⑫	43.6	43.0		45.8	32.8	29.8
		⑭	- 45.8	- 44.8		- 47.5	- 34.7	- 31.5
	Q602	⑤	- 45.8	- 44.8		- 48.4	- 34.7	- 31.2
		③	4.8	4.9		4.9	4.8	4.8
		⑥	- 45.3	- 44.5		- 47.5		- 31.3

(DC Voltage)

UNIT: V

Model		STR-AV370X					STR-AV270X	
Mark		AEP	UK	Germany	E (110V)	E (220V)	AEP	Germany
**		3.2	3.2		3.6	3.8	3.2	3.2
***		69.0	67.0		65.6	70.4	51.0	47.8

(AC Voltage)



3-6. EXPLANATION OF IC301 (μ PD75206)

PIN No.	SIGNAL NAME	FUNCTION	I/O	ACTIVE
1	RESET	Micro Computer RESET	I	L
2	T0	FL tube indication (invalid) digit	O	H
3	T1	FL tube indication digit T1	O	H
4	T2	FL tube indication digit T2	O	H
5	T3	FL tube indication digit T3	O	H
6	T4	FL tube indication digit T4	O	H
7	T5	FL tube indication digit T5	O	H
8	T6	FL tube indication digit T6	O	H
9	T7	FL tube indication digit T7	O	H
10	T8	FL tube indication digit T8	O	H
11	T9	FL tube SIGNAL indication digit T9	O	H
12	T10/PH3	DBFB Output	O	H
13	T11/PH2	IF WIDE/NARROW Output	O	H
14	T12/PH1	Adapter Output	O	H
15	T13/PH0	-20dB Muting Output	O	H
16	T14/S11	FL tube indication Segment/Diode S11	O	H
17	T15/S10	FL tube indication Segment/Diode S10	O	H
18	V road	FL tube pulldown power supply	-	-
19	V pre	FL tube driver power supply	-	-
20	S9	FL tube indication Segment/Diode S9	O	H
21	S8	FL tube indication Segment/Key Scan S8	O	H
22	S7	FL tube indication Segment/Key Scan S7	O	H
23	S6	FL tube indication Segment/Key Scan S6	O	H
24	S5	FL tube indication Segment/Key Scan S5	O	H
25	S4	FL tube indication Segment/Key Scan S4	O	H
26	Vdd	Micro Computer power supply	-	-
27	S3	FL tube indication Segment/Key Scan S3	O	H
28	S2	FL tube indication Segment/Key Scan S2	O	H
29	S1	FL tube indication Segment/Key Scan S1	O	H
30	S0	FL tube indication Segment/Key Scan S0	O	H
31	P00/INT4	Signal to cut power supply STOP	I	L
32	P01/SCK	Serial latch for electrical adjustment use SI. LAT	I	L

PIN No.	SIGNAL NAME	FUNCTION	I/O	ACTIVE
33	P02/S0	Tuner Auto Stop input ASTP	I	L
34	P03/S1	Tuner Stereo input STEREO	I	L
35	P10/INT0	Remote Control Signal input SIRCS	I	L
36	P11/INT1	Protector input PROTECT	I	L
37	P12/INT2	System Power Key input PKEY	I	L
38	P13/TI0	Adapter Mechanical Switch input AKEY	I	H
39	P20	Surround output SURROUND	O	H
40	P21	Video Control A VCRA	O	H
41	P22	Video Control B VCRB	O	H
42	P23/BUZ	Video Inhibit VCRI	O	H
43	P30	Protector Muting PMUT	O	L
44	P31	Source Direct Output	O	H
45	P32	Standby LED Output STANBY	O	H
46	P33	Tuner Muting TMUTE	O	H
47	P60	PLL/7822 Latch PLAT	O	H
48	P61	PLL/7822/SI Data DATA	I/O	H
49	P62	PLL/7822/SI Clock CLOK	I/O	H
50	P63	IF WIDE/NARROW Display output	O	H
51	P40	Function Muting FMUTE	O	L
52	P41	Motor Volume UP VOL+	O	H
53	P42	Motor Volume DOWN VOL-	O	H
54	P43	Speaker Relay SP. RY	O	H
55	PP0	Power Relay POW. RY	O	H
56	X1	Ceramic Oscillator	-	-
57	X2	Ceramic Oscillator	-	-
58	Vss	Micro Computer GND	-	-
59	XT1	-	-	-
60	XT2	-	-	-
61	P50	P50 Key Scan Input	I	H
62	P51	P51 Key Scan Input	I	H
63	P52	P52 Key Scan Input	I	H
64	P53	P53 Key Scan Input	I	H

SECTION 4

EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.

- Color Indication of Appearance Parts
Example:
KNOB, BALANCE (WHITE) ... (RED)


↑ ↑
 Parts Color Cabinet's Color

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark **A** or dotted line with mark **A** are critical for safety. Replace only with part number specified.

- G: Germany model.


(1) FRONT PANEL ASSEMBLY SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
1	4-943-091-01	KNOB (VOL)		11	4-943-087-01	BUTTON (S)	
2	4-943-092-01	PLATE(VOL), LIGHT GUIDE (AV370X)		12	3-704-366-01	SCREW (CASE) (M3X8)	
3	3-350-426-01	SPRING, RING		13	4-923-836-11	CUSHION	
4	4-916-745-11	KNOB (DIA. 21)		14	* 1-590-499-11	WIRE, FLAT TYPE (23 CORE)	
5	A-4323-872-A	PANEL ASSY, FRONT (AV370X)		15	* 1-590-770-11	WIRE, FLAT TYPE (11 CORE)	
5	A-4323-909-A	PANEL ASSY, FRONT (AV270X)		16	A-4341-733-A	TONE BOARD, COMPLETE (AEP, UK, E)	
6	1-638-236-11	STANDBY BOARD (AV370X)		16	* A-4341-734-A	TONE BOARD, COMPLETE (G)	
7	4-928-635-01	SCREW, +BV (2.6X8) TAPPING		17	9-911-842-XX	CUSHION (CD), RUBBER	
8	4-921-941-01	CUSHION (FL)		18	1-638-950-11	VOLUME BOARD	
9	4-943-107-01	HOLDER (FL TUBE)		19	1-638-239-11	MUTING BOARD	
10	* A-4341-721-A	DISPLAY BOARD, COMPLETE (AV270X)		20	* 1-590-769-11	WIRE, FLAT TYPE (7 CORE)	
10	* A-4341-730-A	DISPLAY BOARD, COMPLETE (AV370X)		21	* 4-943-088-01	CASE	

(2) CHASSIS SECTION

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
51	* 4-924-098-11	HOLDER, PC BOARD		67	* 4-943-098-31	PANEL, BACK (AV370X G)	
52	* 4-924-098-31	HOLDER, PC BOARD		67	* 4-943-098-51	PANEL, BACK (AV370X E)	
53	1-638-949-11	HP BOARD		67	* 4-943-109-21	PANEL, BACK (AV270X G)	
54	1-638-234-11	SPEAKER BOARD		67	* 4-943-109-51	PANEL, BACK (AV270X AEP)	
55	4-917-460-01	KNOB, POWER (AV270X)		68	* A-4341-740-A	TUNER BOARD, COMPLETE (AV270X AEP/AV370X AEP, UK)	
56	1-638-237-11	AC SWITCH BOARD (AV270X)		68	* A-4341-741-A	TUNER BOARD, COMPLETE (AV270X G/AV370X G)	
57	3-701-947-15	LABEL (T2.5A), FUSE		68	* A-4341-742-A	TUNER BOARD, COMPLETE (AV370X E)	
58	1-638-235-11	POWER BOARD		69	3-698-359-01	RIVET (DIA 3.5), NYLON	
59	3-701-748-00	CLAMP		70	Δ 1-569-008-11	ADAPTER, CONVERSION (AV370X E)	
60	1-533-217-31	HOLDER, FUSE		CNJ901	Δ 1-526-751-11	OUTLET, AC (AV370X UK)	
61	3-318-688-31	FOOT (F58175S)		CNJ901	Δ 1-526-794-11	OUTLET, AC (AV370X AEP, G, E)	
62	* A-4341-719-A	MAIN BOARD, COMPLETE (AV270X G)		F901	Δ 1-532-286-00	FUSE (2.5A 125V)	
62	* A-4341-726-A	MAIN BOARD, COMPLETE (AV370X E)		F902	Δ 1-532-259-00	FUSE (1.6A 125V) (AV370X AEP, UK)	
62	* A-4341-727-A	MAIN BOARD, COMPLETE (AV370X G)		F902	Δ 1-532-285-00	FUSE (1.25A 125V) (AV270X)	
62	* A-4345-738-A	MAIN BOARD, COMPLETE (AV270X AEP, UK)		F902	Δ 1-532-286-00	FUSE (2.5A 125V) (AV370X G, E)	
62	* A-4345-739-A	MAIN BOARD, COMPLETE (AV270X AEP)		T901	Δ 1-450-359-11	TRANSFORMER, POWER (AV370X UK)	
63	7-621-849-00	SCREW, TAPPING		T901	Δ 1-450-360-11	TRANSFORMER, POWER (AV370X E)	
64	* 3-703-244-00	BUSHING (2104), CORD		T901	Δ 1-450-385-11	TRANSFORMER, POWER (AV270X G)	
65	Δ 1-556-035-00	CORD, POWER (AV370X UK)		T901	Δ 1-450-363-11	TRANSFORMER, POWER (AV370X AEP, G)	
65	Δ 1-555-750-00	CORD, POWER (AV270X/AV370X AEP, G, E)		T901	Δ 1-450-364-11	TRANSFORMER, POWER (AV270X AEP)	
66	3-706-165-00	SCREW		TM601	1-537-341-11	TERMINAL BOARD (8P SPEAKER)	
67	* 4-943-098-21	PANEL, BACK (AV370X AEP)		VS901	Δ 1-570-307-11	SWITCH, VOLTAGE CHANGE (AV370X E)	
67	* 4-943-098-41	PANEL, BACK (AV370X UK)					

SECTION 5
ELECTRICAL PARTS LIST

AC SWITCH

DISPLAY

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F: nonflammable

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA...: μ PA...,
uPB...: μ PB..., uPC...: μ PC...,
uPD...: μ PD...
- CAPACITORS
uF: μ F
- COILS
uH: μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

When including parts by reference number, please include the board name.

- G: Germany model.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	* 1-638-237-11	AC SWITCH BOARD (AV270X)				(DIODE)	

		(CAPACITOR)		D301	8-719-987-63	DIODE 1N4148M	
C901	Δ 1-161-744-00	CERAMIC 0.01 400V (AV270X)		D302	8-719-987-63	DIODE 1N4148M	
		(SWITCH)		D303	8-719-987-63	DIODE 1N4148M	
S901	Δ 1-152-267-21	SWITCH, PUSH (AC POWER) (1 KEY) (POWER) (AV270X)		D304	8-719-987-63	DIODE 1N4148M	
		*****		D305	8-719-987-63	DIODE 1N4148M	
	* A-4341-721-A	DISPLAY BOARD, COMPLETE (AV270X)		D306	8-719-987-63	DIODE 1N4148M	
	* A-4341-731-A	DISPLAY BOARD, COMPLETE (AV370X AEP, UK, G)		D307	8-719-987-63	DIODE 1N4148M	
	* A-4341-750-A	DISPLAY BOARD, COMPLETE (AV370X E)		D308	8-719-987-63	DIODE 1N4148M	
		*****		D309	8-719-987-63	DIODE 1N4148M	
	* 1-568-830-11	SOCKET, CONNECTOR 11P		D311	8-719-987-63	DIODE 1N4148M	
	* 4-921-941-01	CUSHION (FL)		D312	8-719-987-63	DIODE 1N4148M	
	* 4-943-107-01	HOLDER (FL TUBE)		D313	8-719-985-53	DIODE HZS4ALL-TD	
		(CAPACITOR)		D314	8-719-987-63	DIODE 1N4148M	
C301	1-162-306-11	CERAMIC 0.01uF 20% 16V		D315	8-719-987-63	DIODE 1N4148M	
C303	1-162-306-11	CERAMIC 0.01uF 20% 16V		D322	8-719-987-63	DIODE 1N4148M	
C304	1-162-306-11	CERAMIC 0.01uF 20% 16V		D323	8-719-987-63	DIODE 1N4148M	
C305	1-124-903-11	ELECT 1uF 20% 50V		D324	8-719-987-63	DIODE 1N4148M	
C306	1-124-261-00	ELECT 10uF 20% 50V		D326	8-719-987-63	DIODE 1N4148M	
C307	1-162-306-11	CERAMIC 0.01uF 20% 16V		D327	8-719-987-63	DIODE 1N4148M	
C308	1-125-486-11	DUBLE LAYERS 0.22F 5.5V		D803	8-719-987-63	DIODE 1N4148M	
C309	1-124-261-00	ELECT 10uF 20% 50V				(INDICATOR TUBE)	
C310	1-162-306-11	CERAMIC 0.01uF 20% 16V		FL301	1-519-509-11	INDICATOR TUBE, FLUORESCENT	
C311	1-162-306-11	CERAMIC 0.01uF 20% 16V				(IC)	
C630	1-162-306-11	CERAMIC 0.01uF 20% 16V		IC301	8-759-154-23	IC uPD75206GF-715-3BE	
		(CONNECTOR)		IC302	8-749-920-83	IC GP1U52XB	
CNJ306	* 1-568-937-11	PIN, CONNECTOR 10P		IC303	8-759-800-95	IC LB1493	
CNP904	* 1-560-062-00	PIN, CONNECTOR 4P		IC304	8-759-820-62	IC LB1639 (AV370X)	
CNS301	* 1-568-865-11	SOCKET, CONNECTOR 23P				(INDICATOR)	
				L301	1-410-521-11	INDUCTOR 100uH	
						(TRANSISTOR)	
				Q301	8-729-900-36	TRANSISTOR DTC124ES	
				Q305	8-729-900-63	TRANSISTOR DTA124ES	

DISPLAY

HP

MAIN

Ref. No.	Part No.	Description	Remark		
Q306	8-729-900-63	TRANSISTOR	DTA124ES		
Q307	8-729-900-63	TRANSISTOR	DTA124ES		
< RESISTOR >					
R301	1-249-411-11	CARBON	330	5%	1/4W
R302	1-249-411-11	CARBON	330	5%	1/4W
R303	1-249-411-11	CARBON	330	5%	1/4W
R304	1-249-411-11	CARBON	330	5%	1/4W
R305	1-249-429-11	CARBON	10K	5%	1/4W
R306	1-249-429-11	CARBON	10K	5%	1/4W
R307	1-249-429-11	CARBON	10K	5%	1/4W
R308	1-249-429-11	CARBON	10K	5%	1/4W
R311	1-249-429-11	CARBON	10K	5%	1/4W
R312	1-249-431-11	CARBON	15K	5%	1/4W
R313	1-249-417-11	CARBON	1K	5%	1/4W
R314	1-249-441-11	CARBON	100K	5%	1/4W
R315	1-249-437-11	CARBON	47K	5%	1/4W
R316	1-249-441-11	CARBON	100K	5%	1/4W
R321	1-249-410-11	CARBON	270	5%	1/4W (AV370X)
R325	1-249-441-11	CARBON	100K	5%	1/4W
R331	1-249-437-11	CARBON	47K	5%	1/4W
R332	1-249-437-11	CARBON	47K	5%	1/4W
R333	1-249-437-11	CARBON	47K	5%	1/4W
R334	1-249-437-11	CARBON	47K	5%	1/4W
R335	1-249-437-11	CARBON	47K	5%	1/4W
R336	1-249-431-11	CARBON	15K	5%	1/4W
R337	1-249-437-11	CARBON	47K	5%	1/4W
R338	1-249-437-11	CARBON	47K	5%	1/4W
R347	1-249-437-11	CARBON	47K	5%	1/4W
R348	1-249-437-11	CARBON	47K	5%	1/4W
R349	1-249-437-11	CARBON	47K	5%	1/4W
R350	1-249-437-11	CARBON	47K	5%	1/4W
R351	1-249-437-11	CARBON	47K	5%	1/4W
R352	1-249-437-11	CARBON	47K	5%	1/4W
R353	1-249-437-11	CARBON	47K	5%	1/4W
R354	1-249-437-11	CARBON	47K	5%	1/4W
R355	1-249-437-11	CARBON	47K	5%	1/4W
R356	1-249-401-11	CARBON	47	5%	1/4W
< COMPOSITION CIRCUIT BLOCK >					
RB301	1-233-081-11	COMPOSITION CIRCUIT BLOCK			
< SWITCH >					
S301	1-554-303-21	SWITCH, TACTILE (DIRECT)			
S302	1-554-303-21	SWITCH, TACTILE (PRESET TUNING:-)			
S303	1-554-303-21	SWITCH, TACTILE (TUNING:-)			
S304	1-554-303-21	SWITCH, TACTILE (FM)			
S305	1-554-303-21	SWITCH, TACTILE (FM MODE)			

Ref. No.	Part No.	Description	Remark
S306	1-554-303-21	SWITCH, TACTILE (PRESET TUNING:+)	
S307	1-554-303-21	SWITCH, TACTILE (TUNING:+)	
S308	1-554-303-21	SWITCH, TACTILE (AM)	
S310	1-554-303-21	SWITCH, TACTILE (TAPE)	
S311	1-554-303-21	SWITCH, TACTILE (VIDEO)	
S312	1-554-303-21	SWITCH, TACTILE (PHONO)	
S313	1-554-303-21	SWITCH, TACTILE (TUNER)	
S314	1-554-303-21	SWITCH, TACTILE (CD)	
S315	1-554-303-21	SWITCH, TACTILE (7)	
S316	1-554-303-21	SWITCH, TACTILE (8)	
S317	1-554-303-21	SWITCH, TACTILE (9)	
S318	1-554-303-21	SWITCH, TACTILE (MEMORY)	
S319	1-554-303-21	SWITCH, TACTILE (4)	
S320	1-554-303-21	SWITCH, TACTILE (5)	
S321	1-554-303-21	SWITCH, TACTILE (6)	
S322	1-554-303-21	SWITCH, TACTILE (0)	
S323	1-554-303-21	SWITCH, TACTILE (1)	
S324	1-554-303-21	SWITCH, TACTILE (2)	
S325	1-554-303-21	SWITCH, TACTILE (3)	
S326	1-554-303-21	SWITCH, TACTILE (SHIFT)	
< VIBRATOR >			
X301	1-577-101-11	VIBRATOR, CERAMIC (4.19MHz)	

* 1-638-949-11 HP BOARD			

< JACK >			
J601	1-568-515-21	JACK (LARGE TYPE) (HEADPHONES)	
< RESISTOR >			
R638	△ 1-216-454-11	METAL OXIDE 390 5% 2W	F
R658	△ 1-216-454-11	METAL OXIDE 390 5% 2W	F

* A-4341-719-A MAIN BOARD, COMPLETE (AV270X G)			
* A-4341-726-A MAIN BOARD, COMPLETE (AV370X E)			
* A-4341-727-A MAIN BOARD, COMPLETE (AV370X G)			
* A-4341-738-A MAIN BOARD, COMPLETE (AV370X AEP, UK)			
* A-4341-739-A MAIN BOARD, COMPLETE (AV270X AEP)			

* 3-698-359-01 RIVET (DIA. 3.5), NYLON			
7-685-650-79 SCREW +BVTP 3X16 TYPE2 IT-3			
7-682-548-04 SCREW +BVTT 3X8 (S)			

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
< CAPACITOR >						C701	1-106-367-00	MYLAR	0.01uF	5%	200V (UK, E)
C401	1-162-282-31	CERAMIC	100PF	10%	50V	C702	1-106-379-00	MYLAR	0.033uF	5%	200V (AEP, G)
C402	1-123-382-00	ELECT	3.3uF	20%	100V	C704	1-124-478-11	ELECT	100uF	20%	25V
C403	1-162-282-31	CERAMIC	100PF	10%	50V	C705	1-124-477-11	ELECT	47uF	20%	25V
C404	1-162-282-31	CERAMIC	100PF	10%	50V	C706	1-101-005-00	CERAMIC	22000PF		50V
C405	1-124-034-51	ELECT	33uF	20%	16V	C708	1-124-927-11	ELECT	4.7uF	20%	100V
C406	1-130-480-00	MYLAR	0.0056uF	5%	50V	C710	1-124-910-11	ELECT	47uF	20%	50V
C407	1-130-473-00	MYLAR	0.0015uF	5%	50V	C711	1-124-910-11	ELECT	47uF	20%	50V
C408	1-123-382-00	ELECT	3.3uF	20%	100V	C712	1-124-907-11	ELECT	10uF	20%	50V
C409	1-124-477-11	ELECT	47uF	20%	25V	C713	1-124-477-11	ELECT	47uF	20%	25V
C410	1-124-477-11	ELECT	47uF	20%	25V	C714	1-124-477-11	ELECT	47uF	20%	25V
C411	1-162-294-31	CERAMIC	0.001uF	10%	50V	C716	1-124-464-11	ELECT	0.22uF	20%	50V
C412	1-162-282-31	CERAMIC	100PF	10%	50V	C717	1-124-902-00	ELECT	0.47uF	20%	50V
C417	1-124-478-11	ELECT	100uF	20%	25V	C718	1-124-903-11	ELECT	1uF	20%	50V
C418	1-124-478-11	ELECT	100uF	20%	25V	C719	1-101-005-00	CERAMIC	22000PF		50V
C419	1-124-478-11	ELECT	100uF	20%	25V	C801	1-125-614-11	ELECT	6800uF	20%	50V
C420	1-124-927-11	ELECT	4.7uF	20%	100V (AV370X)	C802	1-125-614-11	ELECT	6800uF	20%	50V
C421	1-124-927-11	ELECT	4.7uF	20%	100V	C803	1-101-005-00	CERAMIC	22000PF	50V	(AV370X)
C451	1-162-282-31	CERAMIC	100PF	10%	50V	C804	1-101-005-00	CERAMIC	22000PF	50V	(AV370X)
C452	1-123-382-00	ELECT	3.3uF	20%	100V	C805	1-124-557-11	ELECT	1000uF	20%	25V
C453	1-162-282-31	CERAMIC	100PF	10%	50V	C810	1-126-301-11	ELECT	1uF	20%	50V
C454	1-162-282-31	CERAMIC	100PF	10%	50V	< JACK >					
C455	1-124-034-51	ELECT	33uF	20%	16V	CNJ401 *	1-580-835-11	JACK, PIN 6P			
C456	1-130-480-00	MYLAR	0.0056uF	5%	50V	CNJ402 *	1-580-835-11	JACK, PIN 6P			
C457	1-130-473-00	MYLAR	0.0015uF	5%	50V	CNJ610 *	1-569-507-11	PIN, CONNECTOR 12P			
C458	1-123-382-00	ELECT	3.3uF	20%	100V	< CONNECTOR >					
C601	1-162-286-31	CERAMIC	220PF	10%	50V	CNP503 *	1-564-507-11	PLUG, CONNECTOR 4P			
C602	1-126-163-11	ELECT	4.7uF	20%	50V	CNP504 *	1-535-116-00	TERMINAL			
C603	1-162-288-31	CERAMIC	330PF	10%	50V	CNP505 *	1-580-804-11	PIN, CONNECTOR 10P			
C604	1-124-122-11	ELECT	100uF	20%	50V	CNP506 *	1-564-903-11	PIN, CONNECTOR (L TYPE) 7P			
C605	1-124-910-11	ELECT	47uF	20%	50V	CNP507 *	1-535-116-00	TERMINAL			
C606	1-124-120-11	ELECT	220uF	20%	25V	CNS501 *	1-568-839-11	SOCKET, CONNECTOR 23P			
C607	1-162-193-31	CERAMIC	3.3PF	10%	50V	CNS502 *	1-568-826-11	SOCKET, CONNECTOR 7P			
C608	1-126-059-11	ELECT	10uF	20%	50V	CNS503 *	1-568-826-11	SOCKET, CONNECTOR 7P			
C621	1-130-495-00	MYLAR	0.1uF	5%	50V	CNS507 *	1-569-498-11	SOCKET, CONNECTOR 12P			
C622	1-130-495-00	MYLAR	0.1uF	5%	50V	CNS551 *	1-568-826-11	SOCKET, CONNECTOR 7P			
C623	1-124-907-11	ELECT	10uF	20%	50V	< DIODE >					
C624	1-124-472-11	ELECT	470uF	20%	10V	D401	8-719-987-63	DIODE 1N4148M			
C625	1-130-495-00	MYLAR	0.1uF	5%	50V	D402	8-719-987-63	DIODE 1N4148M			
C651	1-162-286-31	CERAMIC	220PF	10%	50V	D403	8-719-987-63	DIODE 1N4148M			
C652	1-126-163-11	ELECT	4.7uF	20%	50V	D601	8-719-987-63	DIODE 1N4148M			
C653	1-162-288-31	CERAMIC	330PF	10%	50V	D602	8-719-987-63	DIODE 1N4148M			
C654	1-124-122-11	ELECT	100uF	20%	50V	D603	8-719-987-63	DIODE 1N4148M			
C655	1-124-910-11	ELECT	47uF	20%	50V	D604	8-719-987-63	DIODE 1N4148M			
C656	1-124-120-11	ELECT	220uF	20%	25V	D605	8-719-987-63	DIODE 1N4148M			
C657	1-162-193-31	CERAMIC	3.3PF	10%	50V	D651	8-719-987-63	DIODE 1N4148M			
C658	1-126-059-11	ELECT	10uF	20%	50V	D702	8-719-010-86	DIODE UZ-16BSB			
C671	1-130-495-00	MYLAR	0.1uF	5%	50V						
C672	1-130-495-00	MYLAR	0.1uF	5%	50V						
C675	1-130-495-00	MYLAR	0.1uF	5%	50V						

MAIN

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
D703	8-719-010-29	DIODE UZ-4. 3BSB				< RESISTOR >	
D704	8-719-110-67	DIODE RD27ESB2		R401	1-249-411-11	CARBON 330 5% 1/4W	
D705	8-719-010-82	DIODE UZ-15BSB		R402	1-249-417-11	CARBON 1K 5% 1/4W	
D706	8-719-010-47	DIODE UZ-6. 2BSC		R403	1-249-417-11	CARBON 1K 5% 1/4W	
D707	8-719-933-41	DIODE HZS6C3L		R404	1-249-425-11	CARBON 4.7K 5% 1/4W	
				R405	1-249-417-11	CARBON 1K 5% 1/4W	
D708	8-719-985-53	DIODE HZS4ALL		R406	1-249-425-11	CARBON 4.7K 5% 1/4W	
D709	8-719-987-63	DIODE 1N4148M		R407	1-247-897-11	CARBON 560K 5% 1/4W	
D801	8-719-312-09	DIODE RBA-402		R408	1-247-897-11	CARBON 560K 5% 1/4W	
D803	8-719-987-63	DIODE 1N4148M		R409	1-249-437-11	CARBON 47K 5% 1/4W	
D814	8-719-200-82	DIODE 11ES2 (AV370X)		R410	1-247-897-11	CARBON 560K 5% 1/4W	
D815	8-719-200-82	DIODE 11ES2 (AV370X)					
D816	8-719-200-82	DIODE 11ES2 (AV370X)		R411	1-249-416-11	CARBON 820 5% 1/4W	
D817	8-719-200-82	DIODE 11ES2 (AV370X)		R412	1-247-897-11	CARBON 560K 5% 1/4W	
D818	8-719-987-63	DIODE 1N4148M		R413	1-249-437-11	CARBON 47K 5% 1/4W	
D819	8-719-987-63	DIODE 1N4148M		R414	1-247-897-11	CARBON 560K 5% 1/4W	
		< IC >		R415	1-249-417-11	CARBON 1K 5% 1/4W	
IC401	8-759-112-93	IC uPC4570HA-1		R416	1-249-411-11	CARBON 330 5% 1/4W	
IC402	8-759-805-14	IC LC7822		R417	1-249-411-11	CARBON 330 5% 1/4W	
IC601	8-749-900-24	IC STK4162MK2 (AV270X)		R418	1-249-425-11	CARBON 4.7K 5% 1/4W	
IC601	8-749-900-78	IC STK4192MK2 (AV370X)		R419	1-247-838-00	CARBON 2K 5% 1/4W	
		< COIL >		R420	1-249-409-11	CARBON 220 5% 1/4W (AV370X)	
L601	* 1-420-872-00	COIL, AIR CORE		R421	1-249-429-11	CARBON 10K 5% 1/4W	
L651	* 1-420-872-00	COIL, AIR CORE		R422	1-249-425-11	CARBON 4.7K 5% 1/4W	
		< TRANSISTOR >		R423	1-249-437-11	CARBON 47K 5% 1/4W	
Q401	8-729-141-30	TRANSISTOR 2SC3623A-LK (AV370X)		R424	1-249-434-11	CARBON 27K 5% 1/4W	
Q402	8-729-141-30	TRANSISTOR 2SC3623A-LK		R425	1-249-441-11	CARBON 100K 5% 1/4W	
Q403	8-729-900-63	TRANSISTOR DTA124ES		R426	1-249-405-11	CARBON 100 5% 1/4W	
Q451	8-729-141-30	TRANSISTOR 2SC3623A-LK (AV370X)		R427	1-249-437-11	CARBON 47K 5% 1/4W	
Q452	8-729-141-30	TRANSISTOR 2SC3623A-LK		R428	1-249-441-11	CARBON 100K 5% 1/4W	
Q601	8-729-108-14	TRANSISTOR 2SA988-F		R451	1-249-411-11	CARBON 330 5% 1/4W	
Q602	8-729-620-05	TRANSISTOR 2SC2603-EF		R452	1-249-417-11	CARBON 1K 5% 1/4W	
Q603	8-729-620-05	TRANSISTOR 2SC2603-EF		R453	1-249-417-11	CARBON 1K 5% 1/4W	
Q604	8-729-620-05	TRANSISTOR 2SC2603-EF		R454	1-249-425-11	CARBON 4.7K 5% 1/4W	
Q605	8-729-620-05	TRANSISTOR 2SC2603-EF		R455	1-249-417-11	CARBON 1K 5% 1/4W	
Q651	8-729-108-14	TRANSISTOR 2SA988-F		R456	1-249-425-11	CARBON 4.7K 5% 1/4W	
Q701	8-729-209-15	TRANSISTOR 2SD2012		R457	1-247-897-11	CARBON 560K 5% 1/4W	
Q702	8-729-140-97	TRANSISTOR 2SB734-34		R458	1-247-897-11	CARBON 560K 5% 1/4W	
Q703	8-729-180-92	TRANSISTOR 2SD809-K		R459	1-249-437-11	CARBON 47K 5% 1/4W	
Q704	8-729-620-05	TRANSISTOR 2SC2603-EF		R460	1-247-897-11	CARBON 560K 5% 1/4W	
Q705	8-729-119-76	TRANSISTOR 2SA1175-HFE		R461	1-249-416-11	CARBON 820 5% 1/4W	
Q706	8-729-119-76	TRANSISTOR 2SA1175-HFE		R462	1-247-897-11	CARBON 560K 5% 1/4W	
Q707	8-729-620-05	TRANSISTOR 2SC2603-EF		R463	1-249-437-11	CARBON 47K 5% 1/4W	
Q708	8-729-900-36	TRANSISTOR DTC124ES		R464	1-247-897-11	CARBON 560K 5% 1/4W	
Q709	8-729-904-39	TRANSISTOR DTC114TS		R465	1-249-417-11	CARBON 1K 5% 1/4W	
Q801	8-729-620-05	TRANSISTOR 2SC2603-EF		R469	1-247-838-00	CARBON 2K 5% 1/4W	
				R470	1-249-409-11	CARBON 220 5% 1/4W (AV370X)	
				R601	1-249-417-11	CARBON 1K 5% 1/4W	
				R602	1-249-438-11	CARBON 56K 5% 1/4W	
				R603	1-247-826-91	CARBON 620 5% 1/4W (AV270X AEP)	
				R603	1-247-830-11	CARBON 910 5% 1/4W (AV270X G)	

Ref. No.	Part No.	Description				Remark
R703	△ 1-216-448-11	METAL OXIDE	39	5%	2W	F
R705	1-249-423-11	CARBON	3.3K	5%	1/4W	
R706	1-249-405-11	CARBON	100	5%	1/4W	
R707	1-249-410-11	CARBON	270	5%	1/4W	
R708	1-249-389-11	CARBON	4.7	5%	1/4W	
R709	1-249-423-11	CARBON	3.3K	5%	1/4W	
R710	1-249-437-11	CARBON	47K	5%	1/4W	
R711	1-249-429-11	CARBON	10K	5%	1/4W	
R712	1-249-429-11	CARBON	10K	5%	1/4W	
R713	1-249-426-11	CARBON	5.6K	5%	1/4W	
R714	1-249-417-11	CARBON	1K	5%	1/4W	
R715	1-249-426-11	CARBON	5.6K	5%	1/4W	
R716	1-249-417-11	CARBON	1K	5%	1/4W	
R718	1-249-401-11	CARBON	47	5%	1/4W	
R721	1-249-413-11	CARBON	470	5%	1/4W	
R722	1-249-437-11	CARBON	47K	5%	1/4W	
R723	1-249-437-11	CARBON	47K	5%	1/4W	
R724	1-249-437-11	CARBON	47K	5%	1/4W	
R725	1-249-437-11	CARBON	47K	5%	1/4W	
R726	1-249-410-11	CARBON	270	5%	1/4W	
R727	1-249-429-11	CARBON	10K	5%	1/4W	
R728	1-249-417-11	CARBON	1K	5%	1/4W	
R801	1-249-389-11	CARBON	4.7	5%	1/4W	
R802	1-249-437-11	CARBON	47K	5%	1/4W	(AV370X)
R803	1-249-396-11	CARBON	18	5%	1/6W	(AV370X)
R804	1-247-739-11	CARBON	100	5%	1/2W	
R805	1-249-425-11	CARBON	4.7K	5%	1/4W	(AV370X)
		(RELAY)				
RY601	1-515-533-11	RELAY (DBFB)				
		(SWITCH)				
S601	1-506-468-11	CONNECTOR	3P,	MALE		
		(TERMINAL)				
TM601	1-537-341-11	TERMINAL BOARD (8P SP)				

	* 1-638-239-11	MUTING BOARD				

		(DIODE)				
D317	8-719-313-72	DIODE SEL3810A				(AV370X)
D318	8-719-313-72	DIODE SEL3810A				
D319	8-719-313-72	DIODE SEL3810A				
		(TRANSISTOR)				
Q302	8-729-900-36	TRANSISTOR DTC124ES				
Q303	8-729-900-36	TRANSISTOR DTC124ES				

-31-

MUTING

POWER

SPEAKER

STAND BY

tone

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
Q304	8-729-900-36	TRANSISTOR DTC124ES				< CONNECTOR >	
		< RESISTOR >		CNS302 *	1-568-951-11	PIN, CONNECTOR 2P (AV370X)	
R322	1-249-410-11	CARBON	270 5% 1/4W			< SWITCH >	
R323	1-249-410-11	CARBON	270 5% 1/4W (AV370X)	S330	1-554-303-21	SWITCH, TACTILE (POWER) (AV370X)	
R324	1-249-410-11	CARBON	270 5% 1/4W	*****			
R357	1-249-429-11	CARBON	10K 5% 1/4W			* A-4341-733-A	TONE BOARD, COMPLETE (AEP, UK, E)
R358	1-249-429-11	CARBON	10K 5% 1/4W (AV370X)			* A-4341-734-A	TONE BOARD, COMPLETE (G)
R359	1-249-429-11	CARBON	10K 5% 1/4W			*****	
		< SWITCH >				< CAPACITOR >	
S327	1-554-303-21	SWITCH, TACTILE (DBFB) (AV370X)		C501	1-130-489-00	MYLAR	0.033uF 5% 50V
S328	1-554-303-21	SWITCH, TACTILE (MUTING) (AV370X)		C502	1-124-250-00	ELECT	0.15uF 20% 50V
S329	1-554-303-21	SWITCH, TACTILE (SURROUND) (AV370X)		C503	1-130-481-00	MYLAR	0.0068uF 5% 50V
*****				C504	1-130-489-00	MYLAR	0.033uF 5% 50V
	* 1-638-235-11	POWER BOARD	*****	C505	1-126-163-11	ELECT	4.7uF 20% 50V
				C506	1-124-925-11	ELECT	2.2uF 20% 100V
	1-533-217-31	HOLDER, FUSE		C507	1-101-880-00	CERAMIC	47PF 5% 50V
	* 1-535-140-00	BASE POST 22MM (10MM PITCH) 3P		C509	1-124-903-11	ELECT	1uF 20% 50V
	1-535-416-00	TERMINAL		C510	1-130-489-00	MYLAR	0.033uF 5% 50V
		< CAPACITOR >		C512	1-124-464-11	ELECT	0.22uF 20% 50V
C901	△ 1-161-744-00	CERAMIC	0.01uF 400V (AV370X)	C513	1-124-464-11	ELECT	0.22uF 20% 50V
C920	△ 1-161-744-00	CERAMIC	0.01uF 400V (G)	C514	1-136-163-00	MYLAR	0.068uF 10% 50V
C921	△ 1-161-744-00	CERAMIC	0.01uF 400V (G)	C515	1-102-106-00	CERAMIC	100PF 10% 50V
		< TRANSFORMER >		C551	1-130-489-00	MYLAR	0.033uF 5% 50V
PT902	△ 1-450-358-11	TRANSFORMER, POWER (AV370X)		C552	1-124-250-00	ELECT	0.15uF 20% 50V
		< RELAY >		C553	1-130-481-00	MYLAR	0.0068uF 5% 50V
RY901	△ 1-515-720-11	RELAY (AV370X)		C554	1-130-489-00	MYLAR	0.033uF 5% 50V
		< VARISTOR >		C555	1-126-163-11	ELECT	4.7uF 20% 50V
VZ901	△ 1-807-180-31	VARISTOR SNR-14A471U		C556	1-124-925-11	ELECT	2.2uF 20% 100V
*****				C557	1-101-880-00	CERAMIC	47PF 5% 50V
	* 1-638-234-11	SPEAKER SWITCH BOARD	*****	C559	1-124-903-11	ELECT	1uF 20% 50V
		< CAPACITOR >		C560	1-130-489-00	MYLAR	0.033uF 5% 50V
C091	1-164-089-11	CERAMIC	0.0022uF 50V	C565	1-102-106-00	CERAMIC	100PF 10% 50V
C092	1-164-089-11	CERAMIC	0.0022uF 50V			< CONNECTOR >	
		< SWITCH >		CNS552 *	1-568-826-11	SOCKET, CONNECTOR 7P	
S601	1-571-485-11	SWITCH, PUSH (2 KEY) (SPEAKERS)		CNS553 *	1-568-830-11	SOCKET, CONNECTOR 11P	
*****						< DIODE >	
	* 1-638-236-11	STAND BY BOARD (AV370X)	*****	D502	8-719-987-63	DIODE 1N4148M	
						< IC >	
				IC501	8-759-112-93	IC uPC4570HA-1	

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

TONE

TUNER

Ref. No. Part No. Description Remark

< TRANSISTOR >

Q501 8-729-202-67 TRANSISTOR 2SK246GR3
 Q502 8-729-620-05 TRANSISTOR 2SC2603-EF
 Q504 8-729-202-67 TRANSISTOR 2SK246GR3
 Q505 8-729-900-36 TRANSISTOR DTC124ES
 Q506 8-729-900-63 TRANSISTOR DTA124ES

Q551 8-729-202-67 TRANSISTOR 2SK246GR3
 Q552 8-729-620-05 TRANSISTOR 2SC2603-EF

< RESISTOR >

R501 1-249-429-11 CARBON 10K 5% 1/4W
 R502 1-249-421-11 CARBON 2.2K 5% 1/4W
 R503 1-249-441-11 CARBON 100K 5% 1/4W
 R504 1-249-427-11 CARBON 6.8K 5% 1/4W
 R505 1-249-438-11 CARBON 56K 5% 1/4W

R506 1-249-441-11 CARBON 100K 5% 1/4W
 R507 1-247-883-00 CARBON 150K 5% 1/4W
 R508 1-249-417-11 CARBON 1K 5% 1/4W
 R509 1-249-412-11 CARBON 390 5% 1/4W
 R510 1-249-427-11 CARBON 6.8K 5% 1/4W

R518 1-249-441-11 CARBON 100K 5% 1/4W
 R519 1-249-441-11 CARBON 100K 5% 1/4W
 R520 1-247-903-00 CARBON 1M 5% 1/4W
 R521 1-249-427-11 CARBON 6.8K 5% 1/4W
 R522 1-247-903-00 CARBON 1M 5% 1/4W

R551 1-249-429-11 CARBON 10K 5% 1/4W
 R552 1-249-421-11 CARBON 2.2K 5% 1/4W
 R553 1-249-441-11 CARBON 100K 5% 1/4W
 R554 1-249-427-11 CARBON 6.8K 5% 1/4W
 R555 1-249-438-11 CARBON 56K 5% 1/4W

R556 1-249-441-11 CARBON 100K 5% 1/4W
 R557 1-247-883-00 CARBON 150K 5% 1/4W
 R558 1-249-417-11 CARBON 1K 5% 1/4W
 R559 1-249-412-11 CARBON 390 5% 1/4W
 R560 1-249-427-11 CARBON 6.8K 5% 1/4W

< VARIABLE RESISTOR >

RV501 1-241-407-11 RES. VAR. CARBON 100K/100K (BALANCE)
 RV503 1-241-406-11 RES. VAR. CARBON 100K/100K (BASS)
 RV504 1-241-406-11 RES. VAR. CARBON 100K/100K (TREBLE)

* A-4341-740-A TUNER BOARD, COMPLETE (AEP, UK)

* A-4341-741-A TUNER BOARD, COMPLETE (G)

* A-4341-742-A TUNER BOARD, COMPLETE (E)

Ref. No. Part No. Description Remark

< CAPACITOR >

C1 1-163-141-00 CERAMIC CHIP 0.001uF 5% 50V
 C2 1-124-477-11 ELECT 47uF 20% 25V
 C3 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C4 1-163-141-00 CERAMIC CHIP 0.001uF 5% 50V
 C5 1-164-232-11 CERAMIC CHIP 0.01uF 50V

C6 1-164-232-11 CERAMIC CHIP 0.01uF 50V(G)
 C10 1-163-037-11 CERAMIC CHIP 0.022uF 10% 25V
 C21 1-161-021-11 CERAMIC 0.047uF 10% 25V
 C22 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C23 1-124-477-11 ELECT 47uF 20% 25V

C24 1-123-382-00 ELECT 3.3uF 20% 100V
 C25 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C26 1-163-019-00 CERAMIC CHIP 0.0068uF 10% 50V
 C27 1-163-125-00 CERAMIC CHIP 220PF 5% 50V(G)
 C28 1-124-903-11 ELECT 1uF 20% 50V

C29 1-163-117-00 CERAMIC CHIP 100PF 5% 50V(AEP, UK, E)
 C29 1-163-133-00 CERAMIC CHIP 470PF 5% 50V(G)
 C30 1-124-903-11 ELECT 1uF 20% 50V
 C31 1-124-902-00 ELECT 0.47uF 20% 50V
 C32 1-124-463-00 ELECT 0.1uF 20% 50V

C33 1-130-481-00 MYLAR 0.0068uF 5% 50V(AEP, G, UK)
 C33 1-130-482-00 MYLAR 0.0082uF 5% 50V(AV370X E)
 C34 1-123-382-00 ELECT 3.3uF 20% 100V
 C35 1-130-481-00 MYLAR 0.0068uF 5% 50V(AEP, G, UK)
 C35 1-130-482-00 MYLAR 0.0082uF 5% 50V(AV370X E)

C36 1-123-382-00 ELECT 3.3uF 20% 100V
 C37 1-124-907-11 ELECT 10uF 20% 50V
 C39 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C40 1-124-463-00 ELECT 0.1uF 20% 50V
 C41 1-124-927-11 ELECT 4.7uF 20% 100V

C42 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C43 1-126-176-11 ELECT 220uF 20% 10V
 C44 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C45 1-123-382-00 ELECT 3.3uF 20% 100V
 C46 1-164-161-11 CERAMIC CHIP 0.0022uF 10% 100V

C48 1-123-382-00 ELECT 3.3uF 20% 100V
 C49 1-164-161-11 CERAMIC CHIP 0.0022uF 10% 100V
 C51 1-124-477-11 ELECT 47uF 20% 25V
 C61 1-163-037-11 CERAMIC CHIP 0.022uF 10% 25V
 C62 1-163-037-11 CERAMIC CHIP 0.022uF 10% 25V

C63 1-163-037-11 CERAMIC CHIP 0.022uF 10% 25V
 C64 1-163-037-11 CERAMIC CHIP 0.022uF 10% 25V
 C81 1-102-961-00 CERAMIC 27PF 5% 50V
 C82 1-102-961-00 CERAMIC 27PF 5% 50V
 C83 1-164-232-11 CERAMIC CHIP 0.01uF 50V

C84 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C85 1-164-232-11 CERAMIC CHIP 0.01uF 50V
 C86 1-124-477-11 ELECT 47uF 20% 25V
 C87 1-164-232-11 CERAMIC CHIP 0.01uF 50V

TUNER

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C101	1-124-925-11	ELECT 2.2uF	20% 100V	R4	1-216-037-00	METAL CHIP 330 5%	1/10W (G)
C102	1-124-463-00	ELECT 0.1uF	20% 50V	R5	1-216-013-00	METAL CHIP 33 5%	1/10W (AEP, UK, E)
C104	1-164-232-11	CERAMIC CHIP 0.01uF	50V	R5	1-216-037-00	METAL CHIP 330 5%	1/10W (G)
C105	1-124-477-11	ELECT 47uF	20% 25V	R6	1-216-037-00	METAL CHIP 330 5%	1/10W
		< FILTER >		R7	1-216-109-00	METAL CHIP 330K 5%	1/10W
CF1	1-567-389-11	FILTER, CERAMIC		R8	1-216-013-00	METAL CHIP 33 5%	1/10W (G)
CF2	1-567-389-11	FILTER, CERAMIC		R9	1-216-037-00	METAL CHIP 330 5%	1/10W (G)
CF3	1-567-389-11	FILTER, CERAMIC (G)		R10	1-216-109-00	METAL CHIP 330K 5%	1/10W (G)
CF21	1-577-075-11	OSCILLATOR, CERAMIC		R21	1-249-404-00	CARBON 82 5%	1/4W
		< TRANSFORMER >		R22	1-249-462-11	CARBON 22K 5%	1/4W
CFT21	1-404-853-11	TRANSFORMER, IF		R23	1-216-049-00	METAL CHIP 1K 5%	1/10W
		< CONNECTOR >		R24	1-216-085-00	METAL CHIP 33K 5%	1/10W
CNJ1	* 1-569-795-11	HOUSING, CONNECTOR 10P		R25	1-216-071-00	METAL CHIP 8.2K 5%	1/10W
CNJ2	* 1-580-803-11	HOUSING, CONNECTOR 7P		R27	1-249-461-11	CARBON 18K 5%	1/4W
		< FRONT-END >		R28	1-247-719-11	CARBON 3.3K 5%	1/4W
FE1	1-465-006-21	FRONT-END (FM 2 GANG) (AEP, UK, E)		R29	1-216-073-00	METAL CHIP 10K 5%	1/10W
FE1	1-465-007-11	FRONT-END (FM 4 GANG) (G)		R31	1-216-041-00	METAL CHIP 470 5%	1/10W
FE61	1-236-461-11	ENCAPSULATED COMPONENT		R32	1-216-073-00	METAL CHIP 10K 5%	1/10W
		< IC >		R33	1-216-073-00	METAL CHIP 10K 5%	1/10W
IC21	8-759-821-45	IC LA1851N		R35	1-216-089-00	METAL CHIP 47K 5%	1/10W
IC81	8-759-820-91	IC LC7218		R37	1-216-109-00	METAL CHIP 330K 5%	1/10W
		< INDUCTOR >		R39	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
L21	1-410-494-11	INDUCTOR 1MMH		R40	1-216-055-00	METAL CHIP 1.8K 5%	1/10W
		< FILTER >		R41	1-216-067-00	METAL CHIP 5.6K 5%	1/10W
LPF21	1-235-164-00	FILTER, LOW PASS		R42	1-216-109-00	METAL CHIP 330K 5%	1/10W
LPF22	1-235-164-00	FILTER, LOW PASS		R44	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
		< TRANSISTOR >		R45	1-216-055-00	METAL CHIP 1.8K 5%	1/10W
Q1	8-729-230-XX	TRANSISTOR 2SC26690Y-TPE4		R46	1-216-067-00	METAL CHIP 5.6K 5%	1/10W
Q2	8-729-230-XX	TRANSISTOR 2SC26690Y-TPE4 (G)		R47	1-249-409-11	CARBON 220 5%	1/4W
Q21	8-729-119-78	TRANSISTOR 2SC2785-HFE		R61	1-216-097-00	METAL CHIP 100K 5%	1/10W
Q22	8-729-119-78	TRANSISTOR 2SC2785-HFE		R62	1-216-089-00	METAL CHIP 47K 5%	1/10W
Q23	8-729-900-61	TRANSISTOR DTA114ES		R63	1-216-009-00	METAL CHIP 22 5%	1/10W
Q24	8-729-900-80	TRANSISTOR DTC114ES		R81	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q81	8-729-900-61	TRANSISTOR DTA114ES		R82	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q82	8-729-900-80	TRANSISTOR DTC114ES		R83	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q83	8-729-202-67	TRANSISTOR 2SK246GR3		R84	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q84	8-729-230-93	TRANSISTOR 2SC3113-AB		R85	1-216-073-00	METAL CHIP 10K 5%	1/10W
		< RESISTOR >		R86	1-216-049-00	METAL CHIP 1K 5%	1/10W
R1	1-249-401-11	CARBON 47 5%	1/4W	R87	1-216-073-00	METAL CHIP 10K 5%	1/10W
R3	1-216-037-00	METAL CHIP 330 5%	1/10W (G)	R88	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R4	1-216-013-00	METAL CHIP 33 5%	1/10W (AEP, UK, E)	R89	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R90	1-216-073-00	METAL CHIP 10K 5%	1/10W
				R91	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R92	1-249-401-11	CARBON 47 5%	1/4W
				R101	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
				R102	1-216-043-00	METAL CHIP 560 5%	1/10W
				R103	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R104	1-216-035-00	METAL CHIP 270 5%	1/10W
				R105	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
				R106	1-216-057-00	METAL CHIP 2.2K 5%	1/10W

TUNER

VOL

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R107	1-216-065-00	METAL CHIP 4.7K 5% 1/10W		3-753-021-41	MANUAL, INSTRUCTION (AEP) (GERMAN, FRENCH, DUTCH, SWEDISH, SPANISH, ITALIAN)		
R108	1-216-025-00	METAL CHIP 100 5% 1/10W		3-753-021-51	MANUAL, INSTRUCTION (G) (GERMAN)		
R109	1-216-065-00	METAL CHIP 4.7K 5% 1/10W		3-753-021-61	MANUAL, INSTRUCTION (UK) (ENGLISH)		
R110	1-249-405-11	CARBON 100 5% 1/4W		3-753-021-71	MANUAL, INSTRUCTION (E) (ENGLISH, FRENCH, SPANISH, CHINESE)		
(VARIABLE RESISTOR)							
RV21	1-238-015-11	RES, ADJ, CARBON 4.7K		* 4-943-615-01	CUSHION		
RV23	1-238-021-11	RES, ADJ, CARBON 220K		* 4-944-450-01	INDIVIDUAL CARTON (AV370X: AEP, UK, G)		
RV24	1-238-017-11	RES, ADJ, CARBON 22K		* 4-944-451-01	INDIVIDUAL CARTON (AV370X: E)		
(TRANSFORMER)				* 4-944-452-01	INDIVIDUAL CARTON (AV270X)		
T21	1-404-807-11	TRANSFORMER, DISCRIMINATOR		*****			
T23	1-235-126-00	ENCAPSULATED COMPONENT (G)		HARDWARE LIST			
(TERMINAL)				#1	7-682-547-04	SCREW +BVTT 3X6 (S)	
TM1	* 1-537-264-21	TERMINAL BOARD (E)		#2	7-682-548-04	SCREW +BVTT 3X8 (S)	
TM1	* 1-537-288-11	TERMINAL BOARD (PAL) (AEP, G, UK)		#3	7-682-560-04	SCREW +BVTT 4X6 (S)	
(TEST PIN)				#4	7-685-650-79	SCREW +BVTP 3X16 TYPE2 IT-3	
TP1	* 1-560-060-00	PIN, CONNECTOR 2P		#5	7-682-547-09	SCREW +BVTT 3X6 (S)	
(VIBRATOR)				#6	7-685-647-79	SCREW +BVTP 3X10 TYPE2 N-S	
XT81	1-577-126-11	VIBRATOR, CRYSTAL		#7	7-685-534-19	SCREW +BTP2, 6X8 TYPE2 (AV370X E)	

* 1-638-950-11 VOL BOARD							

(CAPACITOR)							
C517	1-124-464-11	ELECT 0.22uF 20% 50V (AV370X)					
C518	1-124-464-11	ELECT 0.22uF 20% 50V (AV370X)					
(VARIABLE RESISTOR)							
RV502	1-241-405-11	RES, VAR, CARBON 100K/100K (VOLUME) (AV370X)					
RV502	1-241-408-11	RES, VAR, CARBON 100K/100K (VOLUME) (AV270X)					

ACCESSORIES & PACKING MATERIALS							

1-465-423-11 REMOTE COMMANDER (RM-S103) (AV370X: AEP, G, E)							
1-465-809-11 REMOTE COMMANDER (RM-U211) (AV370X: UK)							
1-501-369-21 ANTENNA (AEP, UK)							
1-501-374-51 ANTENNA, LOOP							
1-569-008-11 ADAPTOR, CONVERSION 2P (E)							
2-181-754-01 COVER, BATTERY (for RM-S103)							
3-707-584-01 COVER, BATTERY (for RM-U211)							

