

ENSIGN

CHAIRSIDE RADIO-PHONO

MODELS

RP10IX - PR10IX

5M5CX CHASSIS

PARTS LIST & SCHEMATIC

T1126

Canadian Admiral Corporation Ltd.

5M5CX PARTS LIST

RESISTORS

Sym.	Description	Part No.
R1	2.2 meg, $\frac{1}{2}$ W, 10%.....	60B8-225
R2	22K, $\frac{1}{2}$ W, 10%	60B8-223
R3	68 ohm, $\frac{1}{2}$ W, 10%.....	60B8-680
R4	1.5K ohm, $\frac{1}{2}$ W, 10%	60B8-152
R5	1 meg, $\frac{1}{2}$ W, 10%.....	60B8-105
R6	Control, 1 meg ohm, 30%.....	75C56-4
R7	10 meg	Part of couplate
R8	470K	Part of couplate
R9	470K	Part of couplate
R10	150 ohm, $\frac{1}{2}$ W, 10%.....	60B8-151
R11	1.2K ohm, 1W, 10%	60B14-122
R12	33 ohm, 1W, 10%.....	60B14-330

CAPACITORS

C1	220 mmfd, 20%, 500V.....	65D10-83
C2	.1 mfd, 20%, 400V.....	64L6-26
C3	.01 mfd, GMV, 1KV.....	65M1-3
C4	.01 mfd, GMV, 1KV.....	65M1-3
C5	47 mmfd, 20%, 500V.....	65D10-198
C6	.002 mfd, 500V.....	65D10-125
C7	220 mmfd	Part of couplate
C8	.005 mfd	Part of couplate
C9	250 mmfd	Part of couplate
C10	.005 mfd	Part of couplate
C11	.01 mfd, GMV, 1KV.....	65M1-3
C12	.047 mfd, 20%, 400V	64L6-28
C13A	30 mfd, 150V, Electrolytic.....	67B39-1
C13B	50 mfd, 150V, Electrolytic.....	67B39-1
C14A	Condenser, Gang.....	68K1-1
C14B		
C15	.068 mfd, 20%, 600V	64L6-8

COILS

L1	Rod, Antenna.....	69L9-1
L2	Coil, Oscillator	69A217-6

Record Changer.....	9400L5-1
	or
	400B751-10
Cartridge.....	409C40-1

TRANSFORMERS

Sym.	Description	Part No.
T1	1st I.F. Transformer.....	72C170-5
T2	2nd I.F. Transformer.....	72C170-4
T3	Audio Output Transformer.....	79M9-8

MISCELLANEOUS CHASSIS PARTS

Solderless Terminal.....	9A22-1
Terminal & Connect.....	9C28-51
Cable Clamp, Plastic (Antenna mtg.).....	11B12-4
Printed Circuit Board.....	14E216-5
Interlock Bracket	15L75-2
Plug, Amp-Lok (Part of 700N18-6 Plug Assy)	33B287-1
Chassis Mtg. Panel	43M82-1
D.P.D.T. Wafer Switch	76B34-1
Tube Socket, Min. 7 Pin.....	87D35-13
Tube Socket, Min. 7 Pin (with Gnd. Strap)..	87D35-14
Tube Shield	87B52-2
Phono Input Socket.....	88A1-1
Interlock Plug.....	88W36
Plug Ass'y. (Phono Motor Supply)	700N18-6

CABINET PARTS LIST FOR MODEL RP101X

Solderless Terminal (Spkr. Leads).....	9M5-1 or 9M5-8
Plastic Clamp (89N5 to Changer).....	11B12-3
Escutcheon	23L35-1
Nameplate.....	26L44-1
Fishpaper	32K4-4
Knob - Radio Tuning	33L9-1
Knob - Function (Radio-Phono)	33L9-2
Knob - Volume	33C350-2
Cabinet - Chairside (Walnut).....	35P224-1
Cover - Bottom.....	35P224-54
Operating Instructions.....	41K12-10
Cover - Back.....	43M96-1
Masking Tape	52C1-34
Speaker 5" Round (Orange Dot).....	78M27-3
Phono Plug (Part of 89N5-1).....	88A2-3
Twin Speaker Leads	89L4-1
Phono Lead	89N5-1
Line Cord.....	89C62-4
Schematic	99N209

**MODEL PR IOIX IS IDENTICAL TO RP IOIX
EXCEPT FOR THE FOLLOWING CHANGE**

(PR IOIX uses a 41K12-II instruction book)

