


Schematics Only


De Forest Crosley
Color Code for
Battery Operated Models

A+B—White
A—C—Black
B45—Green


B90—Red
B135—Brown
C4½—Yellow
C9—Red and Black




THE C5 COMPACT AND CONSOLE
(1926-27)




THE CONWAY AND HASTINGS (1927-28)




THE WARWICK AND WINDSOR (1927-28)




THE BALMORAL AND BERWICK (1927-28)
Battery Operated



THE BARCAROLLE AND MINUET
(Battery Type—1928-9)




THE NOCTURNE (AC. 1928)



THE CONCERTO, SONATA AND OPERA
MODELS (1928-29)

NOCTURNE (High Boy)
Same Chassis also used in DUET (Phono-Comb.)



Printed in Canada

DATA SHEET

—Courtesy De Forest Crosley Limited

DE FOREST CROSLEY—5