

Fleetwood

2082, 2084,
2085, 2092

NOTES:

- 1. ALL VOLTAGE MEASUREMENTS WITH A VTVM, 2 20%.
- 2. RESISTANCE VALUES ARE IN OHMS UNLESS NOTED.
- 3. CAPACITANCE VALUES ARE IN P.F. UNLESS NOTED.
- 4. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 5. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 6. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 7. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 8. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 9. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.
- 10. ALL VALUES OF (1) OR (2) ARE IN P.F. UNLESS NOTED.




DIAGRAM OF CONNECTIONS FOR R.F. UNIT CHASSIS MODELS 2082, 2084, 2085, 2092.

Fleetwood 2082, 2084, 2085, 2092







Diagram of Connections, Power Chassis and Sound Panel



Diagram, F.M. Tuner

Fleetwood 2082, 2084, 2085, 2092 Tube Locations



Tube Location Chart