


ÄNDERUNGEN VORBEHALTEN'
ALTERATIONS RESERVED



A1	=	Tonband - Aufnahme (Mmm)
A2	=	Tonband - Wiedergabe (Mmm)
B1/3	=	Aufnahme von Stereo Schallplatten
B1/3	=	Stereo Tonband - Wiedergabe
C1/3	=	Stereo Schallplatten - Wiedergabe
C1	=	Monoral - Schallplatten - Wiedergabe
A1	The Recorder	None Recording
A2		None Play-Back
A1/3	*	Recording (Stereo Records)
A1/3	*	Stereo Play-Back
B1/3		None Recording
C1/3	Recorded Channels	None Play-Back
C1		None Play-Back

NOTES: MEASURED IN CHASSIS WITH BROADCAST VOLUME AT THE SOURCE, MEASURING POINTS WOULD BE THE SAME FOR ALL SOUND CHANNELS
TUNED TO WITTING TUNING ON DEMO.

Fleetwood Grundig SO 122 CA

[illegible]

