

- Maximum performance depends on accurate alignment of the receiver I.F. and R.F. circuits. Therefore, the method outlined in the alignment chart and, the instructions below should be followed carefully.

Marconi Models 279, 280, 281, 284 Alignment Procedure

Model 279



- * Lug on R.F. section of gang forms suitable point of connection.
- ** Before proceeding with R.F. Alignment, see that dial pointer is set to last calibration mark at left of dial with gang at maximum capacity.

Marconi Models 279, 280, 281, 284

