



RCA VICTOR



AUTOMATIC RECORD CHANGER SERVICE DATA MODELS GARRARD 1000 & 2000



Model 1000



Model 2000

GENERAL INFORMATION

THE MODELS 1000 & 2000 USE THE SAME MECHANISM AS THE GARRARD AUTOSLIM AND APPROPRIATE SERVICING DETAILS IN THE AUTOSLIM SERVICE MANUAL WILL APPLY. PLEASE REFER TO GARRARD AUTOSLIM SERVICE DATA ISSUE 1964 NO. 7 FOR SERVICE INFORMATION AND REPLACEMENT PARTS LIST. REPLACEMENT PARTS ARE IDENTICAL UNLESS SPECIFIED OTHERWISE IN THIS PUBLICATION.

SUPPLEMENTARY INFORMATION LISTINGS

Issue	Subject

ISSUED BY


SERVICE DIVISION PUBLICATIONS
RCA VICTOR COMPANY, LTD.
MONTREAL, CANADA

Price 35c

1965 No. 23
Printed in Canada.


GARRARD MODEL 1000 AND MODEL 2000 EXPLODED VIEW

EXPLODED VIEW OF PARTS ABOVE UNIT PLATE



GARRARD MODEL 1000 AND MODEL 2000 EXPLODED VIEW

EXPLODED VIEW OF PARTS BENEATH UNIT PLATE



REPLACEMENT PARTS LIST

Insist on Genuine Factory Tested Parts, which are readily identified and may be purchased from Authorized Dealers.

SYMBOL	STOCK NO.	DESCRIPTION	SYMBOL	STOCK NO.	DESCRIPTION
		LIST OF PARTS ABOVE UNIT PLATE			
1	*63-7699	Selector	64	63-27811	Steel Ball
2	*63-7700	Selector Extension	65	63-27812	Spring
3	*63-7701	Overarm Assembly	69	63-7182	Screw (Fixing Pickup Rest)
4	*63-7702	Pickup Arm complete less cartridge	69A		Spring Washer
4		Pickup Arm Unit	69B		Washer (Under Pickup Rest)
4K	*63-7703	Pickup Arm Shroud-Black	125	*63-7730	Pickup Rest Assembly
4L		Screw Fixing Shroud	125A	*63-7731	Pickup Rest Clip
4M		Washer	125B		Screw (Pivot)
6		6 BA Screw - Bright Nickel	125C		P. V. C. Sheath
7	*63-7704	Pivot Spindle		63-7748	45 RPM Adaptor
7B		Pivot Bush Unit			LIST OF PARTS BENEATH UNIT PLATE
8A		Lifting plate M/C	66	*63-7732	Control Lever Assembly
8B	63-29081	Lifting spring	67		Spring Clip
13	*63-7706	Index Plate	70	*63-7733	Return Spring Assembly
15	*63-7707	Counterbalance Spring	71	63-27805	Reject Lever
16	*63-7708	Spring Clip	72	63-27770	Switch Lever Unit
16A	*63-7709	Presspahn Washer	73		Spring Clip
16B		Spring Clip Fixing Pickup Leads	74	*63-7734	Speed Control Lever Assembly
17	63-27726	Screw (for Restrictor)	75		Spring Clip
18	*63-7710	Pivot Screw Top	76	*63-7735	Switch Off Lever
18	*63-7711	Pivot Screw Assembly (D. G. unit)	77	*63-7736	Overarm Lever
19	63-29086	Overload Spring	78	63-27766	Lower Casting Assembly
20	63-27728	Spring (for Restrictor)	78A	*63-7737	Pin
21	*63-7712	Pickup Bracket Unit	79	63-29108	Screw
22	*63-7713	Restrictor Blade	79A	63-27767	Screw
23	*63-7714	Tension Nut	80	*63-7738	Return Spring
24		Grub Screw	81		Spring Clip
25	63-7086	Screw (Fixing Cartridge)	82	63-27718	Selector Lever
25A	*63-7715	Distance Piece	83	63-27719	Fixing Nut
26		Cartridge Bracket	83A		Washer
29H		Pickup Lead Assembly (not shown)	84	63-27720	Selector Spring
31	*63-7716	Record Spindle Assembly	85	63-29105	Pickup Lever Unit
31A	63-29094	Manual Spindle	86	63-27811	Steel Ball
32	63-29095	Turntable Clip	87	63-27816	Friction Spring
33	*63-7717	Turntable Assembly (Model 1000 8")	88	63-27807	Collar
33	*63-7718	Turntable Assembly (Model 2000 10-1/2")	89	*63-7739	Auto Trip Lever Unit
33A		Turntable & Mat Assembly (Model 1000)	89A	*63-7740	Bearing Pad
33A		Turntable & Mat Assembly (Model 2000)	90	63-27808	Screw
34	*63-7719	Turntable Mat (Model 1000)	90A	*63-7741	Anti Friction Washer
34	*63-7720	Turntable Mat (Model 2000)	91	*63-7742	Lifting Spindle Unit
35	*63-7721	Centre Disc (Model 1000)	92	63-27817	Friction Link Unit
35	*63-7722	Centre Disc (Model 2000)	93	63-27769	Pickup Cam Unit
35A	*63-7723	Turntable Trim Disc. (Model 2000 not shown)	94	63-27800	Index Spring
37	63-27759	Thrust Washer	95		Spring Clip
38	63-27760	Ball Race Assembly	96	63-27768	Release Lever
39	63-27761	Cushion Ring	97	*63-7743	Pawl Spring
40	63-27721	Upper Casting	98	63-27771	Return Spring
40	63-29097	Upper Casting Assembly (D. G. Unit)	99		Washer
41	63-27762	Cam Assembly	100		Spring Clip
42		Spring Clip	101		Pickup Connector
43	63-27765	Trip Pawl	101	*63-7744	Twin Phono Socket
44		Spring Clip	101A	63-27853	Muting Switch
45	63-27764	Pivot Plate Unit	101B	63-27747	Spring for Muting Switch
46	63-27754	Tension Link	102		Screw (P. U. Connector or phono socket)
47	63-27748	Tension Lever	103A	63-27772	Switch Body
48		Spring Clip	103B	63-27773	Switch Blade Assembly
49	*63-7725	Tension Spring	103C	63-27774	Contact Plate Assembly
50	63-27747	Interwheel unit	103D	63-27775	Plunger
51	63-27753	Circlip	103E		Cover for Switch
52	63-27752	Presspahn Washer	103E	63-27857	Cover for Switch (with suppressor)
53	63-27750	Support Lever Unit	103F	63-27858	Condenser
54	63-27749	Interwheel Spring	103G	63-27859	Resistor
55	63-27755	Transit Screw	103H		Lead, Red, not shown
55A		Unit Plate Assembly	103J		Lead, Brown, not shown
56		Spring Clip	103K		Insulation Plate, Switch
57		Washer	104		Spring Washer, Switch
58		Screw	105		Nut, Switch
59	*63-7726	Control Cover Assembly	106	63-29106	Amplok Plug
60	*63-7727	Speed Control Knob	106A	63-29107	Amplok Insulation Plate
61	*63-7728	Auto/Manual Control Knob	106B	63-29108	Screw Fixing Amplok
62	63-27756	Transit Screw Clip	107	63-27780	Index Bracket Assembly
63	63-27813	Washer	107A	63-27782	Index Roller
			108	*63-7745	Index Spring
			109	63-27786	Lifting Spring

* Indicates New Stock Items.

Only items listed under stock numbers are available as Replacement Parts.

All parts subject to change or withdrawal without notice.

REPLACEMENT PARTS LIST

Insist on Genuine Factory Tested Parts, which are readily identified and may be purchased from Authorized Dealers.

SYMBOL	STOCK NO.	DESCRIPTION	SYMBOL	STOCK NO.	DESCRIPTION
		LIST OF PARTS BENEATH UNIT PLATE - Cont'd.			
110	63-27783	Support Bracket Assembly	115T		Earth Lead Assembly - not shown
110A	63-27785	Setting Blade	115U	63-24896	Thrust Ball - not shown
111		Spring Clip	115V		Earth Tag
112	63-29109	Speed Cam	115W		Lead Assembly - not shown
113	63-27778	Speed Lever	117	63-27789	Motor Plate Assembly
114	63-27799	Motor Mount	118	63-7110	Distance Piece
115	63-27856	Motor	119	63-24896	Voltage Changeover Block Bracket
115C		Bottom Cover Assembly	119A		Screw
115F	63-24948	Spring Washer	119B		Nut
115G	*63-7747	Motor Pulley 60 Cycle	119C	63-24948	Spring Washer
115G		Motor Pulley 50 Cycle	120A	63-22529	Changeover Block Assembly
115H		Top Cover Assembly	120B	63-27796	Insulation Plate
115J		Paired Bobbin Assembly	120C	63-7095	Cover for C. O. Block (Dual Voltage)
115J		Bobbin Assembly, Right	120C		Cover for C. O. Block (Plain)
115J		Bobbin Assembly, Left	120D		Connector
115K		Stator Assembly	120E	63-7102	Washer
115L		Tension Pin	120F	63-7101	Screw
115M	63-27788	Rotor Assembly	120G		Stud
115N	63-27790	Stud	120H		Nut
115P		Nut	120J		Tag
115S		Motor Pulley Grub Screw	120K	63-27795	Washer
			121	63-7069	Spring Mounting
			121A	*63-7748	Damping Pad

* Indicates New Stock Items.

Only items listed under stock numbers are available as Replacement Parts.

All parts subject to change or withdrawal without notice.



"HIS MASTER'S VOICE"