

BDV-E300/E301/T10/T11

SERVICE MANUAL

Ver. 1.0 2009.06

- BDV-E300/E301/T10/T11 are composed of following models.
As service manuals are issued for each component model, please refer to them..

US Model

BDV-E300/T10/T11

AEP Model

Australian Model

BDV-E300

UK Model

BDV-E300/E301

COMPONENT MODEL NAME

	BDV-E300	BDV-E301	BDV-T10	BDV-T11
BD/DVD receiver	HCD-E300	HCD-E301	HCD-T10	HCD-T11
Front speaker	SS-TSB93	SS-TSB95	SS-TSB95	SS-TSB95
Center speaker	SS-CTB91	SS-CTB92	SS-CTB92	SS-CTB92
Surround speaker	SS-TSB92	SS-TSB95	SS-TSB95	SS-TSB95
Subwoofer	SS-WSB91	SS-WSB92	SS-WSB92	SS-WSB92
DIGITAL MEDIA PORT adapter	TDM-iP20	TDM-iP20	TDM-iP20	TDM-iP20

Note 1: As for TDM-iP20, the part number has been described to this service manual.

Note 2: TDM-iP20 is attached only to US, UK and Australian models.

SPECIFICATIONS

General (BDV-E300/E301/T10/T11)

Power requirements

US model: 120 V AC, 60 Hz

Other models: 220 V – 240 V AC, 50/60 Hz

Power consumption

On: 160 W

Standby: 0.3 W (at the Power Saving mode)

Output voltage/current

(DIGITAL MEDIA PORT)

DC 5 V/700 mA

LAN (100)

100BASE-TX Terminal

EXT

External memory slot (For connecting the external memory)

DC output: 5 V 500 mA Max

Dimensions (approx.)

430 mm × 93 mm × 400 mm

(17 in × 3 3/4 in × 15 3/4 in)

(w/h/d) incl. projecting parts

Mass (approx.)

5.4 kg (11 lb 15 oz)

General (TDM-iP20: US, UK, Australian models)

Power requirements: DC IN: 5 V, 0.6 A (via DIGITAL MEDIA PORT)

Dimensions: Approx. ϕ 80 × 22 (h) mm (ϕ 3 1/4 × 7/8 (h) inch)

Mass: Approx. 132 g (4.7 oz) (includes cable)

Cable length: Approx. 1 m (3.3 ft)

Unpacking

- Front speakers (2)
- Surround speakers (2)
- Center speaker (1)
- Subwoofer (1)
- AM loop antenna (aerial) (1) (US model)
- FM wire antenna (aerial) (1)
- Speaker cords (6, white/red/blue/gray/green/purple) (BDV-E300)
- Speaker cords (5, white/red/blue/gray/green) (BDV-E301/T10/T11)
- Video cord (1)
- Remote commander (remote) (1)
- R6 (size AA) batteries (2)
- Calibration mic (1)
- Foot pads (1 set)
- Operating Instructions
- Speaker and TV Connections Guide
- Software Licence Information (AEP, UK and Australian models)
- Setup Disc (DVD) (US model)
- DIGITAL MEDIA PORT adapter (TDM-iP20) (1) (US, UK and Australian models)
- Operating Instructions for DIGITAL MEDIA PORT adapter (TDM-iP20) (US, UK and Australian models)
- HDMI cable (1) (BDV-T11)

Design and specifications are subject to change without notice.

– Refer to next page for accessories list –

BD/DVD HOME THEATRE SYSTEM

9-889-544-01

2009F05-1

© 2009.06

Sony Corporation

Audio&Video Business Group

Published by Sony Techno Create Corporation


SONY®

BDV-E300/E301/T10/T11

ACCESSORIES

Ref. No.	Part No.	Description	Remark
	4-127-348-21	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH) (for TDM-iP20) (US)	
	4-127-366-21	MANUAL, INSTRUCTION (ENGLISH) (for TDM-iP20) (UK, AUS)	
	4-147-229-13	MANUAL, INSTRUCTION (ENGLISH) (US)	
	4-147-229-33	MANUAL, INSTRUCTION (SPANISH) (US)	
	4-147-233-11	MANUAL, INSTRUCTION (ENGLISH) (AEP, UK, AUS)	
	4-147-233-21	MANUAL, INSTRUCTION (FRENCH) (AEP)	
	4-147-233-31	MANUAL, INSTRUCTION (GERMAN) (AEP)	
	4-147-233-41	MANUAL, INSTRUCTION (ITALIAN) (AEP)	
	4-147-233-51	MANUAL, INSTRUCTION (DUTCH) (AEP)	
	4-147-233-61	MANUAL, INSTRUCTION (SPANISH) (AEP)	
	4-147-233-71	MANUAL, INSTRUCTION (POLISH) (AEP)	
	4-147-233-81	MANUAL, INSTRUCTION (SWEDISH) (AEP)	
	4-147-235-11	MANUAL, INSTRUCTION (DANISH, FINNISH, PORTUGUESE) (AEP)	
	4-147-235-21	MANUAL, INSTRUCTION (GREEK) (AEP)	
	4-147-235-31	MANUAL, INSTRUCTION (CZECH, HUNGARIAN) (AEP)	
	4-147-235-41	MANUAL, INSTRUCTION (TURKISH) (AEP)	
	4-147-235-51	MANUAL, INSTRUCTION (SLOVAKIAN) (AEP)	
	4-149-821-01	DISK, SETUP (Setup Disc (DVD)) (US)	
1	1-754-059-12	ANTENNA, LOOP (AM loop antenna (aerial)) (US)	
2	1-754-060-21	ANTENNA (FM) (FM wire antenna (aerial)) (AEP, UK, AUS)	
2	1-793-184-41	CONNECTOR (F TYPE ADAPTOR) (FM wire antenna (aerial)) (US)	
3	1-836-210-21	CORD (WITH CONNECTOR) (SPEAKER) (Speaker cords: 6, red/white/green/gray/blue/purple) (BDV-E300)	
3	1-836-691-31	CORD (WITH CONNECTOR) (SPEAKER) (Speaker cords: 5, red/white/green/gray/blue) (BDV-E301/T10/T11)	
4	1-833-579-11	CORD, CONNECTION (Video cord)	
5	1-487-360-11	COMMANDER, STANDARD (RM-ADP035) (Remote commander (remote)) (AEP, UK, AUS)	
5	1-487-361-11	COMMANDER, STANDARD (RM-ADP034) (Remote commander (remote)) (US)	
6	1-542-774-11	MEASUREMENT MIC (MONO) (Calibration mic: ECM-AC2)	
7	2-639-385-01	FOOT (Foot pads: 4 pieces, 1 set)	
8	A-1609-467-A	OVERALL ASSY (TDM-iP20) (US, UK, AUS)	
9	3-277-581-01	FOOT (1 piece) (for TDM-iP20) (US, UK, AUS)	
10	1-835-855-11	CORD WITH CONNECTOR (HDMI CABLE) (BDV-T11)	

- Abbreviation
AUS : Australian model



MEMO

REVISION HISTORY

Checking the version allows you to jump to the revised page.

Also, clicking the version at the top of the revised page allows you to jump to the next revised page.

[illegible]