

STEREO CASSETTE-CORDER



TC-158SD

US Model
Canadian Model
AEP Model
E Model

CORRECTION

Correct the service manual as shown below.

No. 1
December, 1976

Incorrect	Correct
Adjustment Location:  The diagram shows the audio amp board with labels for 'audio amp board', 'RV101 (L-CH)', and 'RV201 (R-CH)'. The adjustment points are indicated by circles on the board.	Adjustment Location:  The diagram shows the audio amp board with labels for 'audio amp board', 'RV201 (R-CH)', and 'RV101 (L-CH)'. The adjustment points are indicated by circles on the board.

Sony Corporation

SONY®
SERVICE MANUAL