


TC-K55II

PRELIMINARY

*US Model
Canadian Model
AEP Model
UK Model
E Model*



STEREO CASSETTE DECK

GENERAL

- Power Requirements:** US, Canadian model
120 V ac, 60 Hz
AEP model
220 V ac, 50/60 Hz
(or 240 V ac adjustable by authorized
Sony personnel)
UK model
240 V ac, 50/60 Hz
(or 220 V ac, adjustable by authorized
Sony personnel)
E model
110, 120, 220 or 240 V ac adjustable,
50/60 Hz
- Power Consumption:** 22 W (US, Canadian model)
26 W (AEP, UK model)
29 W (E model)

SPECIFICATIONS

- Dimensions:** Approx. 430 (w) x 130 (h) x 290 (d) mm
17 (w) x 5 $\frac{1}{8}$ (h) x 11 $\frac{1}{2}$ (d) inches
(US, AEP, UK, E model)
Approx. 460 (w) x 130 (h) x 290 (d) mm
18 $\frac{1}{8}$ (w) x 5 $\frac{1}{8}$ (h) x 11 $\frac{1}{2}$ (d) inches
(Canadian model)
including projecting parts and controls
- Weight:** Approx. 5.2 kg, 11 lb 8 oz
(US, AEP, UK, E model)
Approx. 5.9 kg, 13 lb (Canadian model)

TAPE RECORDER SECTION

- Recording System:** 4-track 2-channel stereo
- Fast-forward and
Rewind Time:** Approx. 80 sec. (with C-60)
- Frequency Response:** DOLBY NR OFF

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UN TRAMÉ ET UNE MARQUE  SUR LES DIAGRAMMES SCHEMATIQUES, LES VUES EXPLOSÉES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DES SUPPLÉMENTS PUBLIÉS PAR SONY.

Tape Transport Mechanism Type		TCM-100V3
	Specification	Test Equipment
Forward Torque	28–43 g · cm (0.39–0.59 oz · inch)	Sony torque meter CQ-102
Back Tension Torque	2.5–4.5 g · cm (0.04–0.06 oz · inch)	Sony torque meter CQ-102
Pinch Roller Pressure	280–380 g (10–13 oz)	Spring scale or tension gauge

– Continued on page 2 –

SONY
SERVICE MANUAL

US, Canadian model

- With Type IV cassette (Sony METALLIC)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
- With TYPE III cassette (Sony Fe-Cr)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
- With TYPE II cassette (Sony EHF)
20–18,000 Hz
30–16,000 Hz (± 3 dB)
- With TYPE I cassette (Sony HFX)
20–17,000 Hz

AEP, UK, E model

- With TYPE IV cassette (Sony METALLIC)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
30–13,000 Hz (± 3 dB, 0 VU recording)
30–17,000 Hz (DIN)
- With TYPE III cassette (Sony Fe-Cr)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
30–17,000 Hz (DIN)
- With TYPE II cassette (Sony CD- α)
20–18,000 Hz
30–16,000 Hz (± 3 dB)
30–16,000 Hz (DIN)
- With TYPE I cassette (Sony BHF)
20–17,000 Hz
30–15,000 Hz (DIN)

Wow and Flutter: 0.04% WRMS (US, Canadian model)
0.04% WRMS (NAB) } (AEP, UK, E model)
 $\pm 0.12\%$ (DIN)

S/N Ratio: DOLBY NR OFF

US, Canadian model

- With TYPE III cassette (Sony Fe-Cr)
59 dB at peak level
- With TYPE II cassette (Sony EHF)
57 dB at peak level

AEP, UK, E, model

- With TYPE III cassette (Sony Fe-Cr)
59 dB at peak level (NAB)
57 dB (DIN, 1975, rev.)
- With TYPE II cassette (Sony CD- α)
57 dB at peak level (NAB)

DOLBY NR ON

Improved by 5 dB at 1 kHz, 10 dB above 5 kHz

Total Harmonic Distortion: 1.0% (with Sony Fe-Cr cassette)

Record Bias Frequency: 105 kHz

Inputs: MIC (two phone jacks)
sensitivity 0.25mV (-70 dB) for
a low-impedance microphone
LINE IN (two phono jacks)
sensitivity 77.5 mV (-20 dB)
input impedance 50 k Ω
REC/PB (connector) . . . (AEP, UK, E model)
input impedance less than 10 k Ω

Outputs: LINE OUT (two phono jacks)
output level 0.435 V (-5 dB) at load
impedance 50 k Ω
suitable load impedance more than 10 k Ω
Headphone (binaural jack)
output level -26 dB at load
impedance 8 Ω
REC/PB (connector) . . . (AEP, UK, E model)
output impedance less than 10 k Ω

0 dB = 0.775 V

SPECIFICATIONS

GENERAL

Dimensions:

Weight:

TAPE RECORDER SECTION

Recording System:

Fast Forward and

Reverse Time:

Frequency Response:

Power Requirement: US, Canadian model
120 V ac 60 Hz
AEP model
120 V ac 50/60 Hz
for 240 V ac operation, 1 authorized
factory personnel)
Power Consumption: 22 W (US, Canadian model)
18 W (AEP, UK model)
20 W (E model)
Tape Transport Mechanism Type: TCM-100V3
Specification: 30–43 g cm
(0.39–0.58 oz in-lb)
Forward Torque: 3.5–4.5 g cm
(0.04–0.08 oz in-lb)
Back Torque: 380–390 g
(10–13 oz)
Pinch Roll Pressure

SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY SHADING AND MARK
A ON THE SCHEMATIC DIAGRAMS, EXPLODED
VIEWS AND IN THE PARTS LIST ARE CRITICAL TO
SAFE OPERATION. REPLACE THESE COMPONENTS
WITH SONY PARTS WHOSE PART NUMBERS APPEAR
AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS
PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT
A LA SECURITE!

LES COMPOSANTS IDENTIFIES PAR UN TRAME ET
UNE MARQUE A SUR LES DIAGRAMMES SCHE-
MATIQUES, LES VUES EXPLOSEES ET LA LISTE
DES PIECES SONT CRITIQUES POUR LA SECURITE
DE FONCTIONNEMENT. NE REMPLACER CES
COMPOSANTS QUE PAR DES PIECES SONY. CONT-
RÔLER LES NUMEROS PARTS DONNES DANS CE MANUEL
OU DES SUPPLEMENTS PUBLIES PAR SONY.

1. SCHEMATIC DIAGRAM — System Control Section —

Refer to page 5 for voltages and waveforms at the terminals of IC801.

Note:

- All capacitors are in μF unless otherwise noted. $\text{pF} = \mu\text{F} \times 10^{-6}$
- All resistors are in ohms, $\frac{1}{4}\text{W}$ unless otherwise noted. $\text{k}\Omega : 1000\Omega, \text{M}\Omega = 1000\text{k}\Omega$
- : fusible resistor.
- : nonflammable resistor.
- 1% indicates component tolerance.
- : B+ bus.
- : B- bus.
- : panel designation.
- : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a VOM (20 $\text{k}\Omega/\text{V}$).
- no mark: STOP
- : FORWARD
- : FAST FORWARD
- : REWIND
- : RECORD
- : REC MUTE
- : PAUSE
- : STOP


- Voltage variations may be noted due to normal production tolerances.

Switch

Ref. No.	Switch	Position
S5	REWIND	OFF
S6	STOP	OFF
S7	FORWARD	OFF
S8	FAST FORWARD	OFF
S9	RECORD	OFF
S10	PAUSE	OFF
S11	REC MUTE	OFF
S12	COUNTER	OFF
S13	MEMORY	OFF
S14-1, 2	TIMER	OFF
S15	ACCIDENTAL-ERASURE PREVENTION	ON
S16	CASSETTE	OFF
S17	POWER	OFF

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



Handling Precautions for MOS ICs

Generally, the insulation resistance of the oxide layer in MOS IC structures is very high, and the oxide layer is very thin. Because of this, it is possible that the static voltages usually present on clothes and the human body will be enough to generate a potential difference across the insulator, high enough to cause a breakdown of the insulating layer.

The following precautions should be taken while handling these ICs.

(Particular care should be taken under conditions of low humidity.)

Precautions in Replacing MOS ICs

1. Store new ICs by inserting them into a urethane-polyester cushion (which is somewhat conductive), or wrapping it in aluminum foil, so that all the pins are at the same potential. (The ICs should be stored in that manner until mounted on the circuit board.)




Fig. A




Fig. B

2. Check the soldering iron for possible power-line leakage current. Make sure that there is no leakage path by connecting an ohmmeter to the tip of the soldering iron and the plug as shown in Fig. C. If there is a leakage path, use some other soldering iron.




Fig. C

3. Equalize any potential difference between the clothes, the tools in use, the work bench, the set being worked on, and the packaged IC by touching them all in succession with the hands or a conductive wire or tool.
4. The following are effective methods for handling ICs that remove the potential difference across the oxide layer.
 - Use a paper clip modified by soldering in a wire braid insert.




Fig. D




Fig. E




Fig. F

- Take a short length of fine bare wire and wind it around the IC so that it shorts all the pins of the IC, while it is still in the urethane-polyester cushion or aluminum foil. This ensures that all the pins are at the same potential.




Fig. G

- When it is necessary to handle the IC with the fingers, do not touch any pin, and hold the IC at the ends of its plastic-package case as shown in Fig. H.




Fig. H

5. Method of Mounting
Insert the IC while holding it with the modified clip, and solder all the pins with the clip still shorting the pins. (Similarly, solder all the pins while the bare shorting wire is still wound around them.). Remove the clip or the bare shorting wire only after all the pins have been soldered.

Precaution while Checking C-MOS ICs

The C-MOS ICs (Complementary MOS) are MOS ICs that have their output sections made up of N-channel and P-channel push-pull stages to increase their speed of operation. If the output terminal of these ICs comes into contact with B+ or B- voltage, then the FET which is ON at that time will either become shorted or open.

This is valid for all the output sections that are connected together by the interconnections. Even the circuits that are physically separated (and not on the same board) can be destroyed simultaneously.

Example:




Fig. I

Voltages and Waveforms at the Terminals of IC801.

Terminal No.	Waveform or Voltage	Terminal No.	Waveform or Voltage	Terminal No.	Waveform or Voltage
①		⑭		⑲	
②		⑮		⑳	
③		⑯		㉑	
④ to ⑥		⑰		㉒	
⑦		⑱		㉓	
⑧		㉔		㉕	
⑨		㉖		㉗	
⑩		㉘		㉙	
⑪		㉚		㉛	
⑫, ⑬		㉜		㉝	
		㉝		㉞	
		㉞		㉟	
		㉟		㊱	
		㊱		㊲	
		㊲		㊳	

2. MOUNTING DIAGRAM – System Control Section –
– Conductor Side –


1

2

3


4

5




Refer to page 5 for voltages and waveforms at the terminals of IC801.

Note:
• Color code of sleeving over the end of the jacket.




• Replacement Semiconductors
For replacement, use semiconductors except in ().


Q801: 2SD414




Q802, 811, 812: 2SA1027R (2SA1015)
Q824: 2SA1027R (2SA1026)




Q803, 806
Q813 (AEP, UK, E model): 2SC1364 (2SC1815)
Q814-816, 820




Q804, 821: 2SA952
Q818: 2SA684 (2SA773)




Q805, 808, 809: 2SC2001




Q807, 810
Q1004, 1006: 2SA684 (2SB564)




Q817: PH103-1M (PH103)




Q819: 2SC1475
Q1003, 1005: 2SC1474 (2SD471)




Q822, 823: 2SC1364




Q1001, 1002: 2SC1364 (2SC634A)



D801-804
D806-809 } : 10E2
D814
D805, 812, 815
D817, 819
D820 (AEP, UK, E model) } : 1S1555
D822-824
D831, 833
D834, 901-903 } : 1S1555 (1T40)




D810, 811, 816 } : HZ11B2L (HZ11B2)
D818, 832
D826: HZ15-2L
D1001: HZ6B2L (HZ6B1L)




D825: SR110




D827 (AEP, UK, E model): EQB01-12Z (EQB01-12)




D828: SEL1331G




D829: SEL1112R




D830: SEL1741Y




IC801: μ PD547C-042




IC802: MSM4069
IC901: μ PC339C



IC1001: CX069



IC902: μ PC4558C
IC1002: μ PC4558C (μ PC4558)




3. MOUNTING DIAGRAM — Audio Amp Section — — Conductor Side —


Replacement Semiconductors

For replacement, use semiconductors except in ().


Q101, 102, 104, 2SC1345
Q201, 202, 204 : 2SC1345
Q106, 206: 2SC2001




Q306: 2SC1475 (2SC1213A)




Q103, 203: 2SA1027R (2SA836)



Q105, 107, 108, 205, 207, 208 : 2SC1364
Q305, 308




D101, 201: 1T22AM (1T22)
D301, 302: 1S1555




D303: HZ6B2L (HZ6B1L)




Q301: 2SD414




D304—306: SEL1112R
D307, 308: SEL1312G




Q302: 2SC1364 (2SC458C)




IC101, 201: CX174




Q303: 2SA1027R (2SA844)
Q307: 2SA1027R (2SA1026)




IC301: μ PC4557C



Q304: 2SB548




IC302: TL489CP (TL489C)



Note:




- Color code of sleeving over the end of the jacket.



- : signal path
- : L-CH
- : R-CH

no mark: STOP


- ▶ : FORWARD
- ▶▶ : FAST FORWARD
- ◀ : REWIND
- ◐ : RECORD
- ◐◐ : REC MUTE
- : PAUSE
- : STOP



Q	IC	104	305	103	306	203	204	208	304	307	308	IC302	303	302	IC101	IC201	105	205	106	206	Q	IC
D				301								302	101		303	201					D	
					304, 305, 306, 307, 308																	

Q	IC	201	102	202	101	Q	IC

4. SCHEMATIC DIAGRAM — Audio Amp Section —



Note:

- Components for right channel have same values as for left channel. Reference numbers are coded from 200.
- All capacitors are in μF unless otherwise noted. $\text{pF} = \mu\text{F} \times 10^{-6}$
- All resistors are in ohms, $\frac{1}{4}\text{W}$ unless otherwise noted. $\text{k}\Omega : 1000 \Omega$, $\text{M}\Omega = 1000 \text{k}\Omega$
- : fusible resistor.
- : nonflammable resistor.
- (N) : low-noise.
- : B+ bus.
- : B- bus.
- : panel designation.
- : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.

- Readings are taken under no signal conditions with a VOM (20 $\text{k}\Omega/\text{V}$).
- no mark: STOP

- ▶ : FORWARD
- ▶▶ : FAST FORWARD
- ◀◀ : REWIND
- : RECORD
- : REC MUTE
- : PAUSE
- : STOP

- AC voltage readings in the bias oscillator circuit are taken with a VTVM.
- Voltage variations may be noted due to normal production tolerances.
- Switch


Ref. No.	Switch	Position
S1-1 to 1-4	INPUT SELECT	LINE
S2-1 to 2-4	DOLBY NR	OFF
S3-1 to 3-3	EQ	I
S4	BIAS	MED

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par un tramé et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(3)

(2)



Note: The components identified by shading and mark A are critical for safety. Replace only with part number specified.



- unless
- (-) =
- () =
- Circ
- Euro

(4)

- 5




3

4

Note:

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- (-) = slotted head
- (□□T) shows the number of coils in spring.
- Circled letters (A) to (Z) are applicable to European models only.



Note: Circled letters (A to Z) are applicable to European models only.

6. ELECTRICAL PARTS LIST

Ref. No. Part No. Description

SEMICONDUCTORS

Transistors

Q101, 201)	8-729-334-58	(B) 2SC1345
Q102, 202		
⇒ Q103, 203	8-729-612-77	(B) 2SA1027R
Q104, 204	8-729-334-58	(B) 2SC1345
Q105, 205	8-729-663-47	(C) 2SC1364
Q106, 206	8-729-100-13	(B) 2SC2001
Q107, 207)	8-729-663-47	(C) 2SC1364
Q108, 208)		
Q301	8-729-141-43	(B) 2SD414
⇒ Q302	8-729-663-47	(C) 2SC1364
⇒ Q303	8-729-612-77	(B) 2SA1027R
Q304	8-729-154-83	(B) 2SB548
Q305	8-729-663-47	(C) 2SC1364
⇒ Q306	8-760-413-10	(B) 2SC1475
Q307	8-729-612-77	(B) 2SA1027R
Q308	8-729-663-47	(C) 2SC1364
Q801	8-729-141-43	(B) 2SD414
⇒ Q802	8-729-612-77	(B) 2SA1027R
⇒ Q803	8-729-663-47	(C) 2SC1364
Q804	8-729-195-23	(B) 2SA952
Q805	8-729-100-13	(B) 2SC2001
⇒ Q806	8-729-663-47	(C) 2SC1364
⇒ Q807	8-729-468-43	(C) 2SA684
Q808, 809	8-729-100-13	(B) 2SC2001
⇒ Q810	8-729-468-43	(C) 2SA684
⇒ Q811, 812	8-729-612-77	(B) 2SA1027R
⇒ Q813	8-729-663-47	(C) 2SC1364 (AEP, UK, E model)
⇒ Q814-816	8-729-663-47	(C) 2SC1364
⇒ Q817	8-729-101-03	(C) PH103-1M
⇒ Q818	8-729-468-43	(C) 2SA684
⇒ Q819	8-760-413-10	(B) 2SC1475
⇒ Q820	8-729-663-47	(C) 2SC1364
Q821	8-729-195-23	(B) 2SA952
Q822, 823	8-729-663-47	(C) 2SC1364
⇒ Q824	8-729-612-77	(B) 2SA1027R
⇒ Q1001, 1002	8-729-663-47	(C) 2SC1364
⇒ Q1003	8-760-335-10	(B) 2SC1474

⇒: Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Ref. No. Part No. Description

⇒ Q1004	8-729-468-43	(C) 2SA684
⇒ Q1005	8-760-335-10	(C) 2SC1474
⇒ Q1006	8-729-468-43	(C) 2SA684

ICs

IC101, 201	8-759-101-74	(G) CX174
IC301	8-759-145-57	(D) μPC4557C
⇒ IC302	8-759-904-89	(D) TL489CP
IC801	8-759-147-42	(K) μPD547C-042
IC802	8-759-904-69	(C) MSM4069
IC901	8-759-133-90	(F) μPC339C
IC902	8-759-145-58	(D) μPC4558C
IC1001	8-750-690-00	(D) CX069
⇒ IC1002	8-759-145-58	(D) μPC4558C

Diodes

⇒ D101, 201	8-719-422-21	(B) 1T22AM
D301	 8-719-815-55	(B) 1S1555
D302	8-719-815-55	(B) 1S1555
⇒ D303	8-719-910-65	(B) HZ6B2L
D304-306	8-719-311-12	(B) SEL1112R
D307, 308	8-719-313-12	(B) SEL1312G
D801-804	 8-719-200-02	(B) 10E2
D805	8-719-815-55	(B) 1S1555
D806-809	 8-719-200-02	(B) 10E2
⇒ D810, 811	8-719-910-15	(B) HZ11B2L
D812	8-719-815-55	(B) 1S1555

D814	8-719-200-02	(B) 10E2
D815	 8-719-815-55	(B) 1S1555
⇒ D816	8-719-910-15	(B) HZ11B2L
D817	 8-719-815-55	(B) 1S1555
⇒ D818	8-719-910-15	(B) HZ11B2L
D819	8-719-815-55	(B) 1S1555
D820	8-719-815-55	(B) 1S1555 (AEP, UK model)
D822-824	8-719-815-55	(B) 1S1555
D825	8-719-101-11	(B) SR110

Note: Les composants identifiés par un trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A) to (Z) are applicable to European models only.

Ref. No.	Part No.	Description
D826	8-719-910-52 (B)	HZ15-2L
⇒ D827	8-719-930-12 (B)	EQB01-12Z (AEP, UK, E model)
D828		SEL1331G
D829	8-719-311-12 (B)	SEL1112R
D830		SEL1741Y
⇒ D831	8-719-815-55 (B)	1S1555
⇒ D832	8-719-910-15 (B)	HZ11B2L
⇒ D833,834 D901-903	8-719-815-55 (B)	1S1555
⇒ D1001	8-719-910-65 (B)	HZ6B2L

COILS

L101, 201	1-407-211-XX (B)	27 mH, microinductor
-----------	------------------	----------------------

TRANSFORMERS

T301	1-433-132-11 (B)	Osc
T801	1-446-351-00 (M)	Power (AEP, UK model)
	1-446-368-00	Power (US, Canadian model)
	1-446-518-00	Power (E model)

CAPACITORS

All capacitors are in μF and ceramic unless otherwise noted. 50WV or less are not indicated except for electrolytics and tantalum. p : μF , elect : electrolytic.

C101, 201	1-121-450-00 (A)	2.2	50 V	elect
C102, 202	1-161-323-00 (A)	0.001		
C103, 203	1-121-230-00 (B)	2.2	50 V	elect (nonpolarized)
C104, 204	1-123-307-00 (B)	100	10 V	elect
C105, 205	1-123-308-00 (A)	220	10 V	elect
C106, 206	1-121-392-00 (A)	3.3	25 V	elect
C107, 207	1-121-651-00 (A)	10	16 V	elect
C108, 208	1-161-314-00 (A)	180p		
C109, 209	1-161-316-00 (A)	270p		
C110, 210	1-161-271-00 (A)	100p		
C111, 211	1-121-421-00 (B)	220	16 V	elect
C112, 212	1-130-309-00 (A)	0.033	100 V	polyethylene

Ref. No.	Part No.	Description
C113, 213	1-161-316-00 (A)	270p
C114, 214	1-121-450-00 (A)	2.2 50 V elect
C115, 215	1-121-421-00 (B)	220 16 V elect
C116, 216	1-121-414-00 (A)	100 10 V elect
C117, 217	1-161-314-00 (A)	180p
C118, 218	1-108-569-00 (B)	0.0039
C119, 219	1-121-409-00 (A)	47 16 V elect
C120, 220		
C121, 221	1-123-230-00	2.2 50 V elect (nonpolarized)
C122, 222	1-108-585-00 (B)	0.018 mylar
C123, 223	1-161-347-00 (A)	110p
C124, 224	1-161-268-00 (A)	56p
C125, 225	1-161-257-00 (A)	6.8p
C126, 226	1-161-268-00 (A)	56p
C127, 227	1-121-651-00 (A)	10 16 V elect
C128, 228	1-123-286-00 (A)	0.33 50 V elect
C129, 229	1-108-251-00 (B)	0.1 mylar
C130, 230	1-108-239-00 (A)	0.01 mylar
C131, 231	1-108-360-00 (A)	0.039 mylar
C132, 232	1-121-651-00 (A)	10 16 V elect
C134, 234	1-108-597-00 (A)	0.056 mylar
C135, 235	1-108-573-00 (B)	0.0056 mylar
C136, 236	1-108-589-00 (B)	0.027 mylar
C137, 237	1-108-597-00 (A)	0.056 mylar
C138, 238	1-121-395-00 (A)	4.7 25 V elect
C139, 239	1-123-230-00 (B)	2.2 50 V elect (nonpolarized)
C140, 240	1-121-392-00 (A)	3.3 25 V elect
C141, 241	1-121-651-00 (A)	10 16 V elect
C142, 242	1-121-414-00 (B)	100 10 V elect
C147, 247	1-107-168-00 (A)	91p 500 V mica
C148, 248	1-141-225-00 (C)	Trimmer
C149, 249	1-161-375-00 (A)	0.0022
C150, 250	1-107-097-00 (A)	330p mica
C151, 251	1-123-307-00 (B)	100 10 V elect
C152, 252	1-121-415-00 (A)	100 16 V elect
C154, 254	1-107-159-00 (A)	33p 500 V silvered mica
C156, 256	1-108-573-00 (B)	0.0056 mylar
C157, 257	1-108-571-00 (B)	0.0047 mylar

⇒ : Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A to Z) are applicable to European models only.

Ref. No.	Part No.	Description
C158, 258	1-108-581-00 (B) 0.012	mylar
C159, 259	1-108-569-00 (B) 0.0039	mylar
C160, 260	1-108-585-00 (B) 0.018	mylar
C161, 261	1-108-587-00 (B) 0.022	mylar
C162, 262	1-108-569-00 (B) 0.0039	mylar
C163, 263	1-161-314-00 (A) 180p	
C301-303	1-121-421-00 (B) 220	16 V elect
C304, 305	1-121-422-00 (B) 220	25 V elect
C306	1-123-228-00 (B) 1	50 V elect (nonpolarized)
C307	1-123-330-00 (A) 22	25 V elect
C308	1-130-336-00 (B) 0.0068	630 V polyethylene
C309	1-131-237-00 (B) 1.5	25 V tantalum
C310	1-130-297-00 (A) 0.01	100 V polyethylene
C311	1-130-303-00 (A) 0.018	100 V polyethylene
C312	1-121-353-00 (A) 2.2	50 V elect
C313	1-131-196-00 (B) 2.2	20 V tantalum
C314	1-161-039-00 (A) 0.001	
C317	1-121-726-00 (A) 0.47	50 V elect
C318	1-121-391-00 (A) 1	50 V elect
C320	1-123-333-00 (A) 100	25 V elect
C801, 802	(A) 1-121-657-00 (B) 1000	25 V elect
	(A) 1-123-326-00 3300	16 V elect (US, Canadian model)
C803, 804	(A) 1-123-324-00 (B) 1000	16 V elect (AEP, UK, E model)
C805	1-121-403-00 (A) 33	16 V elect
C806	1-123-329-00 (A) 10	25 V elect
C807	1-123-316-00 (A) 10	16 V elect
C808	1-123-328-00 (A) 4.7	25 V elect
C809	1-123-320-00 (A) 100	16 V elect
C810	1-123-308-00 (A) 220	10 V elect
C811	1-123-329-00 (A) 10	25 V elect (AEP, UK, E model)
C812	1-123-316-00 (A) 10	16 V elect
C813	1-123-352-00 (A) 1	50 V elect
C814	1-108-591-00 (B) 0.033	mylar
C815, 816	1-123-351-00 (A) 0.47	50 V elect
C817	1-123-328-00 (A) 4.7	25 V elect
C818, 819	1-123-351-00 (A) 0.47	50 V elect

Ref. No.	Part No.	Description
C820	1-123-352-00 (A) 1	50 V elect
C821, 822	1-161-263-00 (A) 22p	
C824	1-121-403-00 (A) 33	16 V elect
C825	1-123-353-00 (A) 2.2	50 V elect
C826, 827	1-108-239-00 (A) 0.01	mylar
C828	1-123-352-00 (A) 1	50 V elect (US, Canadian model)
C830, 831	1-161-051-00 (A) 0.01	
C1001, 1002	1-123-306-00 (B) 47	10 V elect
C1003	1-121-409-00 (A) 47	16 V elect
C1004	1-123-354-00 (A) 3.3	50 V elect
C1005	1-130-134-00 (B) 0.082	100 V polyethylene
C1006-1008	1-161-379-00 (A) 0.01	
C1009	1-108-583-00 (A) 0.015	mylar

RESISTORS

All resistors are in ohms. Common ¼W carbon resistors are omitted. Refer to the list on page 27 for their part numbers.

R114, 214	1-244-913-00 (A) 47 k	¼ W carbon
R119, 219	1-244-847-00 (A) 82	¼ W carbon
R123, 223	1-244-885-00 (A) 3.3 k	¼ W carbon
R155, 255	1-244-881-00 (A) 2.2 k	¼ W carbon
R156, 256		
R179, 279	1-244-929-00 (A) 220 k	¼ W carbon
R301	(A) 1-214-733-00 (A) 1.5 k	¼ W metal oxide
R302	(A) 1-214-723-00 (A) 560	¼ W metal oxide
R303	(A) 1-214-729-00 (A) 1 k	¼ W metal oxide
R304	(A) 1-214-732-00 (A) 1.3 k	¼ W metal oxide

R312	(A) 1-213-134-00 (A) 180	1 W metal oxide (nonflammable)
------	--------------------------	--------------------------------

R320	(A) 1-246-461-00 (A) 330	¼ W carbon
R321	(A) 1-246-455-00 (A) 180	¼ W carbon
R322	(A) 1-212-878-00 (A) 75	¼ W fusible
R324	1-214-777-00 (A) 100 k	¼ W metal oxide
R338	(A) 1-244-866-00 (A) 510	½ W carbon

R340, 341	(A) 1-212-958-00 (B) 10	½ W fusible
R342	1-244-866-00 (A) 510	½ W carbon

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A to Z) are applicable to European models only.

Ref. No.	Part No.	Description
R343, 344	1-212-958-00	10 1/2 W fusible
R803	1-244-873-00	(A) 1 k 1/2 W carbon (AEP, UK, E model)

R814, 815	1-212-857-00	(A) 10 1/4 W fusible
R832	1-213-133-00	(A) 150 1 W metal oxide (AEP, UK, E model)
R878	1-212-859-00	12 fusible (AEP, UK, E model)
R880	1-217-395-00	(B) 47 1/4 W fusible (AEP, UK, E model)
	1-247-208-00	(A) 47 1/2 W carbon (nonflammable) (US, Canadian model)

R1001	1-214-777-00	(A) 100 k 1/4 W metal oxide (1%)
RV101, 201	1-226-295-00	(E) 50k/50k-A, variable; REC LEVEL
RV102, 202	1-224-646-XX	(B) 22k-B, adjustable; playback level
RV103, 203	1-224-647-XX	(B) 47k-B, adjustable; record level
RV1001	1-226-433-00	(A) 50k-B, adjustable; tape speed.

SWITCHES

S1	1-552-879-00	(C) Pushbutton, INPUT SELECT
S2	1-552-880-00	(C) Slide, DOLBY NR
S3	1-552-878-00	(D) Slide, EQ
S4	1-552-877-00	(C) Slide, BIAS
S5-11	1-552-919-22	(K) Block, function

S13	1-552-940-00	(C) Slide, MEMORY
S14	1-552-520-00	(C) Slide, timer
S15, 16	1-552-268-00	(B) Slide, accidental-erasure prevention, cassette

S17	1-552-530-00	Pushbutton, POWER (US, Canadian model)
	1-552-903-00	(D) Pushbutton, POWER (AEP, UK, E model)

JACKS

CNJ101,201	1-507-525-00	(D) MIC
CNJ102,202	1-507-531-00	(C) LINE IN, LINE OUT (US, Canadian model)
CNJ103,203		

Ref. No.	Part No.	Description
CNJ102,202	1-536-501-21	(D) LINE IN, LINE OUT, REC/PB (AEP, UK, E model)
CNJ103,203		
CNJ302		
CNJ301	1-507-483-00	(C) HEADPHONES

MISCELLANEOUS

CNJ901	1-561-293-00	(D) Socket, REMOTE
CP1	1-231-057-31	(B) Encapsulated Component (E model)
	1-231-326-11	Encapsulated Component (US model)
	1-231-341-00	Encapsulated Component (Canadian model)
CP1, 2	1-130-267-00	(C) Capacitor, 0.22 250V film (AEP, UK model)

HE402	8-825-724-00	(D) Head, erase; EF201-36
HRP401	8-825-712-10	(O) Head, record/playback; PS185-3602A1

LPF101, 201	1-231-388-00	(D) Filter, low-pass
M1	X-3564-017-0	(K) Motor Ass'y, capstan
M2	X3564-015-0	(I) Motor Ass'y, reel
ME101, 201	1-520-341-51	(F) Meter Unit
PL1	1-518-299-91	(B) Lamp, cassette

PL2, 3	1-518-351-00	(B) Lamp, meter
PM1	1-454-222-11	(D) Solenoid, brake
PM2	1-454-222-21	(D) Solenoid, head
RY301	1-515-323-00	(G) Relay
RY302	1-515-297-00	(F) Relay, reed (AEP, UK, E model)

1-526-576-21	Voltage Selector (E model)
1-534-777-00	(D) Cord, power (UK model)
1-534-817-XX	(D) Cord, power (AEP model)
1-534-986-XX	Cord, power (US, Canadian model)
1-551-473-31	Cord, power; parallel-blade plug (E model)

1-551-530-00	Cord, power; euro-plug (E model)
1-560-064-00	(A) Pin, connector

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un tramé et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A) to (Z) are applicable to European models only.

ACCESSORIES AND PACKING MATERIALS

<u>Part No.</u>	<u>Description</u>
X-3701-105-0	(A) Tip Ass'y, head cleaning
1-551-734-11	(D) Cord, connection RK-74A
3-429-126-00	Bag, plastic (Canadian model)
3-561-142-00	Cushion, upper-front (Canadian model)
3-561-143-00	Cushion, upper-rear (Canadian model)
3-561-144-00	Cushion, bottom-right (Canadian model)
3-561-145-00	Cushion, bottom-left (Canadian model)
3-566-148-00	(B) Cushion, upper-front (US, AEP, UK, E model)
3-566-149-00	(B) Cushion, upper-rear (US, AEP, UK, E model)
3-566-150-00	(B) Cushion, bottom-right (US, AEP, UK E model)
3-566-151-00	(B) Cushion, bottom-left (US, AEP, UK E model)
3-566-165-00	(D) Carton (US, AEP UK, E model)
3-566-166-00	Carton (Canadian model)
3-701-630-00	(A) Bag, plastic
3-701-684-00	(A) Card, voltage indication (AEP model)
3-770-991-11	Manual, instruction (AEP, UK, E model)
3-770-991-21	Manual, instruction (US model)
3-770-991-21)	Manual, instruction (Canadian model)
3-794-575-31	
3-793-828-11	(A) Caution Card, cassette
3-794-233-21	(A) Separate Sheet, consumer products (US model)
4-818-924-00	(B) Bag, plastic


1/4 WATT CARBON RESISTORS Ⓐ

Note: Circled letter Ⓐ is applicable to European models only.

Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.
1.0	1-246-401-00	10	1-246-425-00	100	1-246-449-00	1.0k	1-246-473-00	10k	1-246-497-00	100k	1-246-521-00	1.0M	1-246-545-00
1.1	1-246-402-00	11	1-246-426-00	110	1-246-450-00	1.1k	1-246-474-00	11k	1-246-498-00	110k	1-246-522-00	1.1M	1-210-814-00
1.2	1-246-403-00	12	1-246-427-00	120	1-246-451-00	1.2k	1-246-475-00	12k	1-246-499-00	120k	1-246-523-00	1.2M	1-210-815-00
1.3	1-246-404-00	13	1-246-428-00	130	1-246-452-00	1.3k	1-246-476-00	13k	1-246-500-00	130k	1-246-524-00	1.3M	1-210-816-00
1.5	1-246-405-00	15	1-246-429-00	150	1-246-453-00	1.5k	1-246-477-00	15k	1-246-501-00	150k	1-246-525-00	1.5M	1-210-817-00
1.6	1-246-406-00	16	1-246-430-00	160	1-246-454-00	1.6k	1-246-478-00	16k	1-246-502-00	160k	1-246-526-00	1.6M	1-210-818-00
1.8	1-246-407-00	18	1-246-431-00	180	1-246-455-00	1.8k	1-246-479-00	18k	1-246-503-00	180k	1-246-527-00	1.8M	1-210-819-00
2.0	1-246-408-00	20	1-246-432-00	200	1-246-456-00	2.0k	1-246-480-00	20k	1-246-504-00	200k	1-246-528-00	2.0M	1-210-820-00
2.2	1-246-409-00	22	1-246-433-00	220	1-246-457-00	2.2k	1-246-481-00	22k	1-246-505-00	220k	1-246-529-00	2.2M	1-210-821-00
2.4	1-246-410-00	24	1-246-434-00	240	1-246-458-00	2.4k	1-246-482-00	24k	1-246-506-00	240k	1-246-530-00	2.4M	1-244-754-00
2.7	1-246-411-00	27	1-246-435-00	270	1-246-459-00	2.7k	1-246-483-00	27k	1-246-507-00	270k	1-246-531-00	2.7M	1-244-755-00
3.0	1-246-412-00	30	1-246-436-00	300	1-246-460-00	3.0k	1-246-484-00	30k	1-246-508-00	300k	1-246-532-00	3.0M	1-244-756-00
3.3	1-246-413-00	33	1-246-437-00	330	1-246-461-00	3.3k	1-246-485-00	33k	1-246-509-00	330k	1-246-533-00	3.3M	1-244-757-00
3.6	1-246-414-00	36	1-246-438-00	360	1-246-462-00	3.6k	1-246-486-00	36k	1-246-510-00	360k	1-246-534-00	3.6M	1-244-758-00
3.9	1-246-415-00	39	1-246-439-00	390	1-246-463-00	3.9k	1-246-487-00	39k	1-246-511-00	390k	1-246-535-00	3.9M	1-244-759-00
4.3	1-246-416-00	43	1-246-440-00	430	1-246-464-00	4.3k	1-246-488-00	43k	1-246-512-00	430k	1-246-536-00	4.3M	1-244-760-00
4.7	1-246-417-00	47	1-246-441-00	470	1-246-465-00	4.7k	1-246-489-00	47k	1-246-513-00	470k	1-246-537-00	4.7M	1-244-761-00
5.1	1-246-418-00	51	1-246-442-00	510	1-246-466-00	5.1k	1-246-490-00	51k	1-246-514-00	510k	1-246-538-00	5.1M	1-244-762-00
5.6	1-246-419-00	56	1-246-443-00	560	1-246-467-00	5.6k	1-246-491-00	56k	1-246-515-00	560k	1-246-539-00		
6.2	1-246-420-00	62	1-246-444-00	620	1-246-468-00	6.2k	1-246-492-00	62k	1-246-516-00	620k	1-246-540-00		
6.8	1-246-421-00	68	1-246-445-00	680	1-246-469-00	6.8k	1-246-493-00	68k	1-246-517-00	680k	1-246-541-00		
7.5	1-246-422-00	75	1-246-446-00	750	1-246-470-00	7.5k	1-246-494-00	75k	1-246-518-00	750k	1-246-542-00		
8.2	1-246-423-00	82	1-246-447-00	820	1-246-471-00	8.2k	1-246-495-00	82k	1-246-519-00	820k	1-246-543-00		
9.1	1-246-424-00	91	1-246-448-00	910	1-246-472-00	9.1k	1-246-496-00	91k	1-246-520-00	910k	1-246-544-00		


HARDWARE NOMENCLATURE

Screw:



Unless otherwise indicated, it means cross-recessed head (Phillips type).

Nut, Washer, Retaining ring:



Reference Designation	Shape	Description	Remarks
SCREWS			
P		pan-head screw	binding-head (B) screw for replacement
PWH		pan-head screw with washer face	binding-head (B) screw and flat washer for replacement
PS PSP		pan-head screw with spring washer	binding-head (B) screw and spring washer for replacement
PSW PSPW		pan-head screw with spring and flat washers	binding-head (B) screw and spring and flat washers for replacement
R		round-head screw	binding-head (B) screw for replacement
K		flat-countersunk-head screw	
RK		oval-countersunk-head screw	
B		binding-head screw	
T		truss-head screw	binding-head (B) screw for replacement
F		flat-fillister-head screw	
RF		fillister-head screw	
BV		brazer-head screw	

Reference Designation	Shape	Description	Remarks
SELF-TAPPING SCREWS			
TA		self-tapping screw	ex: TA, P 3 x 10
PTP		pan-head self-tapping screw	binding-head self-tapping (TA, B) screw for replacement
PTPWH		pan-head self-tapping screw with washer face	binding-head self-tapping (TA, B) screw and flat washer for replacement
PTTWH		pan-head thread-rolling screw with washer face	binding-head (B) screw and flat washer for replacement
SET SCREWS			
SC		set screw	
SC		hexagon-socket set screw	ex: SC 2.6 x 4, hexagon socket
NUT			
N		nut	
WASHERS			
W		flat washer	
SW		spring washer	
LW		internal-tooth lock washer	ex: LW3, internal
LW		external-tooth lock washer	ex: LW3, external
RETAINING RINGS			
E		retaining ring	
G		grip-type retaining ring	

Sony Corporation

© 1979

79G0539-1

Printed in Japan

9-954-822-01

TC-K55II

*US Model
Canadian Model
AEP Model
UK Model
E Model*



'Dolby' and the double-D symbol are the trade marks of Dolby Laboratories. Noise reduction system manufactured under license from Dolby Laboratories.

STEREO CASSETTE DECK

GENERAL

SPECIFICATIONS

Power Requirements: US, Canadian model
120 V ac, 60 Hz
AEP model
220 V ac, 50/60 Hz
(or 240 V ac adjustable by authorized Sony personnel)
UK model
240 V ac, 50/60 Hz
(or 220 V ac, adjustable by authorized Sony personnel)
E model
110, 120, 220 or 240 V ac adjustable, 50/60 Hz

Power Consumption: 22 W (US, Canadian model)
26 W (AEP, UK model)
29 W (E model)

Dimensions: Approx. 430 (w) x 130 (h) x 290 (d) mm
17 (w) x 5 1/8 (h) x 11 1/2 (d) inches
(US, AEP, UK, E model)
Approx. 460 (w) x 130 (h) x 290 (d) mm
18 1/8 (w) x 5 1/8 (h) x 11 1/2 (d) inches
(Canadian model)
including projecting parts and controls

Weight: Approx. 5.2 kg, 11 lb 8 oz
(US, AEP, UK, E model)
Approx. 5.9 kg, 13 lb (Canadian model)

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UN TRAMÉ ET UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES, LES VUES EXPLOSÉES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DES SUPPLÉMENTS PUBLIÉS PAR SONY.

Tape Transport Mechanism Type		TCM-100V3
	Specification	Test Equipment
Forward Torque	28–43 g · cm (0.39–0.59 oz · inch)	Sony torque meter CQ-102
Back Tension Torque	2.5–4.5 g · cm (0.04–0.06 oz · inch)	Sony torque meter CQ-102
Pinch Roller Pressure	280–380 g (10–13 oz)	Spring scale or tension gauge

— Continued on page 2 —

SONY
SERVICE MANUAL

TAPE RECORDER SECTION

Recording System: 4-track 2-channel stereo

Fast-forward and Rewind Time: Approx. 80 sec. (with C-60)

Frequency Response: DOLBY NR OFF

US, Canadian model

- With Type IV cassette (Sony METALLIC)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
30–13,000 Hz (± 3 dB, 0 VU recording)
- With TYPE III cassette (Sony Fe-Cr)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
- With TYPE II cassette (Sony EHF)
20–18,000 Hz
30–16,000 Hz (± 3 dB)
- With TYPE I cassette (Sony HFX)
20–17,000 Hz

AEP, UK, E model

- With TYPE IV cassette (Sony METALLIC)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
30–13,000 Hz (± 3 dB, 0 VU recording)
30–17,000 Hz (DIN)
- With TYPE III cassette (Sony Fe-Cr)
20–19,000 Hz
30–17,000 Hz (± 3 dB)
30–17,000 Hz (DIN)
- With TYPE II cassette (Sony CD- α)
20–18,000 Hz
30–16,000 Hz (± 3 dB)
30–16,000 Hz (DIN)
- With TYPE I cassette (Sony BHF)
20–17,000 Hz
30–15,000 Hz (DIN)

Wow and Flutter: 0.04% WRMS (US, Canadian model)
0.04% WRMS (NAB) } (AEP, UK, E model)
 $\pm 0.12\%$ (DIN)

S/N Ratio: DOLBY NR OFF

US, Canadian model

- With TYPE III cassette (Sony Fe-Cr)
59 dB at peak level
- With TYPE II cassette (Sony EHF)
57 dB at peak level

AEP, UK, E, model

- With TYPE III cassette (Sony Fe-Cr)
59 dB at peak level (NAB)
- With TYPE II cassette (Sony CD- α)
57 dB at peak level (NAB)

DOLBY NR ON
Improved by 5 dB at 1 kHz, 10 dB above 5 kHz

Total Harmonic Distortion: 1.0% (with Sony Fe-Cr cassette)

Record Bias Frequency: 105 kHz


Inputs: MIC (two phone jacks)
sensitivity 0.25mV (-70 dB) for a low-impedance microphone
LINE IN (two phono jacks)
sensitivity 77.5 mV (-20 dB)
input impedance 50 k Ω
REC/PB (connector) . . . (AEP, UK, E model)
input impedance less than 10 k Ω

Outputs: LINE OUT (two phono jacks)
output level 0.435 V (-5 dB) at load
impedance 50 k Ω
suitable load impedance more than 10 k Ω
HEADPHONES (binaural jack)
output level -26 dB at load
impedance 8 Ω
REC/PB (connector) . . . (AEP, UK, E model)
output impedance less than 10 k Ω

0 dB = 0.775 V

MODEL IDENTIFICATION

— Specification Label —



US, Canadian model: AC 120V ~ 60Hz 22W


AEP model: AC 220V ~ 50/60 Hz 26W

UK model: AC 240V ~ 50/60 Hz 26W


E model: AC 110, 120, 220, 240V ~ 50/60 Hz 29W

— Power Cord —

E model: euro-plug 1-551-530-00



E model: parallel-blade plug 1-551-473-31



SERVICING NOTE

When the top cover is removed the internal photo transistor may pick up stray light and shut the set off.

Handling Precautions for MOS IC IC801 (μ PD547C-042)



Generally, the insulation resistance of the oxide layer in MOS IC structures is very high, and the oxide layer is very thin. Because of this, it is possible that the static voltages usually present on clothes and the human body will be enough to generate a potential difference across the insulator, high enough to cause a breakdown of the insulating layer.

The following precautions should be taken while handling these ICs.


(Particular care should be taken under conditions of low humidity.)

Precautions in Replacing MOS ICs


1. Store new ICs by inserting them into a urethane-polyester cushion (which is somewhat conductive), or wrapping it in aluminum foil, so that all the pins are at the same potential. (The ICs should be stored in that manner until mounted on the circuit board.)





2. Check the soldering iron for possible power-line leakage current. Make sure that there is no leakage path by connecting an ohmmeter to the tip of the soldering iron and the plug as shown in Fig. C. If there is a leakage path, use some other soldering iron.



3. Equalize any potential difference between the clothes, the tools in use, the work bench, the set being worked on, and the packaged IC by touching them all in succession with the hands or a conductive wire or tool.
4. The following are effective methods for handling ICs that remove the potential difference across the oxide layer.
 - Use a paper clip modified by soldering in a wire braid insert.



Make sure that there is no solder on the inside.



Make sure that all the pins are in contact with the wire braid (all the pins will then be at the same potential.).

- Take a short length of fine bare wire and wind it around the IC so that it shorts all the pins of the IC, while it is still in the urethane-polyester cushion or aluminum foil. This ensures that all the pins are at the same potential.




Fig. G

- When it is necessary to handle the IC with the fingers, do not touch any pin, and hold the IC at the ends of its plastic-package case as shown in Fig. H.




Fig. H

5. Method of Mounting

Insert the IC while holding it with the modified clip, and solder all the pins with the clip still shorting the pins. (Similarly, solder all the pins while the bare shorting wire is still wound around them.). Remove the clip or the bare shorting wire only after all the pins have been soldered.

Precaution while Checking C-MOS ICs

The C-MOS ICs (Complementary MOS) are MOS ICs that have their output sections made up of N-channel and P-channel push-pull stages to increase their speed of operation. If the output terminal of these ICs comes into contact with B+ or B- voltage, then the FET which is ON at that time will either become shorted or open.

This is valid for all the output sections that are connected together by the interconnections. Even the circuits that are physically separated (and not on the same board) can be destroyed simultaneously.

Example:






Fig. I

SECTION 1 OUTLINE

1-1. BLOCK DIAGRAM — Audio Amp Section —



— System Control Section —



SECTION 2 DISASSEMBLY


- Follow the disassembly procedure in the numerical order given.

TOP COVER/FRONT PANEL/BOTTOM PLATE REMOVAL


①, ② : TOP COVER

① - ⑤ : FRONT PANEL


⑥, ⑦ : BOTTOM PLATE



CASSETTE-HOLDER LID REMOVAL



MECHANICAL BLOCK REMOVAL



SECTION 3

ADJUSTMENTS

3-1. MECHANICAL ADJUSTMENTS

PRECAUTION



- Clean the following parts with a denatured-alcohol-moistened swab:


record/playback head	pinch roller
erase head	rubber belts
capstan	idlers
- Demagnetize the record/playback head with a head demagnetizer.
- Do not use a magnetized screwdriver for the adjustments.
- After the adjustments, apply suitable locking compound to the parts adjusted.
- The adjustments should be performed with the rated power supply voltage unless otherwise noted.

Torque Measurement and Back Tension Torque Adjustment

- | Torque | Torque meter | Meter reading |
|--------------|--------------|---|
| Forward | CQ-102 | 28–43 g · cm
(0.39–0.59 oz · inch) |
| Back tension | CQ-102 | 2.5–4.5 g · cm
(0.04–0.06 oz · inch) |


- If the specified back-tension torque is not obtained, change the hooking position.






Head Height Adjustment

1. Prepare an adjustment cassette as shown below.





2. In playback mode and viewing from the front, adjust the head heights to eliminate tape curl and tape twist at portions shown by arrow.



Pinch Roller Pressure Measurement — Forward Mode —

Slowly pull the pinch roller and read the tension gauge just when the pinch roller stops rotating after separating from the capstan.





Brake Solenoid (PM1) Position Adjustment

— Stop Mode —




Fig. 1-a.





Fig. 1-b.



Head Solenoid (PM2) Position Adjustment — Stop Mode —




Fig. 2-a





Fig. 2-b

4-3. MOUNTING DIAGRAM — Audio Amp Section — — Conductor Side —


Replacement Semiconductors

For replacement, use semiconductors except in ().


Q101, 102, 104, 2SC1345
Q201, 202, 204
Q106, 206: 2SC2001




Q306: 2SC1475 (2SC1213A)




Q103, 203: 2SA1027R (2SA836)




D101, 201: 1T22AM (1T22)
D301, 302: 1S1555




Q105, 107, 108
Q205, 207, 208
Q305, 308




D303: HZ6B2L (HZ6B1L)




Q301: 2SD414




D304—306: SEL1112R
D307, 308: SEL1312G




Q302: 2SC1364 (2SC458C)




IC101, 201: CX174




Q303: 2SA1027R (2SA844)
Q307: 2SA1027R (2SA1026)




IC301: μPC4557C



Q304: 2SB548




IC302: TL489CP (TL489C)






Note:

- Color code of sleeving over the end of the jacket.



- B+ pattern
- B- pattern
- signal path
- L-CH
- R-CH


- no mark: STOP
- ▶: FORWARD
- ▶▶: FAST FORWARD
- ◀: REWIND
- ◀◀: RECORD
- ◐: REC MUTE
- : PAUSE
- : STOP



Q	IC	104	305	103	306	108	203	204	208	304	308	IC302	303	302	IC301	301	IC101	IC201	105	205	106	206	Q	IC
D					301							101					201						D	
					304, 305, 306, 307, 308																			

Q		201	102	
			202	
			101	

(R101, 201
300 (U.S., CANADIAN MODEL)
100K (AEP, UK, E MODEL)



2 - 30 -

7



3

• **Use the following symbols in your answers:**

5

A

B

C

D

E

Note:


- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- (-) = slotted head
- (□□T) shows the number of coils in spring.
- Circled letters (A) to (Z) are applicable to European models only.

1

2

3

4



SECTION 6

ELECTRICAL PARTS LIST

Note: Circled letters (A) to (Z) are applicable to European models only.

Ref. No. Part No. Description

SEMICONDUCTORS

Transistors

Q101, 201)	8-729-334-58	(B) 2SC1345
Q102, 202		
⇒ Q103, 203	8-729-612-77	(B) 2SA1027R
Q104, 204	8-729-334-58	(B) 2SC1345
Q105, 205	8-729-663-47	(C) 2SC1364
Q106, 206	8-729-100-13	(B) 2SC2001
Q107, 207)	8-729-663-47	(C) 2SC1364
Q108, 208)		
Q301	8-729-141-43	(B) 2SD414
⇒ Q302	8-729-663-47	(C) 2SC1364
⇒ Q303	8-729-612-77	(B) 2SA1027R
Q304	8-729-154-83	(B) 2SB548
Q305	8-729-663-47	(C) 2SC1364
⇒ Q306	8-760-413-10	(B) 2SC1475
Q307	8-729-612-77	(B) 2SA1027R
Q308	8-729-663-47	(C) 2SC1364
Q801	8-729-141-43	(B) 2SD414
⇒ Q802	8-729-612-77	(B) 2SA1027R
⇒ Q803	8-729-663-47	(C) 2SC1364
Q804	8-729-195-23	(B) 2SA952
Q805	8-729-100-13	(B) 2SC2001
⇒ Q806	8-729-663-47	(C) 2SC1364
⇒ Q807	8-729-468-43	(C) 2SA684
Q808, 809	8-729-100-13	(B) 2SC2001
⇒ Q810	8-729-468-43	(C) 2SA684
⇒ Q811, 812	8-729-612-77	(B) 2SA1027R
⇒ Q813	8-729-663-47	(C) 2SC1364 (AEP, UK, E model)
⇒ Q814-816	8-729-663-47	(C) 2SC1364
⇒ Q817	8-729-101-03	(C) PH103-1M
⇒ Q818	8-729-468-43	(C) 2SA684
⇒ Q819	8-760-413-10	(B) 2SC1475
⇒ Q820	8-729-663-47	(C) 2SC1364
Q821	8-729-195-23	(B) 2SA952
Q822, 823	8-729-663-47	(C) 2SC1364
⇒ Q824	8-729-612-77	(B) 2SA1027R
⇒ Q1001, 1002	8-729-663-47	(C) 2SC1364
⇒ Q1003	8-760-335-10	(B) 2SC1474

⇒: Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

Ref. No. Part No. Description

⇒ Q1004	8-729-468-43	(C) 2SA684
⇒ Q1005	8-760-335-10	(C) 2SC1474
⇒ Q1006	8-729-468-43	(C) 2SA684

ICs

IC101, 201	8-759-101-74	(G) CX174
IC301	8-759-145-57	(D) μPC4557C
⇒ IC302	8-759-904-89	(D) TL489CP
IC801	8-759-147-42	(K) μPD547C-042
IC802	8-759-904-69	(C) MSM4069
IC901	8-759-133-90	(F) μPC339C
IC902	8-759-145-58	(D) μPC4558C
IC1001	8-750-690-00	(D) CX069
⇒ IC1002	8-759-145-58	(D) μPC4558C

Diodes

⇒ D101, 201	8-719-422-21	(B) 1T22AM
D301	⚠ 8-719-815-55	(B) 1S1555
D302	8-719-815-55	(B) 1S1555
⇒ D303	8-719-910-65	(B) HZ6B2L
D304-306	8-719-311-12	(B) SEL1112R
D307, 308	8-719-313-12	(B) SEL1312G
D801-804	⚠ 8-719-200-02	(B) 10E2
D805	8-719-815-55	(B) 1S1555
D806-809	⚠ 8-719-200-02	(B) 10E2
⇒ D810, 811	8-719-910-15	(B) HZ11B2L
D812	8-719-815-55	(B) 1S1555

D814	8-719-200-02	(B) 10E2
D815	⚠ 8-719-815-55	(B) 1S1555
⇒ D816	8-719-910-15	(B) HZ11B2L
D817	⚠ 8-719-815-55	(B) 1S1555
⇒ D818	8-719-910-15	(B) HZ11B2L
D819	8-719-815-55	(B) 1S1555
D820	8-719-815-55	(B) 1S1555 (AEP, UK model)
D822-824	8-719-815-55	(B) 1S1555
D825	8-719-101-11	(B) SR110

Note: The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A to Z) are applicable to European models only.

Ref. No.	Part No.	Description
D826	8-719-910-52 (B)	HZ15-2L
⇒ D827	8-719-930-12 (B)	EQB01-12Z (AEP, UK, E model)
D828	8-719-313-31 (B)	SEL1331G
D829	8-719-311-12 (B)	SEL1112R
D830	8-719-314-41 (B)	SEL1741Y

⇒ D831	8-719-815-55 (B)	1S1555
⇒ D832	8-719-910-15 (B)	HZ11B2L
⇒ D833,834 D901-903	8-719-815-55 (B)	1S1555
⇒ D1001	8-719-910-65 (B)	HZ6B2L

COILS

L101, 201	1-407-211-XX (B)	27 mH, microinductor
-----------	------------------	----------------------

TRANSFORMERS

T301	1-433-132-11 (B)	Osc
T801	1-446-351-00 (M)	Power (AEP, UK model)
	1-446-368-00	Power (US, Canadian model)
	1-446-518-00	Power (E model)

CAPACITORS

All capacitors are in μF and ceramic unless otherwise noted. 50WV or less are not indicated except for electrolytics and tantalum. p : μF , elect : electrolytic.

C101, 201	1-121-450-00 (A)	2.2	50 V	elect
C102, 202	1-161-323-00 (A)	0.001		
C103, 203	1-121-230-00 (B)	2.2	50 V	elect (nonpolarized)
C104, 204	1-123-307-00 (B)	100	10 V	elect
C105, 205	1-123-308-00 (A)	220	10 V	elect
C106, 206	1-121-392-00 (A)	3.3	25 V	elect
C107, 207	1-121-651-00 (A)	10	16 V	elect
C108, 208	1-161-314-00 (A)	180p		
C109, 209	1-161-316-00 (A)	270p		
C110, 210	1-161-271-00 (A)	100p		
C111, 211	1-121-421-00 (B)	220	16 V	elect
C112, 212	1-130-309-00 (A)	0.033	100 V	polyethylene

Ref. No.	Part No.	Description
C113, 213	1-161-316-00 (A)	270p
C114, 214	1-121-450-00 (A)	2.2 50 V elect
C115, 215	1-121-421-00 (B)	220 16 V elect
C116, 216	1-121-414-00 (A)	100 10 V elect
C117, 217	1-161-314-00 (A)	180p
C118, 218	1-108-569-00 (B)	0.0039
C119, 219	1-121-409-00 (A)	47 16 V elect
C120, 220		
C121, 221	1-123-230-00	2.2 50 V elect (nonpolarized) mylar
C122, 222	1-108-585-00 (B)	0.018
C123, 223	1-161-347-00 (A)	110p
C124, 224	1-161-268-00 (A)	56p
C125, 225	1-161-257-00 (A)	6.8p
C126, 226	1-161-268-00 (A)	56p
C127, 227	1-121-651-00 (A)	10 16 V elect
C128, 228	1-123-286-00 (A)	0.33 50 V elect
C129, 229	1-108-251-00 (B)	0.1 mylar
C130, 230	1-108-239-00 (A)	0.01 mylar
C131, 231	1-108-360-00 (A)	0.039 mylar
C132, 232	1-121-651-00 (A)	10 16 V elect
C134, 234	1-108-597-00 (A)	0.056 mylar
C135, 235	1-108-573-00 (B)	0.0056 mylar
C136, 236	1-108-589-00 (B)	0.027 mylar
C137, 237	1-108-597-00 (A)	0.056 mylar
C138, 238	1-121-395-00 (A)	4.7 25 V elect
C139, 239	1-123-230-00 (B)	2.2 50 V elect (nonpolarized)
C140, 240	1-121-392-00 (A)	3.3 25 V elect
C141, 241	1-121-651-00 (A)	10 16 V elect
C142, 242	1-121-414-00 (B)	100 10 V elect
C147, 247	1-107-168-00 (A)	91p 500 V mica
C148, 248	1-141-225-00 (C)	Trimmer
C149, 249	1-161-375-00 (A)	0.0022
C150, 250	1-107-097-00 (A)	330p mica
C151, 251	1-123-307-00 (B)	100 10 V elect
C152, 252	1-121-415-00 (A)	100 16 V elect
C154, 254	1-107-159-00 (A)	33p 500 V silvered mica
C156, 256	1-108-573-00 (B)	0.0056 mylar
C157, 257	1-108-571-00 (B)	0.0047 mylar

⇒: Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A) to (Z) are applicable to European models only.

Ref. No.	Part No.	Description
C158, 258	1-108-581-00 (B) 0.012	mylar
C159, 259	1-108-569-00 (B) 0.0039	mylar
C160, 260	1-108-585-00 (B) 0.018	mylar
C161, 261	1-108-587-00 (B) 0.022	mylar
C162, 262	1-108-569-00 (B) 0.0039	mylar
C163, 263	1-161-314-00 (A) 180p	
C301-303	1-121-421-00 (B) 220	16 V elect
C304, 305	1-121-422-00 (B) 220	25 V elect
C306	1-123-228-00 (B) 1	50 V elect (nonpolarized)
C307	1-123-330-00 (A) 22	25 V elect
C308	1-130-336-00 (B) 0.0068	630 V polyethylene
C309	1-131-237-00 (B) 1.5	25 V tantalum
C310	1-130-297-00 (A) 0.01	100 V polyethylene
C311	1-130-303-00 (A) 0.018	100 V polyethylene
C312	1-121-353-00 (A) 2.2	50 V elect
C313	1-131-196-00 (B) 2.2	20 V tantalum
C314	1-161-039-00 (A) 0.001	
C317	1-121-726-00 (A) 0.47	50 V elect
C318	1-121-391-00 (A) 1	50 V elect
C320	1-123-333-00 (A) 100	25 V elect
C801, 802	(A) 1-121-657-00 (B) 1000	25 V elect
	(A) 1-123-326-00 3300	16 V elect (US, Canadian model)
C803, 804	(A) 1-123-324-00 (B) 1000	16 V elect (AEP, UK, E model)
C805	1-121-403-00 (A) 33	16 V elect
C806	1-123-329-00 (A) 10	25 V elect
C807	1-123-316-00 (A) 10	16 V elect
C808	1-123-328-00 (A) 4.7	25 V elect
C809	1-123-320-00 (A) 100	16 V elect
C810	1-123-308-00 (A) 220	10 V elect
C811	1-123-329-00 (A) 10	25 V elect (AEP, UK, E model)
C812	1-123-316-00 (A) 10	16 V elect
C813	1-123-352-00 (A) 1	50 V elect
C814	1-108-591-00 (B) 0.033	mylar
C815, 816	1-123-351-00 (A) 0.47	50 V elect
C817	1-123-328-00 (A) 4.7	25 V elect
C818, 819	1-123-351-00 (A) 0.47	50 V elect

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description
C820	1-123-352-00 (A) 1	50 V elect
C821, 822	1-161-263-00 (A) 22p	
C824	1-121-403-00 (A) 33	16 V elect
C825	1-123-353-00 (A) 2.2	50 V elect
C826, 827	1-108-239-00 (A) 0.01	mylar
C828	1-123-352-00 (A) 1	50 V elect (US, Canadian model)
C830, 831	1-161-051-00 (A) 0.01	
C1001, 1002	1-123-306-00 (B) 47	10 V elect
C1003	1-121-409-00 (A) 47	16 V elect
C1004	1-123-354-00 (A) 3.3	50 V elect
C1005	1-130-134-00 (B) 0.082	100 V polyethylene
C1006-1008	1-161-379-00 (A) 0.01	
C1009	1-108-583-00 (A) 0.015	mylar

RESISTORS

All resistors are in ohms. Common 1/4W carbon resistors are omitted. Refer to the list on page 27 for their part numbers.

R114, 214	1-244-913-00 (A) 47 k	1/2 W carbon
R119, 219	1-244-847-00 (A) 82	1/2 W carbon
R123, 223	1-244-885-00 (A) 3.3 k	1/2 W carbon
R155, 255	1-244-881-00 (A) 2.2 k	1/2 W carbon
R156, 256		
R179, 279	1-244-929-00 (A) 220 k	1/2 W carbon
R301	(A) 1-214-733-00 (A) 1.5 k	1/4 W metal oxide
R302	(A) 1-214-723-00 (A) 560	1/4 W metal oxide
R303	(A) 1-214-729-00 (A) 1 k	1/4 W metal oxide
R304	(A) 1-214-732-00 (A) 1.3 k	1/4 W metal oxide
R312	(A) 1-213-134-00 (A) 180	1 W metal oxide (nonflammable)
R320	(A) 1-246-461-00 (A) 330	1/4 W carbon
R321	(A) 1-246-455-00 (A) 180	1/4 W carbon
R322	(A) 1-212-878-00 (A) 75	1/4 W fusible
R324	1-214-777-00 (A) 100 k	1/4 W metal oxide
R338	(A) 1-244-866-00 (A) 510	1/2 W carbon
R340, 341	(A) 1-212-958-00 (B) 10	1/2 W fusible
R342	1-244-866-00 (A) 510	1/2 W carbon

Note: Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note: Circled letters (A) to (Z) are applicable to European models only.

Ref. No.	Part No.	Description
R343, 344	1-212-958-00	10 ½ W fusible
R803	1-244-873-00	(A) 1 k ½ W carbon (AEP, UK, E model)
R814, 815	1-212-857-00	(A) 10 ¼ W fusible
R832	1-213-133-00	(A) 150 1 W metal oxide (AEP, UK, E model)
R878	1-212-859-00	12 fusible (AEP, UK, E model)
R880	1-217-395-00	(B) 47 ¼ W fusible (AEP, UK, E model)
	1-247-208-00	47 ½ W carbon (nonflammable) (US, Canadian model)
R1001	1-214-777-00	(A) 100 k ¼ W metal oxide (1%)
RV101, 201	1-226-295-00	(E) 50k/50k-A, variable; REC LEVEL
RV102, 202	1-224-646-XX	(B) 22k-B, adjustable; playback level
RV103, 203	1-224-647-XX	(B) 47k-B, adjustable; record level
RV1001	1-226-433-00	(A) 50k-B, adjustable; tape speed

SWITCHES

S1	1-552-879-00	(C) Pushbutton, INPUT SELECT
S2	1-552-880-00	(C) Slide, DOLBY NR
S3	1-552-878-00	(D) Slide, EQ
S4	1-552-877-00	(C) Slide, BIAS
S5-11	1-552-919-22	(K) Block, function
S13	1-552-940-00	(C) Slide, MEMORY
S14	1-552-520-00	(C) Slide, timer
S15, 16	1-552-268-00	(B) Slide, accidental-erasure prevention, cassette
S17	1-552-530-00	Pushbutton, POWER (US, Canadian model)
	1-552-903-00	(D) Pushbutton, POWER (AEP, UK, E model)

JACKS

CNJ101,201	1-507-525-00	(D) MIC
CNJ102,202	1-507-531-00	(C) LINE IN, LINE OUT (US, Canadian model)
CNJ103,203		

Ref. No.	Part No.	Description
CNJ102,202	1-536-501-21	(D) LINE IN, LINE OUT, REC/PB (AEP, UK, E model)
CNJ103,203		
CNJ302		
CNJ301	1-507-483-00	(C) HEADPHONES

MISCELLANEOUS

CNJ901	1-561-293-00	(D) Socket, REMOTE
CP1	1-231-057-31	(B) Encapsulated Component (E model)
	1-231-326-11	Encapsulated Component (US model)
	1-231-341-00	Encapsulated Component (Canadian model)
CP1, 2	1-130-267-00	(C) Capacitor, 0.22 250V film (AEP, UK model)
HE402	8-825-724-00	(D) Head, erase; EF201-36
HRP401	8-825-712-10	(O) Head, record/playback; PS185-3602A1
LPF101, 201	1-231-388-00	(D) Filter, low-pass
M1	X-3564-017-0	(K) Motor Ass'y, capstan
M2	X3564-015-0	(I) Motor Ass'y, reel
ME101, 201	1-520-341-51	(F) Meter Unit
PL1	1-518-299-91	(B) Lamp, cassette
PL2, 3	1-518-351-00	(B) Lamp, meter
PM1	1-454-222-11	(D) Solenoid, brake
PM2	1-454-222-21	(D) Solenoid, head
RY301	1-515-323-00	(G) Relay
RY302	1-515-297-00	(F) Relay, reed (AEP, UK, E model)
	1-526-576-21	Voltage Selector (E model)
	1-534-777-00	(D) Cord, power (UK model)
	1-534-817-XX	(D) Cord, power (AEP model)
	1-534-986-XX	Cord, power (US, Canadian model)
	1-551-473-31	Cord, power; parallel-blade plug (E model)
	1-551-530-00	Cord, power; euro-plug (E model)
	1-560-064-00	(A) Pin, connector

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

3-2. ELECTRICAL ADJUSTMENTS

Note: The adjustment should be performed in the order given in this service manual. The adjustments should be performed for both L-CH and R-CH.

- Set the BIAS and EQ switches according to the tape as follows.

Tape	BIAS switch	EQ switch
CS-10	MED	TYPE I
CS-25	HIGH	TYPE II
CS-30	MED	TYPE III
CS-40	METAL	TYPE IV

- Switches and controls should be set as follows unless otherwise specified.

DOLBY NR switch: OFF
 EQ switch: TYPE I
 BIAS switch: MED
 TIMER[⌚] switch: OFF

- Standard Record:

Deliver the standard input signal level to the input jack and set the REC LEVEL control to obtain the standard output signal level.

Standard Input Level

	MIC	LINE IN	REC/PB (AEP, UK and E model)
source impedance	300 Ω	10 k Ω	100 k Ω
input level	0.77 mV (-60 dB)	0.25 V (-10 dB)	17 mV (-33 dB)


Standard Output Level

	LINE OUT	HEAD- PHONES	REC/PB (AEP, UK and E model)
load impedance	47 k Ω	8 Ω	50 k Ω
output level	0.44 V (-5 dB)	39 mV (-26 dB)	0.44 V (-5 dB)

Tape Speed Adjustment

Procedure:

Mode: playback




Specification:

Speed checker	Digital frequency counter
-0.7 - +0.7 %	2,980 - 3,020 Hz

Frequency difference between the beginning and the end of the tape should be within 0.7 % (20 Hz).

Adjustment Location:

— servo amp board —




Record/playback Head Azimuth Adjustment


Procedure:

1. Mode: playback

test tape
P-4-A81
(6.3 kHz, -10 dB)





2. Turn the adjustment screw for the maximum output levels. If these levels do not match, turn the adjustment screw until both of output levels match together within 0.5 dB.



3. Phase Check
Mode: playback

test tape
P-4-A81
(6.3 kHz, -10 dB)



Adjustment Location:




Playback Level Adjustment

Procedure:

Mode: Playback

test tape
P-4-L81
(333 Hz, 0 dB)



Specification:


LINE OUT level: 0.52 – 0.59 V
(–3.5 to –2.5 dB)

Level difference between channels:
less than 0.5 dB

Check that the LINE OUT level does not change in playback mode while changing the mode from playback to stop several times.

Adjustment Location:

– record/playback board –




SECTION 4
DIAGRAMS

Playback Equalizer Adjustment

Procedure:

Mode: playback





Specification:

LINE OUT level: 0.12 – 0.27 V
(–16 to –9 dB)

Adjustment Location:

– record/playback board –

Bridge patterns	High frequency level
(open)	down
(A) or (B)	up
(A) and (B)	up




Record Bias Adjustment

Setting:


REC LEVEL control: standard record
(See page 13.)

Procedure:

1. Mode: record



2. Mode: playback




Confirm that the LINE OUT level of 10 kHz signal is 0 dB relative to that of 1 kHz.
If necessary, adjust C148 (L-CH) and C248 (R-CH).

Adjustment Location:

– record/playback board –

C148 (L-CH) C248 (R-CH)




Record Level Adjustment

Setting:


REC LEVEL control: standard record
(See page 13.)

Procedure:

1. Mode: record



2. Mode: playback




Specification:

LINE OUT level: 0.41 – 0.46 V
(–5.5 to –4.5 dB)

Adjustment Location:

– record/playback board –




Level Meter Calibration

Setting:

REC LEVEL control: standard record
(See page 13.)

Procedure:



1. Mode: record



Pattern connection	Pointer deflection	LEVEL meter indication
(A) and (B)	bigger	
(B)		
(A)		
(open)	smaller	

Adjustment Location:

– record/playback board –



Voltages and Waveforms at the Terminals of IC801.

Terminal No.	Waveform or Voltage	Terminal No.	Waveform or Voltage	Terminal No.	Waveform or Voltage
①	10Vp-p 4.75 μsec	⑭	Forward Mode 10V 0V	⑲	10 Vdc
②	• Forward Mode 10Vp-p 0.7 sec • Fast Forward Mode 10Vp-p 20 msec • When pause button is pushed in forward mode: 10 Vdc • Tape End: 10 Vdc	⑮	Record Mode 10V 0V	⑳	10 Vdc
③	8Vp-p 8 msec	⑯	Forward Mode 10V 0V 0.5 sec Forward button is pushed.	㉑	10 Vdc
④ to ⑥	10 Vdc	⑰	Record/Forward Mode 10V 0V	㉒	10 Vdc
⑦	2.5 sec 10Vp-p 0.5 sec S17 (POWER): ON	⑱	Pause Mode 10V 0V	㉓	10 Vdc
⑧	10V 0V Record button is pushed.	㉔	Record/Forward button is pushed. Record Muting or Pause button is pushed.	㉕	10 Vdc
⑨	10V 0V Pause button is pushed.	㉖	10 Vdc	㉗	10 Vdc
⑩	10V 0V Record button is pushed.	㉘	Forward or Record Mode 10V 3.3V 0V 0.6 sec Forward or Record button is pushed.	㉙	10 Vdc
⑪	10 Vdc	㉚	Fast Forward or Rewind Mode or Record/Forward/Pause Mode 10V 0V	㉛	10 Vdc
⑫, ⑬	Fast Forward or Rewind Mode 10V 0V	㉜	Forward Mode 10V 0V	㉝	10 Vdc
		㉞	Forward or Fast Forward or Rewind button is pushed.	㉟	10 Vdc
		㊱	10 Vdc	㊲	10 Vdc
		㊳	10 Vdc	㊴	10 Vdc
		㊵	10 Vdc	㊶	10 Vdc
		㊷	10 Vdc	㊸	10 Vdc
		㊹	10 Vdc	㊺	10 Vdc
		㊻	10 Vdc	㊼	10 Vdc
		㊽	10 Vdc	㊾	10 Vdc
		㊿	10 Vdc	㋀	10 Vdc

4-1. SCHEMATIC DIAGRAM — System Control Section —

Refer to page 17 for voltages and waveforms at the terminals of IC801.

Note:

- All capacitors are in μF unless otherwise noted. $\text{pF} = \mu\text{F} \times 10^{-6}$
- All resistors are in ohms, $\frac{1}{4}\text{W}$ unless otherwise noted. $\text{k}\Omega : 1000\Omega$, $\text{M}\Omega = 1000\text{k}\Omega$
- : fusible resistor.
- : nonflammable resistor.
- 1% indicates component tolerance.
- : B+ bus.
- : B- bus.
- : panel designation.
- : adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a VOM (20 $\text{k}\Omega/\text{V}$).
- no mark: STOP
- : FORWARD
- : FAST FORWARD
- : REWIND
- : RECORD
- : REC MUTE
- : PAUSE
- : STOP





- Voltage variations may be noted due to normal production tolerances.

Switch

Ref. No.	Switch	Position
S5	REWIND	OFF
S6	STOP	OFF
S7	FORWARD	OFF
S8	FAST FORWARD	OFF
S9	RECORD	OFF
S10	PAUSE	OFF
S11	REC MUTE	OFF
S12	COUNTER	OFF
S13	MEMORY	OFF
S14-1, 2	TIMER	OFF
S15	ACCIDENTAL-ERASURE PREVENTION	ON
S16	CASSETTE	OFF
S17	POWER	OFF

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par une trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



Note: Circled letters (**A**) to (**Z**) are applicable to European models only.

ACCESSORIES AND PACKING MATERIALS

<u>Part No.</u>	<u>Description</u>
X-3701-105-0	(A) Tip Ass'y, head cleaning
1-551-734-11	(D) Cord, connection RK-74A
3-429-126-00	Bag, plastic (Canadian model)
3-561-142-00	Cushion, upper-front (Canadian model)
3-561-143-00	Cushion, upper-rear (Canadian model)
3-561-144-00	Cushion, bottom-right (Canadian model)
3-561-145-00	Cushion, bottom-left (Canadian model)
3-566-148-00	(B) Cushion, upper-front (US, AEP, UK, E model)
3-566-149-00	(B) Cushion, upper-rear (US, AEP, UK, E model)
3-566-150-00	(B) Cushion, bottom-right (US, AEP, UK E model)
3-566-151-00	(B) Cushion, bottom-left (US, AEP, UK E model)
3-566-165-00	(D) Carton (US, AEP UK, E model)
3-566-166-00	Carton (Canadian model)
3-701-630-00	(A) Bag, plastic
3-701-684-00	(A) Card, voltage indication (AEP model)
3-770-991-11	(E) Manual, instruction (AEP, UK, E model)
3-770-991-21	Manual, instruction (US model)
3-770-991-21)	Manual, instruction (Canadian model)
3-794-575-31	
3-793-828-11	(A) Caution Card, cassette
3-794-233-21	(A) Separate Sheet, consumer products (US model)
4-818-924-00	(B) Bag, plastic


1/4 WATT CARBON RESISTORS Ⓐ

Note: Circled letter Ⓐ is applicable to European models only.

Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.
1.0	1-246-401-00	10	1-246-425-00	100	1-246-449-00	1.0k	1-246-473-00	10k	1-246-497-00	100k	1-246-521-00	1.0M	1-246-545-00
1.1	1-246-402-00	11	1-246-426-00	110	1-246-450-00	1.1k	1-246-474-00	11k	1-246-498-00	110k	1-246-522-00	1.1M	1-210-814-00
1.2	1-246-403-00	12	1-246-427-00	120	1-246-451-00	1.2k	1-246-475-00	12k	1-246-499-00	120k	1-246-523-00	1.2M	1-210-815-00
1.3	1-246-404-00	13	1-246-428-00	130	1-246-452-00	1.3k	1-246-576-00	13k	1-246-500-00	130k	1-246-524-00	1.3M	1-210-816-00
1.5	1-246-405-00	15	1-246-429-00	150	1-246-453-00	1.5k	1-246-577-00	15k	1-246-501-00	150k	1-246-525-00	1.5M	1-210-817-00
1.6	1-246-406-00	16	1-246-430-00	160	1-246-454-00	1.6k	1-246-578-00	16k	1-246-502-00	160k	1-246-526-00	1.6M	1-210-818-00
1.8	1-246-407-00	18	1-246-431-00	180	1-246-455-00	1.8k	1-246-579-00	18k	1-246-503-00	180k	1-246-527-00	1.8M	1-210-819-00
2.0	1-246-408-00	20	1-246-432-00	200	1-246-456-00	2.0k	1-246-580-00	20k	1-246-504-00	200k	1-246-528-00	2.0M	1-210-820-00
2.2	1-246-409-00	22	1-246-433-00	220	1-246-457-00	2.2k	1-246-581-00	22k	1-246-505-00	220k	1-246-529-00	2.2M	1-210-821-00
2.4	1-246-410-00	24	1-246-434-00	240	1-246-458-00	2.4k	1-246-582-00	24k	1-246-506-00	240k	1-246-530-00	2.4M	1-244-754-00
2.7	1-246-411-00	27	1-246-435-00	270	1-246-459-00	2.7k	1-246-583-00	27k	1-246-507-00	270k	1-246-531-00	2.7M	1-244-755-00
3.0	1-246-412-00	30	1-246-436-00	300	1-246-460-00	3.0k	1-246-584-00	30k	1-246-508-00	300k	1-246-532-00	3.0M	1-244-756-00
3.3	1-246-413-00	33	1-246-437-00	330	1-246-461-00	3.3k	1-246-585-00	33k	1-246-509-00	330k	1-246-533-00	3.3M	1-244-757-00
3.6	1-246-414-00	36	1-246-438-00	360	1-246-462-00	3.6k	1-246-586-00	36k	1-246-510-00	360k	1-246-534-00	3.6M	1-244-758-00
3.9	1-246-415-00	39	1-246-439-00	390	1-246-463-00	3.9k	1-246-587-00	39k	1-246-511-00	390k	1-246-535-00	3.9M	1-244-759-00
4.3	1-246-416-00	43	1-246-440-00	430	1-246-464-00	4.3k	1-246-488-00	43k	1-246-512-00	430k	1-246-536-00	4.3M	1-244-760-00
4.7	1-246-417-00	47	1-246-441-00	470	1-246-465-00	4.7k	1-246-489-00	47k	1-246-513-00	470k	1-246-537-00	4.7M	1-244-761-00
5.1	1-246-418-00	51	1-246-442-00	510	1-246-466-00	5.1k	1-246-490-00	51k	1-246-514-00	510k	1-246-538-00	5.1M	1-244-762-00
5.6	1-246-419-00	56	1-246-443-00	560	1-246-467-00	5.6k	1-246-491-00	56k	1-246-515-00	560k	1-246-539-00		
6.2	1-246-420-00	62	1-246-444-00	620	1-246-468-00	6.2k	1-246-492-00	62k	1-246-516-00	620k	1-246-540-00		
6.8	1-246-421-00	68	1-246-445-00	680	1-246-469-00	6.8k	1-246-493-00	68k	1-246-517-00	680k	1-246-541-00		
7.5	1-246-422-00	75	1-246-446-00	750	1-246-470-00	7.5k	1-246-494-00	75k	1-246-518-00	750k	1-246-542-00		
8.2	1-246-423-00	82	1-246-447-00	820	1-246-471-00	8.2k	1-246-495-00	82k	1-246-519-00	820k	1-246-543-00		
9.1	1-246-424-00	91	1-246-448-00	910	1-246-472-00	9.1k	1-246-496-00	91k	1-246-520-00	910k	1-246-544-00		

HARDWARE NOMENCLATURE


Screw:



Indicated slotted-head only.

Unless otherwise indicated, it means cross-recessed head (Phillips type).

Nut, Washer, Retaining ring:



Reference Designation	Shape	Description	Remarks
SCREWS			
P		pan-head screw	binding-head (B) screw for replacement
PWH		pan-head screw with washer face	binding-head (B) screw and flat washer for replacement
PS PSP		pan-head screw with spring washer	binding-head (B) screw and spring washer for replacement
PSW PSPW		pan-head screw with spring and flat washers	binding-head (B) screw and spring and flat washers for replacement
R		round-head screw	binding-head (B) screw for replacement
K		flat-countersunk-head screw	
RK		oval-countersunk-head screw	
B		binding-head screw	
T		truss-head screw	binding-head (B) screw for replacement
F		flat-fillister-head screw	
RF		fillister-head screw	
BV		brazer-head screw	

Reference Designation	Shape	Description	Remarks
SELF-TAPPING SCREWS			
TA		self-tapping screw	ex: TA, P 3 x 10
PTP		pan-head self-tapping screw	binding-head self-tapping (TA, B) screw for replacement
PTPWH		pan-head self-tapping screw with washer face	binding-head self-tapping (TA, B) screw and flat washer for replacement
PTTWH		pan-head thread-rolling screw with washer face	binding-head (B) screw and flat washer for replacement
SET SCREWS			
SC		set screw	
SC		hexagon-socket set screw	ex: SC 2.6 x 4, hexagon-socket
NUT			
N		nut	
WASHERS			
W		flat washer	
SW		spring washer	
LW		internal-tooth lock washer	ex: LW3, internal
LW		external-tooth lock washer	ex: LW3, external
RETAINING RINGS			
E		retaining ring	
G		grip-type retaining ring	

Sony Corporation

© 1979

9-954-822-01

79H05102-1

Printed in Japan