## TC-RX606ES/RX611S

## SONY. SERVICE MANUAL

US Model Canadian Model TC-RX606ES AEP Model

RX611S

## **CORRECTION-1**

Correct your service manual as shown below.

## : indicates corrected portion.

Page	INCORRECT	CORRECT
	Playback Level Adjustment	Playback Level Adjustment
	:	:
9	<b>:</b>	:
	:	:
	:	:
	Adjustment limits :	Adjustment limits:  LINE OUT level: 0.302 ~ 0.338V(-7.2 ~ - 8.2dB)
	LINE OUT level: 0.301~0.338V(-10.5dB~-9.5dB)	