

TC-WE835S

SERVICE MANUAL

US Model
AEP Model
UK Model

- TC-WE835S is similar to the earlier TC-WE825S.
- Refer to TC-WE625/WE725/WE825S service manual (9-922-795-xx) for information not contained in this service manual.

• DIFFERENCE TABLE

Page	Ref.No.	TC-WE825S			TC-WE835S		
		Part No.	Description	Remark	Part No.	Description	Remark
		EXPLODED VIEWS			***EXPLODED VIEWS***		
38	1	* 3-021-243-01	PANEL, BACK (AEP)		* 3-032-411-01	PANEL, BACK (AEP)	
	1	* 3-021-243-11	PANEL, BACK (UK)		* 3-032-411-11	PANEL, BACK (UK)	
	1	* 3-021-243-31	PANEL, BACK (US)		* 3-032-411-21	PANEL, BACK (US)	
40	101	X-3374-864-1	LID (A) ASSY, CASSETTE		X-3376-715-1	LID (A) ASSY, CASSETTE	
	102	X-3374-865-1	LID (B) ASSY, CASSETTE		X-3376-717-1	LID (B) ASSY, CASSETTE	
41	151	X-3374-858-1	PANEL ASSY, FRONT (AEP, UK)		X-3376-712-1	PANEL ASSY, FRONT (AEP, UK)	
	151	X-3375-510-1	PANEL ASSY, FRONT (US)		X-3376-713-1	PANEL ASSY, FRONT (US)	
54		***ACCESSORIES & PACKING MATERIALS***			***ACCESSORIES & PACKING MATERIALS***		
		NOT USED			1-473-598-11	REMOTE COMMANDER (RM-J910)(US)	
		3-862-713-11	MANUAL, INSTRUCTION (ENGLISH) (US, UK)		3-866-256-11	MANUAL, INSTRUCTION (ENGLISH)	
		3-862-713-31	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, PORTUGUESE) (AEP)		3-866-256-21	MANUAL, INSTRUCTION (FRENCH, SPANISH) (AEP)	
		3-862-713-41	MANUAL, INSTRUCTION (GERMAN, DUTCH, SWEDISH, ITALIAN) (AEP)		3-866-256-31	MANUAL, INSTRUCTION (GERMAN, DUTCH, SWEDISH, ITALIAN, PORTUGUESE) (AEP)	
		NOT USED			3-866-671-11	MANUAL, INSTRUCTION (FOR CONTROL A1 II) (ENGLISH) (US,UK)	
		NOT USED			3-866-671-21	MANUAL, INSTRUCTION (FOR CONTROL A1 II) (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, PORTUGUESE, SWEDISH, ITALIAN, CHINESE)(AEP)	
		NOT USED			4-981-643-01	COVER, BATTERY (FOR RM-J910) (US)	

Items marked "*" are not stocked since they are seldom required for routine service.
Some delay should be anticipated when ordering these items.

STEREO CASSETTE DECK

SONY®

