



(system control section)






16


17

18


[MD-A BOARD(1/2)]






[MD-A LEAF SWITCH BOARD]



[MD-B BOARD(1/2)]



[MD-B LEAF SWITCH BOARD]



R545 10

A

B

C

D

E

F


G


H

I

J


4-4. SCHEMATIC DIAGRAM (audio section)





A

PHONE BOARD]



B


LINE OUT
J302(1/2)

C

TO FL BOARD NOB17

PE SWITCH BOARD(1/2)]


[VOLUME BOARD]




D

E

LINE IN J302(1/2) [TAPE SWITCH BOARD(1/2)]




G



H

I



J

TO FL BOARD NOB12