

TC-WR99ES/WR990

SERVICE MANUAL

US Model
Canadian Model
E Model
TC-WR99ES
AEP Model
TC-WR990



PHOTO:TC-WR990

Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen. "DOLBY", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

Model Name Using Similar Mechanism	TC-WR97ES/WR970
Tape Transport Mechanism Type	TCM-200R4

SPECIFICATIONS

Recording system 4-track 2-channel stereo
Fast winding time Approx. 90 sec. (with Sony C-60 cassette)
Bias AC bias
Signal-to-noise ratio (at peak level)

Cassette (Dolby NR OFF)	Type IV (Sony Metal-S/Select)	Type II (Sony UX-S)	Type I (Sony HF-S)
	59 dB	58 dB	56dB

Measured at peak level weighted without NR.
The S/N is improved by about 15 dB at 500 Hz and by about 20 dB about 1 kHz with Dolby-C NR on, and by 5 dB at 1 kHz and by 10 dB about 5 kHz with Dolby-B NR on.

Harmonic distortion 0.4% (with Sony Type I, 160 nWb/m, 315 Hz, 3rd H.D.)
1.8% (with Sony Type IV, 250 nWb/m, 315 Hz, 3rd H.D.)

Frequency response (DOLBY NR OFF)

Type IV cassette (Sony Metal-S/Select)	25 - 19,000 Hz (± 3 dB, IEC) 30 - 15,000 Hz (± 3 dB (-4 dB) recording]
Type II cassette (Sony UX-S)	25 - 18,000 Hz (± 3 dB, IEC)
Type I cassette (Sony HF-S)	25 - 16,000 Hz (± 3 dB, IEC)

Wow and flutter $\pm 0.09\%$ W.Peak (IEC)
0.06% W.RMS (NAB)
 $\pm 0.16\%$ W.Peak (DIN)

Inputs

Line inputs (phono jacks)	Sensitivity	0.16 V
	Input impedance	47 kilohms

Outputs

Line outputs (phono jacks)	Rated output level	0.5 V at a load impedance of 47 kilohms
	Load impedance	Over 10 kilohms
Headphones (stereo phone jack)	Output level	0 — 3 mW at a load impedance of 32 ohms

General

Power requirements

AEP model :
220 - 230 V AC, 50/60 Hz
US, Canadian model : 120V AC, 60Hz
E model :
120, 220, or 240 V AC adjustable,
50/60 Hz

Power consumption 30 W
Dimensions

TC - WR990 :
430 x 135 x 350 mm (w/h/d)
(17 x 5³/₈ x 13⁷/₈ inches) including projecting parts and controls
TC-WR99ES:
470 x 135 x 350 mm (w/h/d)
(18⁵/₈ x 5³/₈ x 13⁷/₈ inches) including projecting parts and controls
TC - WR990 :
6.5 kg (14 lbs 6 oz)
TC-WR99ES:
7.5 kg (16 lbs 9 oz)

Weight

Supplied accessories

Audio connecting cords (2)
Wireless remote commander RM-J902 (1) (Except for US/Canadian)
Sony size SUM-3(NS) (2) (Except for US/Canadian)
Screws (M3) (4) (TC-WR99ES only)

Design and specifications subject to change without notice.

Note

This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.


STEREO CASSETTE DECK
SONY®

TABLE OF CONTENTS

Section	Title	Page
Specification		1
Model Identification		2
Safety Check-out		2
1. GENERAL		
Identifying the Parts		3
Hook-up Example		4
2. DISASSEMBLY		5
3. ADJUSTMENTS		
3-1. Mechanical Adjustment		8
3-2. Electrical Adjustment		8
4. DIAGRAMS		
4-1. Block Diagram		12
4-1-1. Circuit Boards Location		15
4-2. Printed Wiring Boards		16
4-3. Schematic Diagram		21
4-4. Semiconductor Lead Layouts		24
5. EXPLODED VIEWS		29
6. ELECTRICAL PARTS LIST		33

MODEL IDENTIFICATION

— Specification Label —

TC-WR99ES
TC-WR990

US, Canadian Model: AC: 120V 60Hz 30W
 AEP Model: AC: 220 - 230~50/60Hz
 E Model: AC: 120, 220, 240V~50/60Hz30W

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK OR DOTTED LINE WITH MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

Identifying the Parts

Front Panel

For details, refer to the page number indicated in parenthesis.

(The illustration shows the TC-WR990.)

(Continued from previous page.)

- 9 OPEN/CLOSE button (deck B)
- 10 Front cover
- 11 OPEN/CLOSE button (deck A)
- 12 TAPE SPEED control and button (26)
- 13 BLANK SKIP button (30)
- 14 DUBBING LEVEL control (66)
- 15 AUTO PAUSE button (70)
- 16 BIAS controls (46)
- 17 A+B REC (simultaneous recording) button (52)
- 18 REC (recording) LEVEL control (38,44)
- 19 AUTO REC (automatic recording) LEVEL button and indicator (TC-WR990/WR99ES only) (38)
- 20 BALANCE control (38)
- 21 FADER button (TC-WR990/WR99ES only) (60,62)
- 22 MPX FILTER switch (46)
- 23 DOLBY NR (Dolby noise reduction) switches (22,28,38,52,56,66)
- 24 DIR (direction) MODE switch (22,28,38,52,56,66)
- 25 SYNCHRO DUBBING buttons (66)
- 26 HIGH SPEED button
- 27 NORM (normal) SPEED button
- 28 TIMER switch (72)
- 29 Headphone LEVEL control (24)
- 30 PHONES (headphones) jack (stereo phone jack)

Identifying the Parts

Front Panel

For details, refer to the page number indicated in parenthesis.


(The illustration shows the TC-WR990.)

(Continued from previous page.)

- 1 POWER switch
- 2 Deck A
- 3 COUNTER buttons (deck A) (36)
- 4 RESET button
- 5 MEMORY button
- 6 Remote control sensor
- 7 You can remotely control this cassette deck with:
 - The supplied remote commander
 - (Except for Canada).
 - A remote commander that came with a Sony amplifier or receiver if it has the  mark and cassette deck control capability.
 - Any optional Sony remote commander with the  mark and cassette deck control capability.
- 8 Display panel
- 9 COUNTER buttons (deck B) (36)
- 10 RESET button
- 11 MEMORY button
- 12 Deck B
- 13 Tape operation buttons
 - (stop) button
 - ▶ (reverse play) button
 - ▶ (forward play) button
 - ▶ (leftward fast winding) (Multi-AMS*) button
 - ▶ (rightward fast winding) (Multi-AMS*) button
- 14 AMS*) button
- 15 PAUSE button
- 16 REC MUTE (record muting) button (68)
- 17 REC (recording) button

* AMS is an abbreviation for Automatic Music Sensor.

(Continued on next page.)




SECTION 1
GENERAL


This section is extracted from instruction manual.

Hook-up Example

A



B



Hooking Up the System

Before You Begin

- Turn off the power to all equipment to be connected before making any connection.
- Note that the red plug of the supplied connecting cord is for right-channel (R) connection and the white plug for left-channel (L) connection.

See Fig. **A**.

a) White

b) Red

- The connecting cords should be fully inserted into the jacks. A loose connection may cause hum pickup.

Hook-up Example

Fig. **B** shows how to connect the unit to an amplifier.

- a) CONTROL-S input (Canada only)
- b) to an AC outlet
- c) for recording
- d) for playback
- e) Amplifier
- f) To a wall outlet

The arrow  shows the direction of the signal flow.

Note

Parts on the back panel will differ depending on the model.

Note on the CONTROL-S input


To remote control this unit through a receiver or amplifier, connect the input on this unit to the CONTROL-S output on a Sony receiver or amplifier, with a CONTROL-S cable. When this connection is used, only remote commands sent through the receiver or amplifier will be executed. The remote sensor on this unit will not function.

SECTION 2
DISASSEMBLY


Note: Follow the disassembly procedure in the numerical order given.

Unscrew four screws (M3 × 8)
and remove the upper case.


DOLBY BOARD, MAIN BOARD




MECANISM




CASSETTE HOLDER




ORNAMENTAL PLATE




CAPSTAN PLATE, FLYWHEEL



PINCH LEVER, HEAD



REEL AND ASSIST MOTORS



SECTION 3

ADJUSTMENTS

3-1. MECHANICAL ADJUSTMENTS

PRECAUTION

- Clean the following parts with a denatured-alcohol-moistened swab :

record/playback head	pinch roller
erase head	rubber belts
capstan	idler
- Demagnetize the record/playback head with a head demagnetizer.
- Do not use a magnetized screwdriver for the adjustments.
- After the adjustments, apply suitable locking compound to the parts adjusted.
- The adjustments should be performed in the rated power supply voltage unless otherwise noted.

Torque Measurement

Torque	Torque meter	Meter reading
FWD	CQ-102C	30-60g·cm (0.42-0.83oz·inch)
FWD Back tention	CQ-102C	1-5g·cm (0.014-0.063oz·inch)
REV	CQ-102RC	30-60g·cm (0.42-0.83oz·inch)
REV Back tention	CQ-102RC	1-5g·cm (0.014-0.063oz·inch)
FF, REW	CQ-201B	65-90 g·cm (0.90-1.25 oz·inch)

3-2. ELECTRICAL ADJUSTMENT

Note: The adjustment should be performed in the order given in the service manual. As a rule, adjustments about playback should be performed before those about recording. The adjustments should be performed for both L-CH and R-CH.


- Switches and controls should be set as follows unless otherwise specified.

DOLBY NR switch	: OFF
DIRECTION switch	: $\Rightarrow$
TIMER switch	: OFF
MPX FILTER switch	: OFF

- Standard Record :

Deliver the standard input signal level to the input jack and set the REC LEVEL control to obtain the standard output signal level.

-Record Mode-



0 dB = 775mV

Standard Input Level

input terminal	LINE IN
source impedance	10k Ω
input level	0.5V (-3.8dB)

Standard Output Level

output terminal	LINE OUT
load impedance	47k Ω
output level	0.5V (-3.8dB)

Test tape

Type	Signal	Used for
P-4-A100	10kHz, -10dB	Azimuth Adjustment
P-4-L300	315Hz, 0dB	PB Level Adjustment
WS-48B	3kHz, 0dB	Tape Speed Adjustment

The set will get into TEST MODE by shorting the pins of TP801 (TEST) on Main board before turning the power on, and TEST MODE functions as follows :

- High speed playback
Pressing HIGH SPEED (DUBBING) button while playback changes to high speed playback and another press of the button returns the set to normal speed playback.
- Record memory stop
When starting recording, tape counter is reset to zero and counter memory turned on.


Record/Playback Head Azimuth Adjustment

DECK A DECK B


Procedure :

- Mode : FWD playback


Test tape
P-4-A100
(10kHz, -10dB)



- Turn the adjustment screw for the maximum output levels. If these levels do not match, turn the adjustment screw until both of output levels match together within 1dB.




- Phase Check
Mode : playback



- Set in the REV mode and repeat the step 1-3.
- After the adjustment, lock the screws with locking compound.

Adjustment Location : Record/Playback head




Tape Speed Adjustment DECK A DECK B

Procedure :

Mode : playback

Perform high speed adjustment before normal speed adjustment



(high speed adjustment)

- Short test pin TP801 (TEST) on Main board.
- Set to FWD playback mode.
- Press the HIGH SPEED DUBBING switch.
- Adjust RV871 (DECK A) and RV881 (DECK B) on Main board so that the frequency counter reading becomes $6,000 \pm 30\text{Hz}$.
- After adjustment, disconnect TP801 shorted in step 1.

(normal speed adjustment)

- Set to FWD playback mode.
- Adjust RV872 (DECK A) and RV882 (DECK B) on Main board so that the frequency counter reading becomes $3,000 \pm 15\text{Hz}$.

Frequency difference between the beginning and the end of the tape should be within 5%.

Frequency difference between deck A and deck B should be within 20 Hz (high speed) or 10 Hz (normal speed).

Adjustment Location: Main board

Pitch Control Speed Adjustment DECK A

- Set TAPE SPEED (RV901) to the center and turn on S902.
- Play back DECK A FWD and adjust rv891.
Adjustment value : $3000\text{Hz} \pm 1\text{SHz}$
A, B deviation within 10Hz
Speed difference : VOL MAX $3250\text{Hz} \pm 70\text{Hz}$
: VOL MIN $2710\text{Hz} \pm 70\text{Hz}$


Adjustment Location : Main board

Playback Level Adjustment DECK A DECK B

Procedure :

Mode : playback

test tape
P • 4 • L300
(315Hz, 0dB)



Adjust RV131 (L-ch) and RV231 (R-ch) for DECK A and RV151 (L-ch) and RV251 (R-ch) for DECK B so that the reading on VTVM meter the adjustment limits below.

Adjustment Limits :

LINE OUT level : -8.2dB to -7.2dB (0.301 to 0.338V)

Level difference between channels : less than 0.5dB

Check that the LINE OUT level does not change even if Playback and Stop operation is repeated several times.

Adjustment Location : MAIN board

Bias Current Adjustment

Procedure :

1. Set RV121 and RV221 (DECK A), RV141 and RV241 (DECK B) to mechanical center and turn the set recording mode.
2. Connect digital voltmeter as shown by the following table.
3. Adjust the following transformers for the minimum readings on the digital voltmeter.

DECK	Mesurement Point	Adjustment	Value
A	L ① and ②, TP521	T121	less than 80 mV
	R ② and ③, TP521	T221	
B	L ① and ②, TP541	T141	
	R ② and ③, TP541	T241	

Adjustment Location : MAIN board

Record Bias Adjustment DECK A DECK B


Setting :

REC LEVEL control : standard Record (See page 8.)


test pin TP801 : short

Procedure :

1. Mode : record



2. Mode : playback



Playback the signal recorded in step 1.

Confirm that the 10kHz playback output is $0 \pm 0.5\text{dB}$ relative to the 315Hz output. If necessary, adjust RV121 (L-ch) and RV221 (R-ch) for DECK A and RV141 (L-ch) and RV241 (R-ch) for DECK B, and repeat the steps given above.

Adjustment Location : MAIN board

Record Level Adjustment DECK A DECK B


Setting :

REC LEVEL control : Standard Record (See page 8.)


test pin TP801 : short

Procedure :

1. Mode : record



2. Mode : playback



3. Playback the signal recorded in step1.

Confirm that the signal level is within the adjustment limits below.

If necessary, adjust RV301 (L-ch) and RV401 (R-ch) for DECK A and RV351 (L-ch) and RV451 (R-ch) for DECK B, and repeat the step1-2.

Adjustment Limits : $-23.8\text{dB} \pm 0.5\text{dB}$ (29 to 33.4mV)

Adjustment Location : Main board

Quick Reverse Sensitivity Adjustment DECK A DECK B


Conditions :

DIRECTION MODE switch : $\rightleftarrows$

Adjustment procedure :

C-120

not recorded portion



1. Connect the digital voltmeter to test point TP802 (DECK A) / TP803 (DECK B).
2. Load C-120 tape cassette and playback the leading portion in FWD mode.
3. Adjust the RV841 (DECK A), RV831 (DECK B) for $4.5 \pm 0.5V$ reading on the digital voltmeter.


4. Playback C-120 tape cassette in FWD mode again.

5. Confirm that the reading on the digital voltmeter is "L" level at the magnetic portion of the tape.


6. Confirm that the tape stop around the tape end (border of the leading and the magnetic portions).


Adjustment Location : MAIN board

Adjustment Parts Location Diagram(Component side)




4-1. BLOCK DIAGRAM



4-1-1. Circuit Boards Location


4-2. PRINTED WIRING BOARDS (See Page 15 for Circuit Boards location, Page 24 for Semiconductor Lead Layouts.)



● Semiconductor Location

Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
D71	F-2	IC802	H-8	Q546	F-14
D72	F-2	IC803	F-8	Q547	F-13
D73	A-2	IC801	G-17	Q548	H-13
D74	N-2	IC802	H-16	Q549	H-13
D75	H-2	IC803	F-18	Q550	G-14
D76	H-2	IC804	J-14	Q551	G-14
D191	D-8	IC805	H-18	Q553	H-9
D291	E-8	IC806	H-18	Q561	E-7
D521	C-12	IC807	I-12	Q562	E-7
D522	B-15	IC808	J-10	Q581	F-15
D541	D-12	IC809	C-16	Q582	E-9
D542	H-13	IC901	E-24	Q601	B-8
D561	E-7	IC902	F-21	Q602	C-7
D601	D-8	IC1001-A	J-22	Q603	D-7
D602	D-8	IC1001-B	J-30	Q604	C-8
D701	B-17	IC1002-A	J-23	Q605	C-7
D702	B-16	IC1002-B	J-31	Q651	I-7
D703	E-14			Q652	G-8
D704	E-13	Q71	F-2	Q653	G-9
D705	B-17	Q72	A-2	Q654	G-9
D706	E-14	Q73	B-2	Q707	E-14
D707	O-17	Q74	B-2	Q702	D-14
D708	O-17	Q75	B-2	Q703	I-14
D751	B-16	Q76	H-2	Q704	E-14
D752	B-16	Q77	H-2	Q705	E-15
D753	B-17	Q78	F-3	Q706	D-17
D754	B-17	Q79	F-3	Q707	D-17
D755	E-13	Q80	E-4	Q751	D-12
D756	E-13	Q81	D-4	Q752	D-12
D757	D-12	Q82	D-4	Q753	D-12
D758	E-13	Q83	D-4	Q754	E-12
D801	I-18	Q131	B-10	Q755	E-12
D802	F-19	Q151	G-10	Q756	E-13
D804	H-17	Q161	D-7	Q757	E-12
D805	H-17	Q231	C-10	Q801	G-16
D831	F-16	Q251	H-10	Q802	G-17
D841	F-18	Q261	E-7	Q803	F-19
D890	B-16	Q301	B-8	Q831	F-17
D891	B-17	Q351	G-8	Q832	I-7
D892	J-16	Q371	E-2	Q841	F-17
D893	J-15	Q401	C-8	Q842	G-19
D894	J-17	Q451	H-8	Q871	J-16
D895	J-18	Q471	E-2	Q872	H-17
D901	B-27	Q521	C-15	Q873	I-17
		Q522	C-15	Q874	I-18
IC71	E-3	Q523	C-12	Q875	J-18
IC72	B-3	Q524	B-15	Q876	J-16
IC73	O-3	Q525	C-15	Q877	J-16
IC74	A-1	Q526	B-14	Q878	J-15
IC75	D-2	Q527	B-14	Q879	J-17
IC76	C-4	Q528	B-15	Q881	J-14
IC501	C-14	Q529	B-15	Q882	J-14
IC502	G-16	Q531	C-16	Q883	J-12
IC503	B-11	Q532	C-16	Q884	J-12
IC504	G-10	Q533	B-9	Q885	J-11
IC506	E-10	Q541	G-14	Q901	F-25
IC507	I-3	Q542	G-14	Q902	F-26
IC508	E-9	Q543	F-11	Q903	F-25
IC509	E-8	Q544	G-11	Q1091-A	G-23
IC601	B-8	Q545	G-14	Q1091-B	G-31

Note:
● : parts extracted from the component side.




Note:
 • All capacitors are in μF unless otherwise noted. pF: μF
 50WV or less are not indicated except for electrolytics and tantalums.
 • All resistors are in Ω and $\frac{1}{2}$ W or less unless otherwise specified.
 • Δ : internal component.
 • $\text{---}\text{---}\text{---}$: fusible resistor.

Note:
 The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

4-4. Semiconductor Lead Layouts



SECTION 5

EXPLODED VIEWS

NOTE:

- XX, - X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE)...(RED)

↑
Parts color

↑
Cabinet's color


- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark **A** or dotted line with mark **A** are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(1) CASE, FRONT PANEL SECTION


- ▲A : SW (A) BOARD
- ▲B : POWER SW BOARD
- ▲C : FL BOARD
- ▲D : HP BOARD
- ▲E : SW (B) BOARD
- ▲F : REC VOL BOARD



<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
1	X-3364-899-1	LID (B) ASSY, CASSETTE		14	3-365-420-01	HOLDER, FL TUBE	
2	X-3364-888-1	LID (M) ASSY (WR99ES)		15	3-378-303-01	BUTTON (CONTROL)	
2	X-3364-901-1	LID (M) ASSY (WR990)		16	3-354-932-01	BUTTON (POWER)	
3	3-354-931-11	KNOB (DIA. 10)		17	3-704-366-01	SCREW (CASE) (M3 x 8)	
4	3-354-981-01	SPRING (SUS), RING		17	4-933-446-01	SCREW (SIDE PANEL) (WR99ES)	
5	3-322-044-01	SPACER, RUBBER		18	4-925-039-61	CASE	
6	3-329-983-01	KNOB (REC)		19	* 3-362-478-11	HOLDER (T), LED	
7	4-922-979-01	INDICATOR		20	* A-2006-726-A	PANEL BOARD, COMPLETE	
8	X-3364-898-1	LID (A) ASSY, CASSETTE		21	3-378-285-01	BUTTON (CORNER 4)	
9	4-908-848-01	EMBLEM, SONY		22	4-924-444-01	KNOB (TIMER)	
10	X-3364-919-1	PANEL ASSY, FRONT (WR99ES:US, Canadian)		23	3-354-931-01	KNOB (DIA. 10)	
10	X-3364-920-1	PANEL ASSY, FRONT (WR99ES:E, WR990)		24	3-378-303-11	BUTTON (CONTROL)	
11	3-378-283-01	SPRING (M)		25	X-3364-889-1	PANEL (L) ASSY, SIDE (WR99ES)	
12	4-928-635-01	SCREW, +BV (2. 6X8) TAPPING		26	X-3364-890-1	PANEL (R) ASSY, SIDE (WR99ES)	
13	9-911-844-XX	CUSHION		VFD901	1-519-594-11	INDICATOR TUBE, FLUORESCENT	

(2) CHASSIS SECTION

- ▲ G : COVER BOARD
 ▲ H : POWER TRANSFORMER BOARD
 ▲ I : DOLBY BOARD
 ▲ J : PJ BOARD




Ref. No.	Part No.	Description	Remarks
51	* 4-924-098-11	HOLDER, PC BOARD	
52	* 3-346-265-11	HOLDER, PC BOARD	
53	* 3-356-925-01	HEAT SINK	
54	* A-2006-725-A	MAIN BOARD, COMPLETE	(WR99ES:E, WR990)
54	* A-2006-727-A	MAIN BOARD, COMPLETE	(WR99ES:US, Canadian)
55	* 3-309-144-21	HEAT SINK	
56	* 4-880-403-11	HEAT SINK	
57	▲ 1-551-188-XX	CORD, POWER	(WR99ES:E)
57	▲ 1-555-795-00	CORD, POWER EULO PLUG	(WR990)
57	▲ 1-590-836-31	CORD, POWER	(WR99ES US, Canadian)
58	* 3-703-244-00	BUSHING (2104), CORD	(WR99ES US, Canadian, WR990)

Ref. No.	Part No.	Description	Remarks
58	* 3-703-571-11	BUSHING (S) (4516), CORD	(WR99ES:E)
59	* 3-375-668-11	PANEL, BACK	(WR99ES:US, Canadian)
59	* 3-375-668-41	PANEL, BACK	(WR99ES:E)
59	* 3-375-668-21	PANEL, BACK	(WR990)
60	▲ 1-569-007-11	ADAPTER, CONVERSION 2P	(WR99ES:E)
61	4-943-148-42	FOOT	
T1	▲ 1-450-446-11	TRANSFORMER, POWER	(WR990)
T1	▲ 1-450-444-11	TRANSFORMER, POWER	(WR99ES:US, Canadian)
T1	▲ 1-450-445-11	TRANSFORMER, POWER	(WR99ES:E)
VS1	▲ 1-692-155-11	SELECTOR, POWER VOLTAGE	(WR99ES:E)
CNJ1	1-558-350-21	CORD (WITH CONNECTOR)	(WR99ES:US, Canadian)

Note:
The components identified by mark ▲ or dotted line with mark ▲ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque ▲ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

(4) MECHANISM DECK SECTION 2 (TCM-200R4)



Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
551	3-356-604-01	BELT (CAPSTAN)		574	3-356-603-01	BELT (MODE)	
552	X-3356-642-1	FLYWHEEL (R FWD) ASSY		575	3-356-607-01	PULLEY (MODE)	
553	X-3356-643-1	FLYWHEEL (R REV) ASSY		576	3-356-703-01	GEAR (COMMUNICATION C)	
554	3-355-801-01	SCREW (BTP 2X18)		577	3-356-616-01	GEAR (LOADING CAM)	
555	3-356-705-01	WASHER (CAPSTAN)		578	3-356-609-01	GEAR (LOADING)	
556	* 3-356-718-01	SPACER (THRUST RETAINER R)		579	3-356-605-01	SPRING, COMPRESSION	
557	3-356-631-01	HOLDER (SENSOR)		580	3-558-708-11	WASHER, STOPPER	
558	* 3-356-628-01	SPACER (MOTOR)		581	3-356-630-01	ROLLER (LOADING)	
559	* X-3356-602-1	BRACKET (MOTOR R) ASSY		582	* X-3356-606-1	LEVER (LOADING) ASSY	
560	3-363-804-01	SCREW (+P 2.6X6.5)		583	3-356-612-01	SLIDER (REVERSE)	
561	3-356-702-01	GEAR (COMMUNICATION B)		584	X-3356-634-1	CHASSIS (R2) COMPLETE ASSY, MECH	
562	3-669-465-00	WASHER (1.5), STOPPER		585	3-356-624-01	SPRING, TENSION	
563	3-356-613-01	LEVER (MODE)		586	* 1-632-741-11	REAL MOTOR BOARD	
565	3-356-617-01	LEVER (SELECTION)		587	* 1-634-323-11	TRANSLATION BOARD	
566	3-356-606-01	GEAR (MODE)		588	* 1-632-740-11	MD BOARD	
567	3-356-615-01	GEAR (MODE CAM RR)		M1051	X-3356-638-1	MOTOR (REEL R) ASSY	
570	* 3-356-629-01	BRACKET (THRUST RETAINER R)		M1052	X-3356-604-1	MOTOR (ASSIST) ASSY	
571	3-356-707-01	SCREW (+PTPH 2X25)		M1053	X-3356-605-1	MOTOR (CAPSTAN R) ASSY	
572	4-885-599-00	SCREW, FITTING, REINFORCEMENT		S1001	1-466-525-11	ENCORDER, ROTARY	
573	3-575-321-00	RETAINER, THRUST, CAPSTAN		IC1001	8-749-920-97	DIODE GP2S22B	
				IC1002	8-749-920-97	DIODE GP2S22B	

SECTION 6

ELECTRICAL PARTS LIST

TRANSLATION

MAIN

NOTE:

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spéci-fie.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- - XX, - X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL : metal-film resistor
METAL OXIDE : Metal Oxide-film resistor
F : nonflammable

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example :
uA... : μ A... , uPA... , μ PA... ,
uPB... , μ PB... , uPC... , μ PC... ,
uPD... , μ PD...
- CAPACITORS :
uF : μ F
- COILS
uH : μ H

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
	* 1-634-323-11	TRANSLATION BOARD *****		C153	1-130-469-00	MYLAR 680PF 5%	50V
		< CONNECTOR >		C154	1-136-157-00	FILM 0.022uF 5%	50V
CN1091	* 1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P		C155	1-124-657-00	ELECT 10uF 20%	50V
CN1092	* 1-564-509-11	PLUG, CONNECTOR 6P		C156	1-136-158-00	FILM 0.027uF 5%	50V
CN1093	* 1-564-705-11	PIN, CONNECTOR (SMALL TYPE) 3P		C191	1-123-382-00	ELECT 3.3uF 20%	100V
CN1094	* 1-564-506-11	PLUG, CONNECTOR 3P					
*****				C192	1-164-159-11	CERAMIC 0.1uF	50V
	* A-2006-727-A	MAIN BOARD, COMPLETE (WR99ES:US, Canadian) *****		C221	1-136-153-00	FILM 0.01uF 5%	50V
	* A-2006-725-A	MAIN BOARD, COMPLETE (WR99ES:E, WR990) *****		C222	1-136-157-00	FILM 0.022uF 5%	50V
	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3		C223	1-136-161-00	FILM 0.047uF 5%	50V
	7-682-548-04	SCREW +BVTT 3X8 (S)		C224	1-136-272-00	FILM 68PF 5%	630V
		< CAPACITOR >					
C121	1-136-153-00	FILM 0.01uF 5%	50V	C225	1-136-433-11	FILM 100PF 5%	630V
C122	1-136-157-00	FILM 0.022uF 5%	50V	C226	1-130-468-00	MYLAR 560PF 5%	50V
C123	1-136-161-00	FILM 0.047uF 5%	50V	C231	1-136-935-11	FILM 22PF 5%	630V
C124	1-136-272-00	FILM 68PF 5%	630V	C232	1-162-285-31	CERAMIC 180PF 10%	50V
C125	1-136-433-11	FILM 100PF 5%	630V	C233	1-130-469-00	MYLAR 680PF 5%	50V
C126	1-130-468-00	MYLAR 560PF 5%	50V				
C131	1-136-935-11	FILM 22PF 5%	630V	C234	1-136-157-00	FILM 0.022uF 5%	50V
C132	1-162-285-31	CERAMIC 180PF 10%	50V	C235	1-124-657-00	ELECT 10uF 20%	50V
C133	1-130-469-00	MYLAR 680PF 5%	50V	C236	1-136-158-00	FILM 0.027uF 5%	50V
C134	1-136-157-00	FILM 0.022uF 5%	50V	C241	1-136-153-00	FILM 0.01uF 5%	50V
C135	1-124-657-00	ELECT 10uF 20%	50V	C242	1-136-157-00	FILM 0.022uF 5%	50V
C136	1-136-158-00	FILM 0.027uF 5%	50V				
C141	1-136-153-00	FILM 0.01uF 5%	50V	C243	1-136-161-00	FILM 0.047uF 5%	50V
C142	1-136-157-00	FILM 0.022uF 5%	50V	C244	1-136-272-00	FILM 68PF 5%	630V
C143	1-136-161-00	FILM 0.047uF 5%	50V	C245	1-136-433-11	FILM 100PF 5%	630V
C144	1-136-272-00	FILM 68PF 5%	630V	C246	1-130-468-00	MYLAR 560PF 5%	50V
C145	1-136-433-11	FILM 100PF 5%	630V	C251	1-136-935-11	FILM 22PF 5%	630V
C146	1-130-468-00	MYLAR 560PF 5%	50V				
C151	1-136-935-11	FILM 22PF 5%	630V	C252	1-162-285-31	CERAMIC 180PF 10%	50V
C152	1-162-285-31	CERAMIC 180PF 10%	50V	C253	1-130-469-00	MYLAR 680PF 5%	50V
				C254	1-136-157-00	FILM 0.022uF 5%	50V
				C255	1-124-657-00	ELECT 10uF 20%	50V
				C256	1-136-158-00	FILM 0.027uF 5%	50V
				C291	1-123-382-00	ELECT 3.3uF 20%	100V
				C292	1-164-159-11	CERAMIC 0.1uF	50V
				C301	1-124-902-00	ELECT 0.47uF 20%	50V
				C303	1-124-927-11	ELECT 4.7uF 20%	100V
				C304	1-124-927-11	ELECT 4.7uF 20%	100V
				C351	1-124-902-00	ELECT 0.47uF 20%	50V
				C353	1-124-927-11	ELECT 4.7uF 20%	100V
				C354	1-124-927-11	ELECT 4.7uF 20%	100V
				C401	1-124-902-00	ELECT 0.47uF 20%	50V
				C403	1-124-927-11	ELECT 4.7uF 20%	100V

MAIN

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
C404	1-124-927-11	ELECT	4. 7uF 20% 100V	C758	1-126-176-11	ELECT	220uF 20% 10V
C451	1-124-902-00	ELECT	0. 47uF 20% 50V	C759	1-126-176-11	ELECT	220uF 20% 10V
C453	1-124-927-11	ELECT	4. 7uF 20% 100V	C802	1-164-159-11	CERAMIC	0. 1uF 50V
C454	1-124-927-11	ELECT	4. 7uF 20% 100V	C803	1-161-494-00	CERAMIC	0. 022uF 25V
C521	1-124-925-11	ELECT	2. 2uF 20% 100V	C804	1-162-306-11	CERAMIC	0. 01uF 20% 16V
C522	1-124-902-00	ELECT	0. 47uF 20% 50V	C805	1-124-925-11	ELECT	2. 2uF 20% 100V
C523	1-136-230-00	FILM	0. 0022uF 5% 100V	C806	1-164-159-11	CERAMIC	0. 1uF 50V
C524	1-136-230-00	FILM	0. 0022uF 5% 100V	C807	1-164-159-11	CERAMIC	0. 1uF 50V
C525	1-130-856-00	FILM	0. 0068uF 5% 100V	C811	1-126-233-11	ELECT	22uF 20% 50V
C526	1-124-907-11	ELECT	10uF 20% 50V	C831	1-124-927-11	ELECT	4. 7uF 20% 100V
C527	1-136-558-11	FILM	0. 0039uF 5% 630V	C832	1-124-477-11	ELECT	47uF 20% 25V
C528	1-124-477-11	ELECT	47uF 20% 25V	C833	1-130-479-00	MYLAR	0. 0047uF 5% 50V
C529	1-124-477-11	ELECT	47uF 20% 25V	C834	1-124-443-00	ELECT	100uF 20% 10V
C530	1-107-046-00	MICA	4. 7PF 500V	C841	1-124-927-11	ELECT	4. 7uF 20% 100V
C535	1-126-176-11	ELECT	220uF 20% 10V	C842	1-124-477-11	ELECT	47uF 20% 25V
C536	1-126-176-11	ELECT	220uF 20% 10V	C843	1-130-479-00	MYLAR	0. 0047uF 5% 50V
C541	1-124-925-11	ELECT	2. 2uF 20% 100V	C851	1-124-443-00	ELECT	100uF 20% 10V
C542	1-124-902-00	ELECT	0. 47uF 20% 50V	C871	1-164-159-11	CERAMIC	0. 1uF 50V
C543	1-136-230-00	FILM	0. 0022uF 5% 100V	C872	1-164-159-11	CERAMIC	0. 1uF 50V
C544	1-136-230-00	FILM	0. 0022uF 5% 100V	C873	1-162-306-11	CERAMIC	0. 01uF 20% 16V
C545	1-130-856-00	FILM	0. 0068uF 5% 100V	C881	1-164-159-11	CERAMIC	0. 1uF 50V
C546	1-124-907-11	ELECT	10uF 20% 50V	C882	1-164-159-11	CERAMIC	0. 1uF 50V
C547	1-136-558-11	FILM	0. 0039uF 5% 630V	C898	1-164-159-11	CERAMIC	0. 1uF 50V
C548	1-124-477-11	ELECT	47uF 20% 25V			(WR99ES:US, Canadian)	
C549	1-124-477-11	ELECT	47uF 20% 25V	C899	1-161-375-00	CERAMIC	0. 0022uF 20% 50V
C550	1-107-046-00	MICA	4. 7PF 500V			< CONNECTOR >	
C555	1-126-176-11	ELECT	220uF 20% 10V	CN541	1-506-469-11	CONNECTOR	4P, MALE
C556	1-126-176-11	ELECT	220uF 20% 10V	CN561	* 1-564-705-11	PIN, CONNECTOR (SMALL TYPE)	3P
C561	1-124-120-11	ELECT	220uF 20% 25V	CN562	* 1-564-337-00	PIN, CONNECTOR	3P
C562	1-161-494-00	CERAMIC	0. 022uF 25V	CN571	* 1-564-707-11	PIN, CONNECTOR (SMALL TYPE)	5P
C581	1-124-925-11	ELECT	2. 2uF 20% 100V	CN701	* 1-564-513-11	PLUG, CONNECTOR	10P
C582	1-162-217-31	CERAMIC	56PF 5% 50V	CN801	* 1-564-340-61	PIN, CONNECTOR	6P
C583	1-136-157-00	FILM	0. 022uF 5% 50V	CN802	* 1-568-935-11	PIN, CONNECTOR	8P
C585	1-162-286-31	CERAMIC	220PF 10% 50V	CN804	* 1-691-908-11	SOCKET, CONNECTOR	
C586	1-124-925-11	ELECT	2. 2uF 20% 100V	CN805	* 1-564-338-71	PIN, CONNECTOR	4P
C587	1-124-925-11	ELECT	2. 2uF 20% 100V	CN806	* 1-564-340-00	PIN, CONNECTOR	6P
C601	1-124-903-11	ELECT	1uF 20% 50V	CN807	1-565-951-11	SOCKET, CONNECTOR (PC BOARD)	4P
C651	1-124-903-11	ELECT	1uF 20% 50V			(WR99ES:US, Canadian)	
C701	1-124-927-11	ELECT	4. 7uF 20% 100V	CN810	1-506-469-11	CONNECTOR	4P, MALE
C702	1-124-772-11	ELECT	10000uF 20% 25V	CNP601	* 1-691-915-11	CONNECTOR, BOARD TO BOARD	15P
C703	1-124-126-00	ELECT	47uF 20% 10V	CNP602	* 1-691-915-11	CONNECTOR, BOARD TO BOARD	15P
C704	1-124-898-11	ELECT	4700uF 20% 16V			< COMPOSITION CIRCUIT BLOCK >	
C705	1-124-556-11	ELECT	2200uF 20% 16V	CP851	1-233-199-11	COMPOSITION CIRCUIT BLOCK	
C706	1-124-443-00	ELECT	100uF 20% 10V	CP852	1-233-199-11	COMPOSITION CIRCUIT BLOCK	
C707	1-124-471-00	ELECT	1000uF 20% 6. 3V			< DIODE >	
C708	1-124-919-11	ELECT	220uF 20% 63V	D191	8-719-987-63	DIODE	1N4148M
C709	1-124-927-11	ELECT	4. 7uF 20% 100V	D291	8-719-987-63	DIODE	1N4148M
C710	1-124-927-11	ELECT	4. 7uF 20% 100V	D521	8-719-987-63	DIODE	1N4148M
C751	1-124-556-11	ELECT	2200uF 20% 16V	D522	8-719-987-63	DIODE	1N4148M
C752	1-124-556-11	ELECT	2200uF 20% 16V	D541	8-719-987-63	DIODE	1N4148M
C753	1-124-120-11	ELECT	220uF 20% 25V				
C754	1-124-120-11	ELECT	220uF 20% 25V				
C755	1-124-925-11	ELECT	2. 2uF 20% 100V				
C756	1-162-286-31	CERAMIC	220PF 10% 50V				
C757	1-162-286-31	CERAMIC	220PF 10% 50V				

MAIN

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
D542	8-719-987-63	DIODE 1N4148M				< COIL >	
D561	8-719-987-63	DIODE 1N4148M		L131	1-410-780-11	INDUCTOR 27mH	
D601	8-719-987-63	DIODE 1N4148M		L151	1-410-780-11	INDUCTOR 27mH	
D602	8-719-987-63	DIODE 1N4148M		L231	1-410-780-11	INDUCTOR 27mH	
D701	8-719-200-77	DIODE 10E2N		L251	1-410-780-11	INDUCTOR 27mH	
D702	8-719-500-36	DIODE D2SB20				< JACK >	
D703	8-719-987-63	DIODE 1N4148M		PJ561	1-573-070-11	JACK, PIN 4P (LINE IN/OUT)	
D704	8-719-001-54	DIODE UZL-11H2				< TRANSISTOR >	
D705	8-719-200-77	DIODE 10E2N		Q131	8-729-900-74	TRANSISTOR DTC143TS	
D706	8-719-933-41	DIODE HZS6C3L		Q151	8-729-900-74	TRANSISTOR DTC143TS	
D707	8-719-987-63	DIODE 1N4148M		Q161	8-729-922-37	TRANSISTOR 2SD2144S	
D708	8-719-933-38	DIODE HZS6B3L		Q231	8-729-900-74	TRANSISTOR DTC143TS	
D751	8-719-200-77	DIODE 10E2N		Q251	8-729-900-74	TRANSISTOR DTC143TS	
D752	8-719-200-77	DIODE 10E2N					
D753	8-719-200-77	DIODE 10E2N		Q261	8-729-922-37	TRANSISTOR 2SD2144S	
D754	8-719-200-77	DIODE 10E2N		Q301	8-729-620-05	TRANSISTOR 2SC2603-EF	
D755	8-719-987-63	DIODE 1N4148M		Q351	8-729-620-05	TRANSISTOR 2SC2603-EF	
D756	8-719-987-63	DIODE 1N4148M		Q401	8-729-620-05	TRANSISTOR 2SC2603-EF	
D757	8-719-933-33	DIODE HZS6A1L		Q451	8-729-620-05	TRANSISTOR 2SC2603-EF	
D758	8-719-987-63	DIODE 1N4148M					
D801	8-719-987-63	DIODE 1N4148M		Q521	8-729-900-65	TRANSISTOR DTA144ES	
D802	8-719-987-63	DIODE 1N4148M		Q522	8-729-900-65	TRANSISTOR DTA144ES	
D804	8-719-987-63	DIODE 1N4148M		Q523	8-729-900-61	TRANSISTOR DTA114ES	
D805	8-719-987-63	DIODE 1N4148M		Q524	8-729-900-89	TRANSISTOR DTC144ES	
D831	8-719-987-63	DIODE 1N4148M		Q525	8-729-900-89	TRANSISTOR DTC144ES	
D841	8-719-987-63	DIODE 1N4148M					
D890	8-719-987-63	DIODE 1N4148M	(WR99ES:US, Canadian)	Q526	8-729-900-80	TRANSISTOR DTC114ES	
D891	8-719-987-63	DIODE 1N4148M	(WR99ES:US, Canadian)	Q527	8-729-821-04	TRANSISTOR 2SA1317-STU	
D892	8-719-987-63	DIODE 1N4148M		Q528	8-729-142-46	TRANSISTOR 2SC2001-M	
D893	8-719-987-63	DIODE 1N4148M		Q529	8-729-142-46	TRANSISTOR 2SC2001-M	
				Q531	8-729-900-89	TRANSISTOR DTC144ES	
D894	8-719-987-63	DIODE 1N4148M					
D895	8-719-987-63	DIODE 1N4148M		Q532	8-729-900-89	TRANSISTOR DTC144ES	
		< IC >		Q533	8-729-900-65	TRANSISTOR DTA144ES	
IC501	8-759-106-56	IC uPC1297CA		Q541	8-729-900-65	TRANSISTOR DTA144ES	
IC502	8-759-106-56	IC uPC1297CA		Q542	8-729-900-65	TRANSISTOR DTA144ES	
IC503	8-759-111-44	IC uPC4570C-1		Q543	8-729-900-61	TRANSISTOR DTA114ES	
IC504	8-759-111-44	IC uPC4570C-1					
IC506	8-759-140-53	IC MC14053BCP		Q544	8-729-900-89	TRANSISTOR DTC144ES	
				Q545	8-729-900-89	TRANSISTOR DTC144ES	
IC508	8-759-945-58	IC RC4558P		Q546	8-729-900-80	TRANSISTOR DTC114ES	
IC509	8-759-945-58	IC RC4558P		Q547	8-729-821-04	TRANSISTOR 2SA1317-STU	
IC601	8-752-060-64	IC CXA1198AP		Q548	8-729-142-46	TRANSISTOR 2SC2001-M	
IC602	8-752-060-64	IC CXA1198AP					
IC603	8-759-000-47	IC MC14051BCP		Q549	8-729-142-46	TRANSISTOR 2SC2001-M	
				Q551	8-729-900-89	TRANSISTOR DTC144ES	
IC801	8-759-059-44	IC M50944-178SP		Q552	8-729-900-89	TRANSISTOR DTC144ES	
IC802	8-759-633-86	IC M50747-B83SP		Q553	8-729-900-65	TRANSISTOR DTA144ES	
IC803	8-759-822-09	IC LB1641		Q561	8-729-900-65	TRANSISTOR DTA144ES	
IC804	8-759-240-71	IC TC4071BP					
IC805	8-759-973-95	IC BA6219B		Q562	8-729-821-04	TRANSISTOR 2SA1317-STU	
				Q581	8-729-900-65	TRANSISTOR DTA144ES	
IC806	8-759-822-09	IC LB1641		Q582	8-729-900-89	TRANSISTOR DTC144ES	
IC807	8-759-973-95	IC BA6219B		Q601	8-729-900-65	TRANSISTOR DTA144ES	
IC808	8-759-822-09	IC LB1641		Q602	8-729-900-89	TRANSISTOR DTC144ES	
IC809	8-759-140-11	IC uPD4011BC	(WR99ES:US, Canadian)				

MAIN

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
Q603	8-729-900-89	TRANSISTOR	DTC144ES	R137	1-247-840-00	CARBON	2. 4K 5% 1/4W
Q604	8-729-620-05	TRANSISTOR	2SC2603-EF	R138	1-247-887-00	CARBON	220K 5% 1/4W
Q605	8-729-900-89	TRANSISTOR	DTC144ES	R139	1-249-425-11	CARBON	4. 7K 5% 1/4W
Q651	8-729-900-65	TRANSISTOR	DTA144ES	R141	1-249-427-11	CARBON	6. 8K 5% 1/4W
Q652	8-729-900-80	TRANSISTOR	DTC114ES	R142	1-249-435-11	CARBON	33K 5% 1/4W
Q653	8-729-900-89	TRANSISTOR	DTC144ES	R143	△1-219-153-11	FUSIBLE	10 5% 1/4W F
Q654	8-729-900-65	TRANSISTOR	DTA144ES	R144	1-247-883-00	CARBON	150K 5% 1/4W
Q701	8-729-620-05	TRANSISTOR	2SC2603-EF	R151	1-249-428-11	CARBON	8. 2K 5% 1/4W
Q702	8-729-141-83	TRANSISTOR	2SB1094-LK	R152	1-249-433-11	CARBON	22K 5% 1/4W
Q703	8-729-620-05	TRANSISTOR	2SC2603-EF	R153	1-249-403-11	CARBON	68 5% 1/4W
Q704	8-729-620-05	TRANSISTOR	2SC2603-EF	R154	1-247-882-11	CARBON	130K 5% 1/4W
Q705	8-729-209-15	TRANSISTOR	2SD2012	R155	1-249-426-11	CARBON	5. 6K 5% 1/4W
Q706	8-729-821-04	TRANSISTOR	2SA1317-STU	R156	1-249-420-11	CARBON	1. 8K 5% 1/4W
Q707	8-729-140-04	TRANSISTOR	2SB1116A-L	R157	1-247-840-00	CARBON	2. 4K 5% 1/4W
Q751	8-729-620-05	TRANSISTOR	2SC2603-EF	R158	1-247-887-00	CARBON	220K 5% 1/4W
Q752	8-729-209-15	TRANSISTOR	2SD2012	R159	1-249-425-11	CARBON	4. 7K 5% 1/4W
Q753	8-729-620-05	TRANSISTOR	2SC2603-EF	R161	1-249-433-11	CARBON	22K 5% 1/4W
Q754	8-729-821-04	TRANSISTOR	2SA1317-STU	R162	1-249-417-11	CARBON	1K 5% 1/4W
Q755	8-729-141-83	TRANSISTOR	2SB1094-LK	R163	1-249-421-11	CARBON	2. 2K 5% 1/4W
Q756	8-729-821-04	TRANSISTOR	2SA1317-STU	R164	1-249-432-11	CARBON	18K 5% 1/4W
Q757	8-729-821-04	TRANSISTOR	2SA1317-STU	R165	1-249-421-11	CARBON	2. 2K 5% 1/4W
Q801	8-729-620-05	TRANSISTOR	2SC2603-EF	R191	1-249-429-11	CARBON	10K 5% 1/4W
Q802	8-729-620-05	TRANSISTOR	2SC2603-EF	R192	1-247-864-11	CARBON	24K 5% 1/4W
Q803	8-729-821-04	TRANSISTOR	2SA1317-STU	R193	1-249-434-11	CARBON	27K 5% 1/4W
Q831	8-729-620-05	TRANSISTOR	2SC2603-EF	R194	1-249-408-11	CARBON	180 5% 1/4W
Q832	8-729-620-05	TRANSISTOR	2SC2603-EF	R221	1-249-427-11	CARBON	6. 8K 5% 1/4W
Q841	8-729-620-05	TRANSISTOR	2SC2603-EF	R222	1-249-435-11	CARBON	33K 5% 1/4W
Q842	8-729-620-05	TRANSISTOR	2SC2603-EF	R223	△1-219-153-11	FUSIBLE	10 5% 1/4W F
Q871	8-729-900-65	TRANSISTOR	DTA144ES	R224	1-247-883-00	CARBON	150K 5% 1/4W
Q872	8-729-900-80	TRANSISTOR	DTC114ES	R231	1-249-428-11	CARBON	8. 2K 5% 1/4W
Q873	8-729-900-80	TRANSISTOR	DTC114ES	R232	1-249-433-11	CARBON	22K 5% 1/4W
Q874	8-729-900-80	TRANSISTOR	DTC114ES	R233	1-249-403-11	CARBON	68 5% 1/4W
Q875	8-729-900-65	TRANSISTOR	DTA144ES	R234	1-247-882-11	CARBON	130K 5% 1/4W
Q876	8-729-900-89	TRANSISTOR	DTC144ES	R235	1-249-426-11	CARBON	5. 6K 5% 1/4W
Q877	8-729-900-89	TRANSISTOR	DTC144ES	R236	1-249-420-11	CARBON	1. 8K 5% 1/4W
Q878	8-729-900-89	TRANSISTOR	DTC144ES	R237	1-247-840-00	CARBON	2. 4K 5% 1/4W
Q879	8-729-900-65	TRANSISTOR	DTA144ES	R238	1-247-887-00	CARBON	220K 5% 1/4W
Q881	8-729-900-65	TRANSISTOR	DTA144ES	R239	1-249-425-11	CARBON	4. 7K 5% 1/4W
Q882	8-729-900-89	TRANSISTOR	DTC144ES	R241	1-249-427-11	CARBON	6. 8K 5% 1/4W
Q883	8-729-900-80	TRANSISTOR	DTC114ES	R242	1-249-435-11	CARBON	33K 5% 1/4W
Q884	8-729-900-80	TRANSISTOR	DTC114ES	R243	△1-219-153-11	FUSIBLE	10 5% 1/4W F
Q885	8-729-900-80	TRANSISTOR	DTC114ES	R244	1-247-883-00	CARBON	150K 5% 1/4W
< RESISTOR >				R251	1-249-428-11	CARBON	8. 2K 5% 1/4W
R121	1-249-427-11	CARBON	6. 8K 5% 1/4W	R252	1-249-433-11	CARBON	22K 5% 1/4W
R122	1-249-435-11	CARBON	33K 5% 1/4W	R253	1-249-403-11	CARBON	68 5% 1/4W
R123	△1-219-153-11	FUSIBLE	10 5% 1/4W F	R254	1-247-882-11	CARBON	130K 5% 1/4W
R124	1-247-883-00	CARBON	150K 5% 1/4W	R255	1-249-426-11	CARBON	5. 6K 5% 1/4W
R131	1-249-428-11	CARBON	8. 2K 5% 1/4W	R256	1-249-420-11	CARBON	1. 8K 5% 1/4W
R132	1-249-433-11	CARBON	22K 5% 1/4W	R257	1-247-840-00	CARBON	2. 4K 5% 1/4W
R133	1-249-403-11	CARBON	68 5% 1/4W	R258	1-247-887-00	CARBON	220K 5% 1/4W
R134	1-247-882-11	CARBON	130K 5% 1/4W	R259	1-249-425-11	CARBON	4. 7K 5% 1/4W
R135	1-249-426-11	CARBON	5. 6K 5% 1/4W	R261	1-249-433-11	CARBON	22K 5% 1/4W
R136	1-249-420-11	CARBON	1. 8K 5% 1/4W	R262	1-249-417-11	CARBON	1K 5% 1/4W
				R263	1-249-421-11	CARBON	2. 2K 5% 1/4W
				R264	1-249-432-11	CARBON	18K 5% 1/4W

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

MAIN

Ref. No.	Part No.	Description				Remarks	Ref. No.	Part No.	Description				Remarks
R265	1-249-421-11	CARBON	2.2K	5%	1/4W		R587	1-249-421-11	CARBON	2.2K	5%	1/4W	
R291	1-249-429-11	CARBON	10K	5%	1/4W		R588	1-249-441-11	CARBON	100K	5%	1/4W	
R292	1-247-864-11	CARBON	24K	5%	1/4W		R601	1-249-417-11	CARBON	1K	5%	1/4W	
R293	1-249-434-11	CARBON	27K	5%	1/4W		R602	1-249-441-11	CARBON	100K	5%	1/4W	
R294	1-249-408-11	CARBON	180	5%	1/4W		R603	1-247-864-11	CARBON	24K	5%	1/4W	
R301	1-249-429-11	CARBON	10K	5%	1/4W		R604	1-249-433-11	CARBON	22K	5%	1/4W	
R302	1-249-425-11	CARBON	4.7K	5%	1/4W		R621	1-249-434-11	CARBON	27K	5%	1/4W	
R304	1-249-425-11	CARBON	4.7K	5%	1/4W		R622	1-249-434-11	CARBON	27K	5%	1/4W	
R305	1-249-425-11	CARBON	4.7K	5%	1/4W		R623	1-247-874-11	CARBON	62K	5%	1/4W	
R306	1-249-425-11	CARBON	4.7K	5%	1/4W		R624	1-247-883-00	CARBON	150K	5%	1/4W	
R351	1-249-429-11	CARBON	10K	5%	1/4W		R625	1-249-437-11	CARBON	47K	5%	1/4W	
R352	1-249-425-11	CARBON	4.7K	5%	1/4W		R626	1-249-439-11	CARBON	68K	5%	1/4W	
R354	1-249-425-11	CARBON	4.7K	5%	1/4W		R631	1-249-436-11	CARBON	39K	5%	1/4W	
R355	1-249-425-11	CARBON	4.7K	5%	1/4W		R632	1-247-868-11	CARBON	36K	5%	1/4W	
R356	1-249-425-11	CARBON	4.7K	5%	1/4W		R633	1-247-880-11	CARBON	110K	5%	1/4W	
R401	1-249-429-11	CARBON	10K	5%	1/4W		R634	1-247-885-00	CARBON	180K	5%	1/4W	
R402	1-249-425-11	CARBON	4.7K	5%	1/4W		R635	1-249-437-11	CARBON	47K	5%	1/4W	
R404	1-249-425-11	CARBON	4.7K	5%	1/4W		R636	1-247-889-00	CARBON	270K	5%	1/4W	
R405	1-249-425-11	CARBON	4.7K	5%	1/4W		R641	1-249-436-11	CARBON	39K	5%	1/4W	
R406	1-249-425-11	CARBON	4.7K	5%	1/4W		R642	1-249-436-11	CARBON	39K	5%	1/4W	
R451	1-249-429-11	CARBON	10K	5%	1/4W		R643	1-249-439-11	CARBON	68K	5%	1/4W	
R452	1-249-425-11	CARBON	4.7K	5%	1/4W		R644	1-247-883-00	CARBON	150K	5%	1/4W	
R454	1-249-425-11	CARBON	4.7K	5%	1/4W		R645	1-247-868-11	CARBON	36K	5%	1/4W	
R455	1-249-425-11	CARBON	4.7K	5%	1/4W		R646	1-249-441-11	CARBON	100K	5%	1/4W	
R456	1-249-425-11	CARBON	4.7K	5%	1/4W		R651	1-249-417-11	CARBON	1K	5%	1/4W	
R521	1-249-425-11	CARBON	4.7K	5%	1/4W		R652	1-249-441-11	CARBON	100K	5%	1/4W	
R522	1-249-422-11	CARBON	2.7K	5%	1/4W		R653	1-247-864-11	CARBON	24K	5%	1/4W	
R523	1-249-430-11	CARBON	12K	5%	1/4W		R655	1-247-887-00	CARBON	220K	5%	1/4W	
R524	1-249-441-11	CARBON	100K	5%	1/4W		R656	1-249-429-11	CARBON	10K	5%	1/4W	
R526	1-249-421-11	CARBON	2.2K	5%	1/4W		R662	1-249-434-11	CARBON	27K	5%	1/4W	
R527	1-249-421-11	CARBON	2.2K	5%	1/4W		R663	1-249-434-11	CARBON	27K	5%	1/4W	
R528	1-249-429-11	CARBON	10K	5%	1/4W		R664	1-249-439-11	CARBON	68K	5%	1/4W	
R529	1-249-437-11	CARBON	47K	5%	1/4W		R665	1-247-885-00	CARBON	180K	5%	1/4W	
R530	1-249-437-11	CARBON	47K	5%	1/4W		R666	1-249-437-11	CARBON	47K	5%	1/4W	
R531	1-249-389-11	CARBON	4.7	5%	1/4W		R667	1-249-439-11	CARBON	68K	5%	1/4W	
R532	1-249-389-11	CARBON	4.7	5%	1/4W		R668	1-249-436-11	CARBON	39K	5%	1/4W	
R541	1-249-425-11	CARBON	4.7K	5%	1/4W		R669	1-247-868-11	CARBON	36K	5%	1/4W	
R542	1-249-422-11	CARBON	2.7K	5%	1/4W		R670	1-247-883-00	CARBON	150K	5%	1/4W	
R543	1-249-430-11	CARBON	12K	5%	1/4W		R671	1-247-887-00	CARBON	220K	5%	1/4W	
R544	1-249-441-11	CARBON	100K	5%	1/4W		R672	1-247-870-11	CARBON	43K	5%	1/4W	
R546	1-249-421-11	CARBON	2.2K	5%	1/4W		R673	1-247-889-00	CARBON	270K	5%	1/4W	
R547	1-249-421-11	CARBON	2.2K	5%	1/4W		R674	1-249-436-11	CARBON	39K	5%	1/4W	
R548	1-249-429-11	CARBON	10K	5%	1/4W		R675	1-249-436-11	CARBON	39K	5%	1/4W	
R549	1-249-437-11	CARBON	47K	5%	1/4W		R676	1-249-440-11	CARBON	82K	5%	1/4W	
R550	1-249-437-11	CARBON	47K	5%	1/4W		R677	1-247-885-00	CARBON	180K	5%	1/4W	
R551	1-249-389-11	CARBON	4.7	5%	1/4W		R678	1-247-868-11	CARBON	36K	5%	1/4W	
R552	1-249-389-11	CARBON	4.7	5%	1/4W		R679	1-249-441-11	CARBON	100K	5%	1/4W	
R561	1-249-409-11	CARBON	220	5%	1/4W		R681	1-247-858-11	CARBON	13K	5%	1/4W	
R562	1-249-433-11	CARBON	22K	5%	1/4W		R682	1-247-866-11	CARBON	30K	5%	1/4W	
R581	1-247-887-00	CARBON	220K	5%	1/4W		R683	1-247-858-11	CARBON	13K	5%	1/4W	
R582	1-249-425-11	CARBON	4.7K	5%	1/4W		R684	1-249-438-11	CARBON	56K	5%	1/4W	
R583	1-249-437-11	CARBON	47K	5%	1/4W		R685	1-249-435-11	CARBON	33K	5%	1/4W	
R584	1-249-428-11	CARBON	8.2K	5%	1/4W		R686	1-247-885-00	CARBON	180K	5%	1/4W	
R585	1-249-441-11	CARBON	100K	5%	1/4W		R687	1-247-864-11	CARBON	24K	5%	1/4W	
R586	1-249-423-11	CARBON	3.3K	5%	1/4W		R688	1-247-870-11	CARBON	43K	5%	1/4W	

MAIN

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
R689	1-249-435-11	CARBON	33K 5% 1/4W	R824	1-249-420-11	CARBON	1.8K 5% 1/4W
R690	1-249-438-11	CARBON	56K 5% 1/4W	R825	1-249-417-11	CARBON	1K 5% 1/4W
R691	1-247-866-11	CARBON	30K 5% 1/4W	R826	1-249-429-11	CARBON	10K 5% 1/4W
R692	1-247-887-00	CARBON	220K 5% 1/4W	R827	1-249-429-11	CARBON	10K 5% 1/4W
R693	1-247-862-11	CARBON	20K 5% 1/4W	R828	1-249-415-11	CARBON	680 5% 1/4W
R694	1-247-870-11	CARBON	43K 5% 1/4W	R829	△1-212-950-00	FUSIBLE	4.7 5% 1/2W F
R695	1-249-429-11	CARBON	10K 5% 1/4W	R831	1-249-429-11	CARBON	10K 5% 1/4W
R696	1-249-437-11	CARBON	47K 5% 1/4W	R832	1-249-433-11	CARBON	22K 5% 1/4W
R697	1-249-435-11	CARBON	33K 5% 1/4W	R833	1-249-429-11	CARBON	10K 5% 1/4W
R698	1-247-885-00	CARBON	180K 5% 1/4W	R834	1-249-421-11	CARBON	2.2K 5% 1/4W
R700	△1-219-134-11	FUSIBLE	0.1 5% 1/4W F	R835	1-249-429-11	CARBON	10K 5% 1/4W
R701	1-249-433-11	CARBON	22K 5% 1/4W	R836	1-249-417-11	CARBON	1K 5% 1/4W
R702	1-249-421-11	CARBON	2.2K 5% 1/4W	R837	1-249-412-11	CARBON	390 5% 1/4W
R703	△1-219-154-11	FUSIBLE	0.12 10% 1/4W	R841	1-249-429-11	CARBON	10K 5% 1/4W
R704	△1-219-136-11	FUSIBLE	0.22 10% 1/4W	R842	1-249-433-11	CARBON	22K 5% 1/4W
R705	1-249-422-11	CARBON	2.7K 5% 1/4W	R843	1-249-429-11	CARBON	10K 5% 1/4W
R706	1-249-421-11	CARBON	2.2K 5% 1/4W	R844	1-249-421-11	CARBON	2.2K 5% 1/4W
R707	1-249-421-11	CARBON	2.2K 5% 1/4W	R845	1-249-429-11	CARBON	10K 5% 1/4W
R708	1-249-430-11	CARBON	12K 5% 1/4W	R846	1-249-417-11	CARBON	1K 5% 1/4W
R709	1-249-429-11	CARBON	10K 5% 1/4W	R847	1-249-412-11	CARBON	390 5% 1/4W
R710	1-249-436-11	CARBON	39K 5% 1/4W	R851	1-247-903-00	CARBON	1M 5% 1/4W
R751	1-249-433-11	CARBON	22K 5% 1/4W	R852	1-249-425-11	CARBON	4.7K 5% 1/4W
R752	1-249-421-11	CARBON	2.2K 5% 1/4W	R853	1-249-425-11	CARBON	4.7K 5% 1/4W
R753	1-249-421-11	CARBON	2.2K 5% 1/4W	R854	1-249-425-11	CARBON	4.7K 5% 1/4W
R754	1-249-421-11	CARBON	2.2K 5% 1/4W	R855	1-249-425-11	CARBON	4.7K 5% 1/4W
R755	1-249-421-11	CARBON	2.2K 5% 1/4W	R856	1-249-425-11	CARBON	4.7K 5% 1/4W
R756	1-249-417-11	CARBON	1K 5% 1/4W	R857	1-249-425-11	CARBON	4.7K 5% 1/4W
R757	1-249-417-11	CARBON	1K 5% 1/4W	R858	1-249-425-11	CARBON	4.7K 5% 1/4W
R758	1-249-417-11	CARBON	1K 5% 1/4W	R859	1-249-425-11	CARBON	4.7K 5% 1/4W
R759	1-249-415-11	CARBON	680 5% 1/4W	R861	1-249-436-11	CARBON	39K 5% 1/4W
R760	1-249-422-11	CARBON	2.7K 5% 1/4W	R862	1-249-436-11	CARBON	39K 5% 1/4W
R761	1-249-424-11	CARBON	3.9K 5% 1/4W	R863	1-247-895-00	CARBON	470K 5% 1/4W
R762	1-249-423-11	CARBON	3.3K 5% 1/4W	R864	1-247-895-00	CARBON	470K 5% 1/4W
R763	1-249-405-11	CARBON	100 5% 1/4W	R865	1-249-436-11	CARBON	39K 5% 1/4W
R801	1-249-405-11	CARBON	100 5% 1/4W	R866	1-249-436-11	CARBON	39K 5% 1/4W
R802	1-249-405-11	CARBON	100 5% 1/4W	R867	1-247-895-00	CARBON	470K 5% 1/4W
R803	1-249-433-11	CARBON	22K 5% 1/4W	R868	1-247-895-00	CARBON	470K 5% 1/4W
R804	1-249-433-11	CARBON	22K 5% 1/4W	R871	1-249-433-11	CARBON	22K 5% 1/4W
R806	1-249-421-11	CARBON	2.2K 5% 1/4W	R872	1-247-864-11	CARBON	24K 5% 1/4W
R807	1-249-421-11	CARBON	2.2K 5% 1/4W	R873	1-249-411-11	CARBON	330 5% 1/4W
R808	1-249-421-11	CARBON	2.2K 5% 1/4W	R874	1-247-830-11	CARBON	910 5% 1/4W
R809	1-249-421-11	CARBON	2.2K 5% 1/4W	R875	1-249-418-11	CARBON	1.2K 5% 1/4W
R810	1-249-421-11	CARBON	2.2K 5% 1/4W	R876	1-249-417-11	CARBON	1K 5% 1/4W
R811	1-249-433-11	CARBON	22K 5% 1/4W	R877	△1-212-950-00	FUSIBLE	4.7 5% 1/2W F
R812	1-249-433-11	CARBON	22K 5% 1/4W	R878	1-249-416-11	CARBON	820 5% 1/4W
R813	1-247-903-00	CARBON	1M 5% 1/4W	R879	1-249-419-11	CARBON	1.5K 5% 1/4W
R814	1-249-425-11	CARBON	4.7K 5% 1/4W	R880	1-249-417-11	CARBON	1K 5% 1/4W
R815	1-249-433-11	CARBON	22K 5% 1/4W	R881	△1-212-950-00	FUSIBLE	4.7 5% 1/2W F
R816	1-249-433-11	CARBON	22K 5% 1/4W	R882	1-249-433-11	CARBON	22K 5% 1/4W
R817	1-249-424-11	CARBON	3.9K 5% 1/4W	R883	1-247-864-11	CARBON	24K 5% 1/4W
R819	1-249-433-11	CARBON	22K 5% 1/4W	R884	1-249-411-11	CARBON	330 5% 1/4W
R820	1-249-429-11	CARBON	10K 5% 1/4W	R885	1-247-830-11	CARBON	910 5% 1/4W
R821	1-249-441-11	CARBON	100K 5% 1/4W	R886	1-249-418-11	CARBON	1.2K 5% 1/4W
R822	1-249-417-11	CARBON	1K 5% 1/4W	R887	1-249-417-11	CARBON	1K 5% 1/4W
R823	1-249-437-11	CARBON	47K 5% 1/4W	R888	△1-212-950-00	FUSIBLE	4.7 5% 1/2W F

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

PANEL (including SW (A) / (B) / POWER SW / FL / HP / REC VOL / COVER / POWER TRANSFORMER / DOLBY / PJ)

Ref. No.	Part No.	Description				Remarks	Ref. No.	Part No.	Description				Remarks
R889	1-249-416-11	CARBON	820	5%	1/4W				< TEST PIN >				
R890	1-249-419-11	CARBON	1.5K	5%	1/4W								
R891	1-249-417-11	CARBON	1K	5%	1/4W		TP521	* 1-564-506-11	PLUG, CONNECTOR 3P				
R892	△ 1-212-950-00	FUSIBLE	4.7	5%	1/2W F		TP541	* 1-564-506-11	PLUG, CONNECTOR 3P				
R893	1-249-433-11	CARBON	22K	5%	1/4W		TP581	* 1-564-506-11	PLUG, CONNECTOR 3P				
							TP801	* 1-564-505-11	PLUG, CONNECTOR 2P				
R894	1-249-393-11	CARBON	10	5%	1/4W		TP802	* 1-564-505-11	PLUG, CONNECTOR 2P				
R895	1-249-429-11	CARBON	10K	5%	1/4W	(WR99ES:US, Canadian)	TP803	* 1-564-505-11	PLUG, CONNECTOR 2P				
R896	1-249-429-11	CARBON	10K	5%	1/4W	(WR99ES:US, Canadian)			< VIBRATOR >				
R897	1-249-405-11	CARBON	100	5%	1/4W	(WR99ES:US, Canadian)	X801	1-577-358-21	VIBRATOR, CERAMIC 4MHZ				
R898	1-249-429-11	CARBON	10K	5%	1/4W	(WR99ES:US, Canadian)	X802	1-577-358-21	VIBRATOR, CERAMIC 4MHZ				

R899	1-249-429-11	CARBON	10K	5%	1/4W	(WR99ES:US, Canadian)							
R941	1-249-433-11	CARBON	22K	5%	1/4W			* 1-632-740-11	MD BOARD				
R942	1-247-862-11	CARBON	20K	5%	1/4W				*****				
R943	1-249-429-11	CARBON	10K	5%	1/4W								
R945	1-249-433-11	CARBON	22K	5%	1/4W			3-356-631-01	HOLDER (SENSOR)				
		< VARIABLE RESISTOR >							< CONNECTOR >				
RV121	1-238-601-11	RES, ADJ, CARBON 22K					CN1001	1-506-615-11	PIN, CONNECTOR 9P				
RV131	1-238-600-11	RES, ADJ, CARBON 10K					CN1002	* 1-564-502-11	PIN, CONNECTOR 10P				
RV141	1-238-601-11	RES, ADJ, CARBON 22K											
RV151	1-238-600-11	RES, ADJ, CARBON 10K							< DIODE >				
RV221	1-238-601-11	RES, ADJ, CARBON 22K											
							IC1001	8-749-920-97	DIODE GP2S22B				
RV231	1-238-600-11	RES, ADJ, CARBON 10K					IC1002	8-749-920-97	DIODE GP2S22B				
RV241	1-238-601-11	RES, ADJ, CARBON 22K							< RESISTOR >				
RV251	1-238-600-11	RES, ADJ, CARBON 10K											
RV301	1-238-600-11	RES, ADJ, CARBON 10K											
RV351	1-238-600-11	RES, ADJ, CARBON 10K					R1001	1-249-408-11	CARBON	180	5%	1/4W	
							R1002	1-249-408-11	CARBON	180	5%	1/4W	
RV401	1-238-600-11	RES, ADJ, CARBON 10K							< SWITCH >				
RV451	1-238-600-11	RES, ADJ, CARBON 10K											
RV831	1-238-602-11	RES, ADJ, CARBON 47K											
RV841	1-238-602-11	RES, ADJ, CARBON 47K					S1002	1-570-953-11	SWITCH, PUSH (1 KEY) (DOOR)				
RV871	1-238-600-11	RES, ADJ, CARBON 10K					S1003	1-571-958-11	SWITCH, PUSH (1 KEY) (CLOSE)				
							S1004	1-572-126-11	SWITCH, PUSH (1 KEY) (OPEN)				
RV872	1-238-600-11	RES, ADJ, CARBON 10K					S1005	1-572-125-11	SWITCH, LEAF (FWD)				
RV881	1-238-600-11	RES, ADJ, CARBON 10K					S1006	1-572-202-11	SWITCH, LEAF (HALF)				
RV882	1-238-600-11	RES, ADJ, CARBON 10K											
RV891	1-238-600-11	RES, ADJ, CARBON 10K					S1007	1-572-125-11	SWITCH, LEAF (METAL)				
		< RELAY >					S1008	1-572-125-11	SWITCH, LEAF (70uS)				
							S1009	1-572-125-11	SWITCH, LEAF (REV)				
RY531	1-515-683-11	RELAY							< TERMINAL >				
RY551	1-515-683-11	RELAY											
		< TRANSFORMER >					TB1001	* 1-694-018-11	TERMINAL (5P)				

T121	1-433-382-11	TRANSFORMER, BIAS OSCILLATION											
T141	1-433-382-11	TRANSFORMER, BIAS OSCILLATION											
T221	1-433-382-11	TRANSFORMER, BIAS OSCILLATION											
T241	1-433-382-11	TRANSFORMER, BIAS OSCILLATION						* A-2006-726-A	PANEL BOARD, COMPLETE				
T521	1-433-336-11	TRANSFORMER, BIAS OSCILLATION							*****				
T541	1-433-336-11	TRANSFORMER, BIAS OSCILLATION						9-911-844-XX	CUSHION				

Note:

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Note:

Note.
Les composants identifiés par une marque  sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

PANEL (including SW (A) / (B) / POWER SW/FL/HP/REC VOL/COVER/POWER TRANSFORMER/DOLBY/PJ)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
< CAPACITOR >				< CONNECTOR >			
C71	1-124-126-00	ELECT	47uF 20% 10V	CN73	* 1-564-708-11	PIN, CONNECTOR (SMALL TYPE) 6P	
C72	1-124-126-00	ELECT	47uF 20% 10V	CN74	* 1-564-705-11	PIN, CONNECTOR (SMALL TYPE) 3P	
C73	1-124-126-00	ELECT	47uF 20% 10V	CN75	1-506-468-11	CONNECTOR 3P, MALE	
C74	1-124-126-00	ELECT	47uF 20% 10V	CN76	1-564-722-11	PIN, CONNECTOR (SMALL TYPE) 6P	
C75	1-124-903-11	ELECT	1uF 20% 50V	CN563	* 1-564-705-11	PIN, CONNECTOR (SMALL TYPE) 3P	
C171	1-126-157-11	ELECT	10uF 20% 16V	CN572	1-691-909-11	SOCKET, CONNECTOR 8P	
C172	1-162-288-31	CERAMIC	330PF 10% 50V	CNP71	* 1-691-914-11	CONNECTOR, BOARD TO BOARD 15P	
C271	1-126-157-11	ELECT	10uF 20% 16V	CNP72	* 1-691-914-11	CONNECTOR, BOARD TO BOARD 15P	
C272	1-162-288-31	CERAMIC	330PF 10% 50V	CNP73	* 1-691-469-11	CONNECTOR (PC BOARD) (PLUG) 5P	
C371	1-124-927-11	ELECT	4.7uF 20% 100V	CNP74	* 1-691-007-11	CONNECTOR (PC BOARD) (PLUG) 4P	
C372	1-124-927-11	ELECT	4.7uF 20% 100V	CNP76	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE)	
C373	1-161-375-00	CERAMIC	0.0022uF 20% 50V	< DIODE >			
C375	1-124-927-11	ELECT	4.7uF 20% 100V	D71	8-719-987-63	DIODE 1N4148M	
C376	1-136-171-00	FILM	0.33uF 5% 50V	D72	8-719-987-63	DIODE 1N4148M	
C377	1-136-174-00	FILM	0.56uF 5% 50V	D73	8-719-933-54	DIODE HZS9A2L	
C378	1-130-475-00	MYLAR	0.0022uF 5% 50V	D74	8-719-987-63	DIODE 1N4148M	
C379	1-130-475-00	MYLAR	0.0022uF 5% 50V	D75	8-719-987-63	DIODE 1N4148M	
C380	1-124-768-11	ELECT	4.7uF 20% 50V	D76	8-719-933-54	DIODE HZS9A2L	
C381	1-124-927-11	ELECT	4.7uF 20% 100V	D901	8-719-301-39	DIODE SEL2210S	
C382	1-136-171-00	FILM	0.33uF 5% 50V	< IC >			
C383	1-136-174-00	FILM	0.56uF 5% 50V	IC71	8-759-634-51	IC M5218AP	
C384	1-130-475-00	MYLAR	0.0022uF 5% 50V	IC72	8-752-059-55	IC CXA1331S	
C385	1-130-475-00	MYLAR	0.0022uF 5% 50V	IC73	8-752-059-55	IC CXA1331S	
C386	1-124-768-11	ELECT	4.7uF 20% 50V	IC74	8-759-000-49	IC uPD4066BC	
C471	1-124-927-11	ELECT	4.7uF 20% 100V	IC75	8-759-000-49	IC uPD4066BC	
C472	1-124-927-11	ELECT	4.7uF 20% 100V	IC76	8-759-000-49	IC uPD4066BC	
C473	1-161-375-00	CERAMIC	0.0022uF 20% 50V	IC507	8-759-634-50	IC M5218AL	
C475	1-124-927-11	ELECT	4.7uF 20% 100V	IC901	8-759-323-40	IC HD614023SA85	
C476	1-136-171-00	FILM	0.33uF 5% 50V	IC902	8-741-100-48	IC SBX1610-59	
C477	1-136-174-00	FILM	0.56uF 5% 50V	< JACK >			
C478	1-130-475-00	MYLAR	0.0022uF 5% 50V	J501	1-507-796-71	JACK (PHONES)	
C479	1-130-475-00	MYLAR	0.0022uF 5% 50V	< FILTER >			
C480	1-124-768-11	ELECT	4.7uF 20% 50V	LPF371	1-236-147-11	FILTER, LOW PASS	
C481	1-124-927-11	ELECT	4.7uF 20% 100V	LPF471	1-236-147-11	FILTER, LOW PASS	
C482	1-136-171-00	FILM	0.33uF 5% 50V	< TRANSISTOR >			
C483	1-136-174-00	FILM	0.56uF 5% 50V	Q71	8-729-900-65	TRANSISTOR DTA144ES	
C484	1-130-475-00	MYLAR	0.0022uF 5% 50V	Q72	8-729-900-65	TRANSISTOR DTA144ES	
C485	1-130-475-00	MYLAR	0.0022uF 5% 50V	Q73	8-729-900-65	TRANSISTOR DTA144ES	
C486	1-124-768-11	ELECT	4.7uF 20% 50V	Q74	8-729-900-80	TRANSISTOR DTC114ES	
C571	1-126-157-11	ELECT	10uF 20% 16V	Q75	8-729-900-65	TRANSISTOR DTA144ES	
C572	1-126-157-11	ELECT	10uF 20% 16V	Q76	8-729-900-65	TRANSISTOR DTA144ES	
C808	1-164-159-11	CERAMIC	0.1uF 50V	Q77	8-729-900-80	TRANSISTOR DTC114ES	
C809	1-164-159-11	CERAMIC	0.1uF 50V	Q78	8-729-900-65	TRANSISTOR DTA144ES	
C810	1-124-927-11	ELECT	4.7uF 20% 100V	Q79	8-729-900-89	TRANSISTOR DTC114ES	
C899	1-164-159-11	CERAMIC	0.1uF 50V	Q80	8-729-900-65	TRANSISTOR DTA144ES	
C901	1-161-494-00	CERAMIC	0.022uF 25V	Q81	8-729-900-89	TRANSISTOR DTC144ES	
C902	1-164-159-11	CERAMIC	0.1uF 50V	Q82	8-729-900-65	TRANSISTOR DTA144ES	
C903	1-124-443-00	ELECT	100uF 20% 10V				
C904	1-161-375-00	CERAMIC	0.0022uF 20% 50V				
C905	1-161-375-00	CERAMIC	0.0022uF 20% 50V				
C999	1-164-159-11	CERAMIC	0.1uF 50V				

PANEL (including SW (A) / (B) /POWER SW/FL/HP/REC VOL/COVER/POWER TRANSFORMER/DOLBY/PJ)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
Q83	8-729-900-89	TRANSISTOR DTC144ES		R482	1-247-864-11	CARBON 24K 5% 1/4W	
Q371	8-729-900-80	TRANSISTOR DTC114ES		R483	1-249-441-11	CARBON 100K 5% 1/4W	
Q471	8-729-900-80	TRANSISTOR DTC114ES		R484	1-249-414-11	CARBON 560 5% 1/4W	
				R485	1-247-864-11	CARBON 24K 5% 1/4W	
Q901	8-729-900-61	TRANSISTOR DTA114ES					
Q902	8-729-900-61	TRANSISTOR DTA114ES		R486	1-249-441-11	CARBON 100K 5% 1/4W	
Q903	8-729-620-05	TRANSISTOR 2SC2603-EF		R491	1-249-437-11	CARBON 47K 5% 1/4W	
		< RESISTOR >		R525	1-247-842-11	CARBON 3K 5% 1/4W	
				R545	1-247-842-11	CARBON 3K 5% 1/4W	
R71	1-249-425-11	CARBON 4.7K 5% 1/4W		R830	1-249-410-11	CARBON 270 5% 1/4W	
R72	1-215-455-00	METAL 27K 1% 1/6W					
R73	1-249-417-11	CARBON 1K 5% 1/4W		R901	1-249-411-11	CARBON 330 5% 1/4W	
R74	1-215-455-00	METAL 27K 1% 1/6W		R902	1-249-433-11	CARBON 22K 5% 1/4W	
R75	1-249-417-11	CARBON 1K 5% 1/4W		R903	1-249-433-11	CARBON 22K 5% 1/4W	
				R904	1-249-417-11	CARBON 1K 5% 1/4W	
R76	1-249-433-11	CARBON 22K 5% 1/4W		R905	1-247-903-00	CARBON 1M 5% 1/4W	
R77	1-249-429-11	CARBON 10K 5% 1/4W					
R78	1-249-433-11	CARBON 22K 5% 1/4W		R906	1-249-441-11	CARBON 100K 5% 1/4W	
R79	1-249-433-11	CARBON 22K 5% 1/4W		R907	1-249-441-11	CARBON 100K 5% 1/4W	
R80	1-249-429-11	CARBON 10K 5% 1/4W		R908	1-249-441-11	CARBON 100K 5% 1/4W	
				R951	1-249-407-11	CARBON 150 5% 1/4W	
R81	1-249-433-11	CARBON 22K 5% 1/4W		R952	1-249-409-11	CARBON 220 5% 1/4W	
R82	1-249-435-11	CARBON 33K 5% 1/4W					
R83	1-249-435-11	CARBON 33K 5% 1/4W		R953	1-249-411-11	CARBON 330 5% 1/4W	
R84	1-249-435-11	CARBON 33K 5% 1/4W		R954	1-249-421-11	CARBON 2.2K 5% 1/4W	
R001	1-249-673-11	CARBON 1K 5% 1/2W		R955	1-249-420-11	CARBON 1.8K 5% 1/4W	
				R961	1-249-407-11	CARBON 150 5% 1/4W	
R002	1-249-417-11	CARBON 1K 5% 1/4W		R962	1-249-422-11	CARBON 2.7K 5% 1/4W	
R171	1-249-432-11	CARBON 18K 5% 1/4W					
R172	1-249-421-11	CARBON 2.2K 5% 1/4W		R963	1-249-420-11	CARBON 1.8K 5% 1/4W	
R173	1-249-432-11	CARBON 18K 5% 1/4W		R968	1-249-405-11	CARBON 100 5% 1/4W	
R174	1-249-409-11	CARBON 220 5% 1/4W		R969	1-249-405-11	CARBON 100 5% 1/4W	
				R970	1-249-405-11	CARBON 100 5% 1/4W	
R271	1-249-432-11	CARBON 18K 5% 1/4W		R971	1-249-407-11	CARBON 150 5% 1/4W	
R272	1-249-421-11	CARBON 2.2K 5% 1/4W					
R273	1-249-432-11	CARBON 18K 5% 1/4W		R972	1-249-409-11	CARBON 220 5% 1/4W	
R274	1-249-409-11	CARBON 220 5% 1/4W		R973	1-249-411-11	CARBON 330 5% 1/4W	
R372	1-249-441-11	CARBON 100K 5% 1/4W		R974	1-249-413-11	CARBON 470 5% 1/4W	
				R975	1-249-415-11	CARBON 680 5% 1/4W	
R373	1-249-435-11	CARBON 33K 5% 1/4W		R976	1-249-417-11	CARBON 1K 5% 1/4W	
R374	1-249-432-11	CARBON 18K 5% 1/4W					
R375	1-249-423-11	CARBON 3.3K 5% 1/4W		R977	1-249-420-11	CARBON 1.8K 5% 1/4W	
R376	1-249-441-11	CARBON 100K 5% 1/4W		R978	1-249-424-11	CARBON 3.9K 5% 1/4W	
R377	1-249-428-11	CARBON 8.2K 5% 1/4W		R981	1-249-407-11	CARBON 150 5% 1/4W	
				R982	1-249-409-11	CARBON 220 5% 1/4W	
R379	1-249-441-11	CARBON 100K 5% 1/4W		R983	1-249-411-11	CARBON 330 5% 1/4W	
R381	1-249-414-11	CARBON 560 5% 1/4W					
R382	1-247-864-11	CARBON 24K 5% 1/4W		R984	1-249-413-11	CARBON 470 5% 1/4W	
R383	1-249-441-11	CARBON 100K 5% 1/4W		R985	1-249-415-11	CARBON 680 5% 1/4W	
R384	1-249-414-11	CARBON 560 5% 1/4W		R986	1-249-417-11	CARBON 1K 5% 1/4W	
				R987	1-249-420-11	CARBON 1.8K 5% 1/4W	
R385	1-247-864-11	CARBON 24K 5% 1/4W		R988	1-249-424-11	CARBON 3.9K 5% 1/4W	
R386	1-249-441-11	CARBON 100K 5% 1/4W					
R391	1-249-437-11	CARBON 47K 5% 1/4W		R991	1-249-407-11	CARBON 150 5% 1/4W	
R472	1-249-441-11	CARBON 100K 5% 1/4W		R992	1-249-409-11	CARBON 220 5% 1/4W	
R473	1-249-435-11	CARBON 33K 5% 1/4W		R993	1-249-411-11	CARBON 330 5% 1/4W	
				R994	1-249-413-11	CARBON 470 5% 1/4W	
R474	1-249-432-11	CARBON 18K 5% 1/4W		R995	1-249-415-11	CARBON 680 5% 1/4W	
R475	1-249-423-11	CARBON 3.3K 5% 1/4W					
R476	1-249-441-11	CARBON 100K 5% 1/4W		R996	1-249-417-11	CARBON 1K 5% 1/4W	
R477	1-249-428-11	CARBON 8.2K 5% 1/4W		R997	1-249-420-11	CARBON 1.8K 5% 1/4W	
R479	1-249-441-11	CARBON 100K 5% 1/4W		R998	1-249-424-11	CARBON 3.9K 5% 1/4W	
R481	1-249-414-11	CARBON 560 5% 1/4W					

PANEL (including SW (A) / (B) / POWER SW/FL/HP/REC VOL/COVER/POWER TRANSFORMER/DOLBY/PJ)

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
< VARIABLE RESISTOR >				* 1-632-741-11 REEL MOTOR BOARD *****			
RV71	1-241-898-11	RES, VAR, CARBON 10K/10K (DUBBING LEVEL)		< CAPACITOR >			
RV521	1-241-895-11	RES, VAR, CARBON 5K (BIAS A)		C1051	1-124-907-11	ELECT 10uF 20% 50V	
RV541	1-241-895-11	RES, VAR, CARBON 5K (BIAS B)		C1052	1-124-907-11	ELECT 10uF 20% 50V	
RV561	1-238-908-11	RES, VAR, CARBON 20K/50K/50K (REC LEVEL)		C1053	1-164-159-11	CERAMIC 0.1uF 50V	
RV562	1-241-897-11	RES, VAR, CARBON 50K/50K (BALANCE)		< CONNECTOR >			
RV571	1-238-085-11	REA, VAR, CARBON 20K/20K (LEVEL PHONES)		CN1051	1-564-501-11	PIN, CONNECTOR 8P	
< SWITCH >				CN1052 *	1-564-720-11	PIN, CONNECTOR (SMALL TYPE) 4P	
S599	1-554-118-00	SWITCH, PUSH (1 KEY) (MPX FILTER)		CN1053 *	1-564-718-11	PIN, CONNECTOR (SMALL TYPE) 2P	
S901	1-554-118-00	SWITCH, PUSH (1 KEY) (POWER)		< RESISTOR >			
S902	1-554-118-00	SWITCH, PUSH (1 KEY) (TAPE SPEED)		R1051	1-249-414-11	CARBON 560 5% 1/4W	
S951	1-554-303-21	SWITCH, TACTILE (BLANK SKIP)		*****			
S952	1-554-303-21	SWITCH, TACTILE (AUTO PAUSE)		MISCELLANEOUS *****			
S953	1-554-303-21	SWITCH, TACTILE (AUTO REC LEVEL)		T1	△1-450-446-11	TRANSFORMER, POWER (WR990)	
S954	1-554-303-21	SWITCH, TACTILE (FADER)		CNJ1	1-558-350-21	CORD (WITH CONNECTOR) (WR99ES:US, Canadian)	
S955	1-571-452-11	SWITCH, SLIDE (DECK B)		T1	△1-450-444-11	TRANSFORMER, POWER (WR99ES:US, Canadian)	
S961	1-571-452-11	SWITCH, SLIDE (TIMER)		T1	△1-450-445-11	TRANSFORMER, POWER (WR99ES:E)	
S962	1-571-452-11	SWITCH, SLIDE (DECK A)		VS1	△1-692-155-11	SELECTOR, POWER VOLTAGE (WR99ES:E)	
S971	1-554-303-21	SWITCH, TACTILE (A+B REC)		D1051	8-719-980-85	DIODE SLF325C	
S972	1-554-303-21	SWITCH, TACTILE (HIGH SPEED)		D1091	8-719-950-74	LED SLR314D	
S973	1-554-303-21	SWITCH, TACTILE (NORM SPEED)		Q1091	8-729-809-43	TRANSISTOR SPS-314B	
S974	1-554-303-21	SWITCH, TACTILE (RESET A)		S1001	1-466-525-11	ENCORDER, ROTARY	
S975	1-554-303-21	SWITCH, TACTILE (MEMORY A)		57	△1-551-188-XX	CORD, POWER (WR99ES:E)	
S976	1-554-303-21	SWITCH, TACTILE (RESET B)		57	△1-590-836-31	CORD, POWER (WR99ES:US, Canadian)	
S977	1-554-303-21	SWITCH, TACTILE (MEMORY B)		57	△1-555-795-00	CORD, POWER EULOPLUG (WR990)	
S978	1-571-452-11	SWITCH, SLIDE (DIR MODE)		60	△1-569-007-11	ADAPTER, CONVERSION 2P (WR99ES:E)	
S981	1-554-303-21	SWITCH, TACTILE (▲) A DECK		*****			
S982	1-554-303-21	SWITCH, TACTILE (■) A DECK					
S983	1-554-303-21	SWITCH, TACTILE (▷) A DECK					
S984	1-554-303-21	SWITCH, TACTILE (◁) A DECK					
S985	1-554-303-21	SWITCH, TACTILE () A DECK					
S986	1-554-303-21	SWITCH, TACTILE (○) A DECK					
S987	1-554-303-21	SWITCH, TACTILE (◀) B DECK					
S988	1-554-303-21	SWITCH, TACTILE (▶) B DECK					
S989	1-554-303-21	SWITCH, TACTILE (•) B DECK					
S991	1-554-303-21	SWITCH, TACTILE (▲) B DECK					
S992	1-554-303-21	SWITCH, TACTILE (■) B DECK					
S993	1-554-303-21	SWITCH, TACTILE (▷) B DECK					
S994	1-554-303-21	SWITCH, TACTILE (◁) B DECK					
S995	1-554-303-21	SWITCH, TACTILE () B DECK					
S996	1-554-303-21	SWITCH, TACTILE (○) B DECK					
S997	1-554-303-21	SWITCH, TACTILE (◀) A DECK					
S998	1-554-303-21	SWITCH, TACTILE (▶) A DECK					
S999	1-554-303-21	SWITCH, TACTILE (•) A DECK					
< FLUORESCENT INDICATOR >							
VFD901	1-519-594-11	INDICATOR TUBE, FLUORESCENT					
< VIBRATOR >							
X901	1-577-359-21	VIBRATOR, CERAMIC 4.19MHZ					

Note:
The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remarks</u>
ACCESSORIES & PACKING MATERIALS				HARDWARE LIST			
*****				*****			
1-465-369-11		COMMANDER, REMOTE (RM-J902) (WR99ES:E, WR990)		#1	7-682-548-09	SCREW +BVTT 3X8 (S)	
1-558-271-11		CORD, CONNECTION		#2	7-685-133-19	SCREW +BTP 2. 6X6 TYPE2 N-S	
1-558-271-11		CORD, CONNECTION		#3	7-682-547-04	SCREW +BVTT 3X6 (S)	
2-181-754-01		COVER, BATTERY (FOR RM-J902) (WR99ES:E WR990)		#4	7-685-870-01	SCREW +BVTT 3X5 (S)	
* 3-354-915-01		CUSHION (WR99ES)		#5	7-682-548-04	SCREW +BVTT 3X8 (S)	
* 3-354-913-01		CUSHION (WR990)		#6	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
* 3-354-919-41		INDIVIDUAL CARTON (WR99ES)		#7	7-621-849-00	SCREW (BV/RING)	
* 3-366-699-61		INDIVIDUAL CARTON (WR990)		#8	7-621-255-20	SCREW +BVTT 2X4 (S)	
3-677-503-00		SHEET (LARGE), PROTECTION		#9	7-621-770-67	SCREW +BVTT 2. 6X6 (S)	
		(WR99ES:US, Canadian)		#10	7-685-131-19	SCREW +BTP 2. 6X4 TYPE2 N-S	
3-704-366-01		SCREW (CASE) (M3X8)		#11	7-621-255-35	SCREW +BVTT 2X5 (S)	
3-754-915-11		MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, PORTUGUESE) (WR99ES:Canadian, E, WR990)		#12	7-685-534-19	SCREW +BTP 2. 6X8 (E)	
3-754-915-21		MANUAL, INSTRUCTION (ENGLISH) (WR99ES:US)					
3-754-915-41		MANUAL, INSTRUCTION (GERMAN, DUTCH, SWEDISH ITALIAN) (WR990)					
9-910-999-33		INSTRUCTION (WR99ES:US)					
