



SUPPLEMENTARY TUBE TEST DATA

FOR

DYNAMIC TRANS-CONDUCTANCE TUBE TESTER

MODEL 9-99

ENGINEERING DEPARTMENT

SUPP. August 1967

STARK ELECTRONIC INSTRUMENTS LIMITED

OFFICES AND PLANT

AJAX **ONTARIO**

LIST OF TUBES NOT INCLUDED ON THE ROLL CHART FOR THE STARK MODEL 9-99

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTE
0G3	-		1 2, 3, 4, 6,		5	D	75	-	Gas Tube No Filament
1A5	1.4	2		5	3, 4	A	75	7	
1A6	2.0	1		4	2, 5	A	75	6	Heptode
1A6	2.0	1		T. C.	4	A	35	6	Triode
1A7	1.4	2		5	4, 6	A	65	7	
1AB5	1.4	1	7	6	2, 3	B	35	8	
1B3	1.4	2	1, 3, 5, 8	-	TC	D	60	7	
1B4	2.0	1		T. C	2, 3	A	65	4	
1B5	2.0	1		5	2	A	60	6	Triode
1B5	2.0	1			3	A	65	6	Diode #1
1B5	2.0	1			4	A	65	6	Diode #2
1B7	1.4	2		5	4, 6	A	40	7	
1B8	1.4	2		5	3, 4	B	60	7	Pentode
1B8	1.4	2		T. C.	6	B	55	7	Triode
1B8	1.4	2			8	A	50	7	Diode
1C6	2.0	1		4	2, 3, 5	A	40	6	
1C7	2.0	2		5	4, 6	A	40	7	
1D5	2.0	2		T. C.	3, 4	A	60	7	
1D7	2.0	2		5	4, 6	A	40	7	
1DN5	1.4	1		6	2, 3	A	60	7	Pentode
1DN5	1.4	1			4	A	50	7	Diode
1E4	1.4	2		5	3	B	60	7	
1E5	2.0	2		T. C.	3, 4	A	65	7	
1E7	2.0	2		4	3	B	75	7	Pentode #1
1E7	2.0	2		5	6	B	75	7	Pentode #2
1F5	2.0	2		5	3, 4	B	60	7	
1F6	2.0	1		T. C.	2, 3	A	85	6	Pentode
1F6	2.0	1			4	A	50	6	Diode #1
1F6	2.0	1			5	A	50	6	Diode #2
1F7	2.0	2		T. C.	3, 6	A	85	7	Pentode
1F7	2.0	2			4	A	50	7	Diode #1
1F7	2.0	2			5	A	50	7	Diode #2
1G3	1.4	2	1, 3, 5, 8		T. C.	D	50	7	
1G4GT	1.4	7		5	3	D	40	2	
1G5	2.0	2		5	3, 4	D	25	7	Pentode
1H2	1.4	2	1, 4, 5, 6, 8,		T. C.	D	50	9	
1H6	2.0	2		6	3	A	60	7	Triode
1H6	2.0	2			4	A	65	7	Diode #1
1H6	2.0	2			5	A	65	7	Diode #2
1J3 *	1.4	2	1, 3, 5, 8		T. C.	D	80	7	

* Indicates Correction of Listing on Roll Chart
STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
1J5	2.0	2		5	3, 4	B	60	7	
1J6	2.0	2		4	3	A	45	7	Triode #1
1J6	2.0	2		5	6	A	45	7	Triode #2
1K3	1.4	2	1, 3, 5, 8		T.C.	D	50	7	
1M3	1.4	4	2	1	8	D	100	5	Indicator Only
1N2	1.4	2	1, 3, 4, 5, 6, 8, 9	-	T.C.	D	55	2	Diode
1X2	1.4	4	1, 2, 6, 8, 9		T.C.	D	60	5	
1N6	1.4	2		5	3, 4	B	80	7	Pentode
1N6	1.4	2			6	A	40	7	Diode
1P5	1.4	2		T.C.	3, 4	A	75	7	
1Q5	1.4	7		5	3, 4	D	25	2	Pentode
1Q6	1.4	5		2	7, 8	B	75	4	Pentode
1Q6	1.4	5			6	A	60	4	Diode
1SA6	1.4	2		4	6, 8	A	50	7	
1SB6	1.4	2		8	3, 4	A	60	7	Pentode
1SB6	1.4	2			5	A	60	7	Diode
1V5 *	1.4	5		2	7, 8	A	65	4	
1V6 *	1.4	7		5	6	A	40	4	Triode
1V6 *	1.4	7		3	1, 2	A	40	4	Pentode
1W4	1.4	7	4	6	2, 3	A	35	1	
1Z2	1.4	4	1, 2, 3, 6, 7		T.C.	D	55	5	
2A5	2.5	1		4	2, 3	B	65	6	
2A6	2.5	1		T.C.	2	A	30	6	Triode
2A6	2.5	1			3	A	50	6	Diode #1
2A6	2.5	1			4	A	50	6	Diode #2
2A7	2.5	1		T.C.	2, 3	A	75	7	Heptode
2A7	2.5	1		5	3, 4	A	25	7	Triode
2AV2	2.0	4		-	9	D	60	5	
2B6	2.5	1		4	3	B	60	7	Triode #1
2B6	2.5	1		5	2	C	70	7	Triode #2
2B7	2.5	1		T.C.	2, 3	B	75	7	Pentode
2B7	2.5	1			4	A	40	7	Diode #1
2B7	2.5	1			5	A	40	7	Diode #2
2BJ2	2.5	4	1, 2, 9, 6	-	TC	D	50	5	
2C4	2.5	1		3	5	D	25	7	
2DZ4	2.0	3	6, 7	2	1	B	40	4	
2E5	2.5	1	Eye Closes	3	2, 4	D	70	6	Quality Test
2E5	2.5	1	Eye Open	3	4	D	70	6	
2EA5	2.5	3	7	1	5, 6	B	60	4	
2EN5	2.5	3			2	B	35	4	Diode #1
2EN5	2.5	3			7	B	35	4	Diode #2
2ER5	2.5	3	7	2	5, 6	B	60	4	
2ES 5	2.5	3	7	2	5	B	60	4	
2EV5	2.5	3	7	1	5, 6	B	60	4	
2FH5	2.5	3	1	2	5	B	50	4	
2FQ5	2.5	3	7	2	5	B	65	4	
2FS5	2.5	4	2, 8,	1	5, 6	D	35	3	Pentode
2FV6	2.5	3		1	5, 6	B	60	4	
2FY5	2.5	3	7	2	5	B	60	4	
2GK5	2.5	3	1	2	5	B	50	4	

* Indicates Correction of Listing on Roll Chart
STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
2GU5	2.5	4	2	1	5, 6	D	30	3	Pentode
2GW5	2.5	3	2	6	1	C	60	4	
2V3	2.5	2			T.C.	D	60	7	
2X2	2.5	1			T.C.	E	40	4	
3A5	3.0	2	1	T.C.	3, 4	A	85	7	Pentode
3A6	3.0	2	1	5	6	A	85	7	Triode
3A8	3.0	2	1		8	A	80	7	Diode
3AJ8	3.0	4		2	1, 6	B	60	5	Heptode
3AJ8	3.0	4		9	8	B	60	5	Triode
3AW3	3.0	2	1, 3, 5		T.C.	D	60	7	
3B5	3.0	2	8	5	3, 4	B	50	7	
3BU6	3.0	3		1	7	B	80	4	Triode
3BU6	3.0	3			5	A	40	4	Diode #1
3BU6	3.0	3			6	A	40	4	Diode #2
3BX6	3.0	4	1	2	7, 8	B	60	5	
3C5	3.0	2	8	5	3, 4	B	50	7	
3CA3	3.0	7	1, 3, 4, 5, 6, 8,	-	T.C.	D	55	2	
3DK6	3.0	3		1	5, 8	B	65	4	
3DX4	3.0	4	6, 7,	2	1	C	40	3	
3DZ4	3.0	3	6, 7	2	1	B	40	4	
3DG4	3.0	1	2		5	B	40	3	Diode #1
3DG4	3.0	1	2		7	B	40	3	Diode #2
3EA5	3.0	3	7	1	5, 6	B	50	4	
3EH7	3.0	4	3	2	7, 8	B	50	5	
3EJ7	3.0	4	3	2	7, 8	B	50	5	
3ER5	3.0	3	7	2	5, 6	B	50	4	
3ES5	3.0	3	7	2	5	B	60	4	
3EV5	3.0	3	7	1	5, 6	B	60	4	
3F55	3	3	2	1	5, 8	B	85	4	
3FH5	3.0	3	1	2	5	B	50	4	
3FQ5	3.0	3	7	2	5	B	65	4	
3FY5	3.0	3	7	2	5	B	60	4	
3GK5	3.0	3	1	2	5	B	50	4	
3GS8	3.0	4		7	2, 3	B	65	5	Pentode #1
3GS8	3.0	4		7	2, 8	B	65	5	Pentode #2
3GW5	3.0	3	6	2	1	C	55	4	
3JC6	3.0	4	1	2	7, 8	B	45	5	
3JD6	3.0	4	1	2	7, 8	B	45	5	
4AV6	5.0	3		1	7	B	80	4	Triode
4AV6	5.0	3		-	5	A	50	4	Diode #1
4AV6	5.0	3			6	A	50	4	Diode #2
4BL8	5.0	4		2	3, 6	B	65	5	Pentode
4BL8	5.0	4		9	1	B	60	5	Triode
4BN4	5.0	3	6, 7	2	5	B	40	4	
4BN6	5.0	4		2	5, 7	D	55	3	Pentode, Set Line at 66 on scale.
4CM4	5.0	4	6, 7, 8, 9,	2	1	C	50	5	
4CS6	5.0	3	-	1	6	B	50	4	
4DE6	5.0	3	-	1	5, 6	B	55	4	
4DK6	5.0	3	-	1	5, 6	B	65	4	
4EH7	5.0	4	3	2	7, 8	B	50	5	
4EJ7	5.0	4	3	2	7, 8	B	50	5	
4ES8	5.0	4	-	2	1	B	45	5	Triode #1
4ES8	5.0	4	-	7	6	B	45	5	Triode #2

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
4EW6	5.0	3		1	5.6	B	65	4	
4FS7	5.0	4	3	2	8.9	B	60	5	Pentode
4FS7	5.0	4	3	6	7	B	55	5	Triode
4GK5	5.0	3	1	2	5	C	55	4	
4GM6	5.0	3		1	5.6	B	65	4	
4GS8	5.0	4		7	2.3	B	65	5	Pentode #1
4GS8	5.0	4		7	2.8	B	65	5	Pentode #2
4GZ5	5.0	4	5	2	6.7	D	25	3	Pentode
4HM6	5.0	5	3	2	7.8	D	30	4	Set line at 60 on scale
4HR8	5.0	4	2.7	9	1.6	B	75	5	
4HS8	5.0	4		7	2.8	B	45	5	Pentode #1
4HS8	5.0	4	-	7	2.3	B	45	5	Pentode #2
4HT6	5.0	5	3	2	7.8	D	30	4	Pentode Set line at 65 or 60
5AR4	5.0	2	1	-	4	B	40	8	Diode #1
5AR4	5.0	2	1	-	6	B	40	8	Diode #2
5AS8	5.0	4	-	2	1.9	B	50	5	Pentode
5AS8	5.0	4	-	-	6	C	25	5	Diode
5AT4	5.0	2			4	B	45	8	Diode #1
5AT4	5.0	2			6	B	45	8	Diode #2
5AX4	5.0	2	-	-	4	B	45	8	Diode #1
5AX4	5.0	2	-	-	6	B	45	8	Diode #2
5B8	5.0	4	-	2	3	B	65	5	Triode
5B8	5.0	4	-	6	8.9	B	50	5	Pentode
5BC3	5.0	1	2, 4, 6, 7, 8		5	B	45	3	Diode #1
5BC3	5.0	1	2, 4, 6, 7, 8		9	B	45	3	Diode #2
5BC8	5.0	4	-	2	1	B	50	5	Triode #1
5BC8	5.0	4	-	7	6	B	50	5	Triode #2
5BT8	5.0	4	-	8	6.7	B	55	5	Pentode
5BT8	5.0	4	-	-	1	A	30	5	Diode #1
5BT8	5.0	4	-	-	2	A	30	5	Diode #2
5BW8	5.0	4	-	6	8.9	B	65	5	Pentode
5BW8	5.0	4	-	-	1	A	40	5	Diode #1
5BW8	5.0	4	-	-	3	A	40	5	Diode #2
5CG4	5.0	2	-	-	4	B	45	8	Diode #1
5CG4	5.0	2	-	-	6	B	45	8	Diode #2
5CQ8	5.0	4	-	2	3.6	B	65	5	Pentode
5CQ8	5.0	4	-	9	1	B	60	5	Triode
5CR8	5.0	4	-	2	6.7	B	60	5	Pentode
5CR8	5.0	4	-	9	1	B	55	5	Triode
5CU4	5.0	2			4	B	45	8	Diode #1
5CU4	5.0	2			6	B	45	8	Diode #2
5DJ4	5.0	2	1, 4, 5, 8		3	B	40	7	Diode #1
5DJ4	5.0	2	1, 4, 5, 8		6	B	40	7	Diode #2
5EA8	5.0	4		2	3.6	B	60	5	Pentode
5EA8	5.0	4		9	1	B	55	5	Triode
5EH8	5.0	4	6	7	8.9	B	65	5	Pentode
5EH8	5.0	4	6	2	3	B	55	5	Triode
5ES8	5.0	4		2	1	B	45	5	Triode #1
5ES8	5.0	4		7	6	B	45	5	Triode #2

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
5EU8	5.0	4		7	1, 9	B	60	5	Pentode
5EU8	5.0	4		2	3	B	55	5	Triode
5EW6	5.0	3		1	5, 6	B	65	4	
5FG7	5.0	4	8	1	2	B	55	5	Triode
5FG7	5.0	4	8	2	6, 7	B	60	5	Pentode
5FV8	5.0	4		2	6, 7	B	60	5	Pentode
5FV8	5.0	4		1	2	B	65	5	Triode
5GH8	5.0	4	-	2	3, 6	B	50	5	Pentode
5GH8	5.0	4	-	9	1	B	60	5	Triode
5GM6	5.0	3	-	1	5, 6	B	60	4	
5GX6	5.0	3		1	5, 6	B	60	4	
5HG8	5	4	1	6	7	B	45	5	Triode Section
5HG8	5	4	1	2	8, 9	B	50	5	Pentode Section
5X3	5.0	1			2	B	45	4	Diode #1
5X3	5.0	1			3	B	45	4	Diode #2
5X8 *	5.0	4		2	3	B	55	5	Triode
5X8 *	5.0	4		7	8, 9	B	65	5	Pentode
6A4	6.3	1		3	2, 4	B	54	5	
6A5	6.3	2	8	5	3	B	55	7	
6A6	6.3	1		3	2	B	75	7	Triode #1
6A6	6.3	1		5	6	B	75	7	Triode #2
6A7	6.3	1		T.C	2, 3	A	75	7	Pentode
6A7	6.3	1		5	3, 4	A	25	7	Triode
6A8	6.3	2		T.C	3, 4	A	75	7	Pentode
6A8	6.3	2		5	4, 6	A	25	7	Triode
6AB6	6.3	2		5	3, 4	B	70	7	
6AC6	6.3	2		5	3, 4	C	70	7	
6AD5	6.3	2		5	3	B	50	7	
6AD6	6.3	2	Disregard		5	D	100	7	Eye Open
6AD6	6.3	2	Meter		3, 5	D	100	7	Right eye closed
6AD6	6.3	2	Reading		4, 5	D	100	7	Left eye closed
6AE5	6.3	2		5	3	B	60	7	
6AE6	6.3	2		5	3	B	50	7	Triode #1
6AE6	6.3	2		5	4	B	50	7	Triode #2
6AE7	6.3	2		4	3	B	50	7	Triode #1
6AE7	6.3	2		6	3	B	50	7	Triode #2
6AF3	6.3	4	1, 2, 3, 6, 7, 8		9	B	30	5	
6AF5	6.3	2		5	3	B	60	7	
6AH5	6.3	2		6	1, 4	B	50	7	
6AJ7	6.3	2		4	6, 8	B	60	7	
6AK4	6.3	3		1	8	A	40	6	
6AK7	6.3	2		4	6, 8	B	60	7	
6AL3	6.3	4			0	B	35	5	
6AL6	6.3	2		5	3, 4	C	70	7	
6AN6	6.3	1			2	B	50	7	Diode #1
6AN6	6.3	1			3	B	50	7	Diode #2
6AN6	6.3	1			4	B	50	7	Diode #3
6AN6	6.3	1			5	B	50	7	Diode #4
6AQ8	6.3	4		2	1	B	60	5	Triode #1
6AQ8	6.3	4		7	6	B	60	5	Triode #2
6AX6	6.3	2			3	B	35	7	Diode #1
6AX6	6.3	2			5	B	35	7	Diode #2
6AY3	6.3	4	1, 3, 6, 7, 8		2	B	35	5	

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6BA5	6.3	3		1	5,7	B	65	6	
6BF5 *	6.3	3	7	1	5,6	C	35	4	
6BH3	6.3	4	1,3,6,7,8		2	B	35	3	
6BL8	6.3	4		9	1	B	60	5	Triode
6BL8	6.3	4		2	3,6	B	65	5	Pentode
6BM8	6.3	4		1	9	B	60	5	Triode
6BM8	6.3	4		3	6,7	C	75	5	Pentode
6BN7	6.3	4		2	1	A	50	5	Triode #1
6BN7	6.3	4		7	9	B	40	5	Triode #2
6BQ5	6.3	4	1,6,8	2	7,9	C	70	5	
6BR5	6.3	4		1	7,9	D	100	5	Indicator
6BR7 *	6.3	3	1	6	5	B	60	4	
6BU4	6.3	2	3,4,6,8		5	B	30	7	
6BU8 *	6.3	4		7	2,8,9	C	60	5	Pentode #1
6BU8 *	6.3	4		7	2,3,6	C	60	5	Pentode #2
6BW4	6.3	4			1	B	40	5	Diode #1
6BW4	6.3	4			7	B	40	5	Diode #2
6BY7	6.3	4		2	7,8	B	60	5	
6BY8	6.3	4		1	7,8	B	60	5	Pentode
6BY8	6.3	4			6	B	50	5	Diode
6C7	6.3	1		T.C	2	B	85	7	Triode
6C7	6.3	1			4	A	45	7	Diode #1
6C7	6.3	1			5	A	45	7	Diode #2
6CA4	6.3	4	2,6,8,9		1	B	30	5	Diode #1
6CA4	6.3	4	2,6,8,9		7	B	30	5	Diode #2
6CA7	6.3	2		5	3,4	C	45	7	
6CD7	6.3	2		4	3,5	D	100	7	Shadow Test
6CD7	6.3	2		4	4,5	D	100	7	Shadow Test
6CJ3	6.3	4	7	-	2	D	15	5	Use NO adapter
6CK3	6.3	4	7	-	2	B	25	5	Use NO adapter
6CK4	6.3	2	1	3	5	B	40	7	
6CM4	6.3	4	6,7,8,9	2	1	C	50	5	
6CM5	6.3	2	1,3	5	4,TC	C	40	7	
6CQ4	6.3	7			5	B	35	8	
6CR4	6.3	7	3,4,6,9	1	5	B	35	8	
6CR5	6.3	4	1,2,8	3	7,TC	C	45	5	
6CU8 *	6.3	4	1	7	2,3	B	60	5	Pentode
6CU8 *	6.3	4	7	8	9	B	65	5	Triode
6CW5	6.3	4	1,6,8	2	7,9	C	75	5	
6CY7 *	6.3	4	2	3	1	B	60	5	Triode #1
6CY7 *	6.3	4	2	7	6	B	60	5	Triode #2
6D7	6.3	1		T.C.	2,3	B	85	7	
6DA4	6.3	7	1,2		5	B	35	8	
6DA5	6.3	4	3,6,8	1	7,9	D	100	5	Indicator only
6DA6	6.3	4		2	7,8	B	65	5	
6DB5 *	6.3	4	3,7,8	6	1,9	C	40	5	
6DC8	6.3	4		2	1,6	B	55	5	Pentode
6DC8	6.3	4			7	A	40	5	Diode #1
6DC8	6.3	4			8	A	40	5	Diode #2
6DE4	6.3	7	2		5	B	35	8	

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE		FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6DE7	*	6.3	4	3	2	1	B	55	5	Triode #1
6DE7	*	6.3	4	3	7	6	B	55	5	Triode #2
6DG7		6.3	4	1	2	7, 8	B	65	5	
6DJ8		6.3	4		2	1	B	60	5	Triode #1
6DJ8		6.3	4		7	6	B	60	5	Triode #2
6DK6		6.3	3		1	5, 6	B	65	4	
6DM4		6.3	7	1, 2, 4, 6		5	B	35	8	
6DN7		6.3	7		1	2	B	60	8	Triode #1
6DN7		6.3	7		4	5	B	60	8	Triode #2
6DQ4		6.3	7	2		5	B	30	8	
6DQ5		6.3	2	3, 4, 5	1	8, T.C	B	40	7	
6DQ6		6.3	2		5	4, TC	C	30	7	
6DR7		6.3	4	3	2	1	B	55	5	Triode #1
6DR7		6.3	4	3	7	6	B	55	5	Triode #2
6DS5		6.3	3	7	1	5, 6	B	55	4	
6DS8		6.3	4		9	8	D	30	5	Triode Section
6DS8		6.3	4		2	1, 6, 7	D	25	5	Heptode Section
6DT4		6.3	7	1		5	B	35	8	
6DT5		6.3	4	6, 8	3	1, 9	B	50	5	
6DT8		6.3	4		2	1	B	50	5	Triode #1
6DT8		6.3	4		7	6	B	50	5	Triode #2
6DW4		6.3	4	2	-	7	D	15	5	Use <u>NO</u> adapter
6DW5		6.3	4	6	3	1, 9	B	50	5	
6DX4		6.3	4	6, 7	2	1	C	40	3	
6DX8		6.3	5	6, 7, 8, 9,	1	2	B	55	4	Triode Section
6DX8		6.3	5	1, 2, 3,	8	6, 9	B	65	4	Pentode Section
6DY7		6.3	2		5	4, 6	C	60	7	Pentode #1
6DY7		6.3	2		1	3, 4	C	60	7	Pentode #2
6DZ4		6.3	3	6, 7	2	1	B	40	4	
6DZ7		6.3	2		1	3, 4	C	70	7	Pentode #1
6DZ7		6.3	2		5	4, 6	C	70	7	Pentode #2
6DZ8		6.3	4		3	6, 7	B	60	5	Pentode
6DZ8		6.3	4		1	9	B	55	5	Triode
6E6		6.3	1		3	2	B	75	7	Triode #1
6E6		6.3	1		5	6	B	75	7	Triode #2
6E7		6.3	1		T.C.	2, 3	B	75	7	
6E8		6.3	2		T.C.	4, 5	C	60	7	
6EA5		6.3	3	7	1	5, 6	B	60	4	
6EA7	*	6.3	7		1	2	B	50	8	Triode #1
6EA7	*	6.3	7		4	5	B	50	8	Triode #2
6EA8		6.3	4		2	3, 6	B	60	5	Pentode
6EA8		6.3	4		9	1	B	55	5	Triode
6EB5		6.3	3			2	B	35	4	Diode #1
6EB5		6.3	3			7	B	35	4	Diode #2
6EB8		6.3	4		7	8, 9	B	60	5	Pentode
6EB8		6.3	4		2	3	B	55	5	Triode
6EC7		6.3	4	1	2	7, 8	B	50	5	
6EF6		6.3	2		5	3, 4	B	55	7	
6EG6		6.3	3		1	6, 7	B	60	4	
6EH5		6.3	3	5	2	6, 7	B	55	4	
6EH7		6.3	4	3	2	7, 8	B	50	5	
6EH8		6.3	4	6	7	8, 9	B	60	5	Pentode
6EH8		6.3	4	6	2	3	B	55	5	Triode

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6EJ7	6.3	4	3	2	7.8	B	50	3	
6EM5	6.3	4	6, 8	3	1.9	B	45	5	
6EM7	6.3	7		1	2	B	30	8	Triode #1
6EM7	6.3	7		4	5	B	60	8	Triode #2
6EQ7	6.3	4		2	6.7	B	65	5	Pentode
6EQ7	6.3	4			8	A	40	5	Diode
6ER5	6.3	3	7	2	5.6	B	60	4	
6ES5	6.3	3	1	2	5	B	50	4	
6ES6	6.3	3		1	5.6	B	35	4	
6ES7	6.3	3		1	5.6	B	65	4	
6ES8	6.3	4		2	1	B	60	5	Triode #1
6ES8	6.3	4		7	6	B	60	5	Triode #2
6ET6	6.3	3		1	5.6	B	65	4	
6ET7	6.3	4		7	8.9	B	65	5	Pentode
6ET7	6.3	4			2	B	45	5	Diode #1
6ET7	6.3	4			3	B	45	5	Diode #2
6EU7	6.3	1		5	6	B	50	2	Triode #1
6EU7	6.3	1		8	7	B	50	2	Triode #2
6EU8	6.3	4		7	1.9	B	60	5	Pentode
6EU8	6.3	4		2	3	B	55	5	Triode
6EV5	6.3	3	7	1	5.6	B	60	4	
6EV7	6.3	4		2	1	B	60	4	Triode #1
6EV7	6.3	4		7	6	B	60	4	Triode #2
6EW6	6.3	3		1	5.6	B	65	4	
6EW7	6.3	4	3	2	1	B	30	5	Triode #1
6EW7	6.3	4	3	7	6	B	50	5	Triode #2
6EX6	6.3	2		5	8T C.	C	40	7	
6EY6	6.3	2		5	3, 4	C	75	7	
6EZ5	6.3	2		5	3, 4	B	60	7	
6EZ8	6.3	5		2	3	B	55	4	Triode #1
6EZ8	6.3	5		7	6	B	55	4	Triode #2
6EZ8	6.3	5		9	8	B	55	4	Triode #3
6F5	6.3	2		T.C.	4	B	65	7	
6F7	6.3	1		T.C.	2, 3	A	50	7	Pentode
6F7	6.3	1		5	4	B	80	7	Triode
6FA7	6.3	4		7	1.8, 9	B	65	5	Pentode
6FA7	6.3	4			3	A	40	5	Diode
6FD6	6.3	3		1	5.6	B	60	4	
6FD7	6.3	4	3	2	1	B	30	5	Triode #1
6FD7	6.3	4	3	7	6	B	50	5	Triode #2
6FE5	6.3	2		5	3, 4	B	50	7	
6FG5	6.3	3	2	1	5.6	B	60	4	
6FG6 *	6.3	4	2, 8	1	7.9	D	100	5	Indicator
(Shadow Test Only - Disregard Meter Reading)									
6FG7	6.3	4	3	1	2	B	55	5	Triode
6FG7	6.3	4	3	9	6.7	B	60	5	Pentode
6FH5	6.3	3	1	2	5	B	50	4	
6FH6	6.3	2		4	4, T C.	C	45	7	
6FH8	6.3	5		2	3	B	60	4	Triode
6FH8	6.3	5		6	1.7	B	65	4	Pentode #1
6FH8	6.3	5		6	7.8	B	65	4	Pentode #2

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6FH8	6.3	5		6	7, 9	B	65	4	Pentode #3
6FM8	6.3	4		8	9	B	65	5	Triode
6FM8	6.3	4			2	B	50	5	Diode #1
6FM8	6.3	4			6	B	50	5	Diode #2
6FQ5	6.3	3	7	2	5	B	65	4	
6FQ7	6.3	4		2	1	B	60	5	Triode #1
6FQ7	6.3	4		7	6	B	60	5	Triode #2
6FR7	6.3	4	3	2	1	B	30	5	Triode #1
6FR7	6.3	4	3	7	6	B	50	5	Triode #2
6FS5	6.3	3	2	1	5, 6	B	60	4	
6FV6	6.3	3		1	5, 6	B	60	4	
6FV8	6.3	4		9	6, 7	B	60	5	Pentode
6FV8	6.3	4		1	2	B	65	5	Triode
6FW5	6.3	2		1	5, 8	C	50	7	
6FW8	6.3	4		2	1	B	50	5	Triode #1
6FW8	6.3	4		7	6	B	50	5	Triode #2
6FY5	6.3	3	7	2	5	B	50	4	
6FY8 *	6.3	4		1	9	B	60	5	Triode
6FY8 *	6.3	4		3	6, 7	C	75	5	Pentode
6GB5	6.3	4	2, 6	3	1, 9	C	50	5	
6GC5	6.3	4	1, 2, 6	3	8, 9	B	35	5	
6GC6	6.3	2	4	5	8, T.C.	C	45	7	
6GE8	6.3	4		3	6	B	50	5	Triode
6GE8	6.3	4		8	1, 9	B	60	5	Pentode
6GF7	6.3	4	-	9	8	A	20	5	Triode Section
6GF7	6.3	4	-	2	6	A	15	5	Triode Section 2
6GH8	6.3	4		2	3, 6	B	50	5	Pentode
6GH8	6.3	4		9	1	B	60	5	Triode
6GJ5	6.3	4	6, 7, 8, 9	2	1, T.C.	C	70	5	
6GJ8	6.3	4		2	3, 6	B	60	5	Pentode
6GJ8	6.3	4		9	1	B	55	5	Triode
6GK5	6.3	3	1	2	5	B	50	4	
6GK6	6.3	5	3	2	7, 8	A	20	4	
6GM5	6.3	4		6	1, 9	C	50	5	
6GM6	6.3	3		1	5, 6	B	65	4	
6GN8	6.3	4		2	3	B	55	5	Triode
6GN8	6.3	4		7	8, 9	B	60	5	Pentode
6GL7	6.3	7	4, 5, 6	1	2	B	30	8	Triode #1
6GL7	6.3	7	1, 2, 3	4	5	B	85	8	Triode #2
6GS8	6.3	4		7	2, 3	B	65	5	Pentode #1
6GS8	6.3	4		7	2, 8	B	65	5	Pentode #2
6GT5	6.3	4	1, 2, 8	6	7, 9	C	40	5	
6GU5	6.3	4	2	1	5, 6	D	25	3	Pentode
6GV8	6.3	4	6, 7, 8, 9	2	1	D	35	5	Triode
6GV8	6.3	4	1, 2, 3	9	6, 7	C	40	5	Pentode
6GW8	6.3	4		1	9	B	50	5	Triode
6GW8	6.3	4		8	3, 6	B	60	5	Pentode
6GX6	6.3	3		1	5, 6	B	60	4	
6GY6	6.3	3		1	5, 6	B	65	4	
6GX7	6.3	4	-	2	6, 7	C	50	5	Pent. Section
6GX7	6.3	4	-	9	8	B	40	5	Triode Section

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6GY8	6.3	5		1	2	B	60	4	Triode #1
6GY8	6.3	5		3	9	B	60	4	Triode #2
6GY8	6.3	5			6	D	30	4	Triode #3
6H4	6.3	2			4	B	45	7	
6HA6	6.3	5	6, 9	2	7, 8	B	40	4	
6HB6	6.3	4	3, 6	2	7, 8	B	50	5	
6HC8	6.3	4		1	9	B	50	5	Triode
6HC8	6.3	4		3	6, 7	B	60	5	Pentode
6HF8	6.3	4		2	3	B	50	5	Triode
6HF8	6.3	4		7	8, 9	B	60	5	Pentode
6HG8	6.3	4		2	8, 9	B	60	5	Pentode
6HG8	6.3	4		6	7	B	50	5	Triode
6HJ8	6.3	4		2	3, 6	B	60	5	Pentode
6HJ8	6.3	4			8	B	50	5	Diode
6HK5	6.3	3	7	1	5	A	25	4	
6HL8	6.3	4	-	2	3, 6	B	50	5	Pentode Section
6HL8	6.3	4	-	9	1	B	45	5	Triode Section
6HM6	6.3	4	3, 6	2	7, 8	B	40	5	
6HQ5	6.3	3	7	1	5	B	40	4	
6HR6	6.3	4		1	5, 6	C	80	3	Pentode
6HS6	6.3	3		1	5, 6	B	65	4	
6HS8	6.3	4		7	2, 3	B	60	5	Pentode #1
6HS8	6.3	4		7	2, 8	B	60	5	Pentode #2
6HZ6	6.3	3		1	5, 6	B	60	4	
6HZ8	6.3	4		2	3	B	50	5	Triode
6HZ8	6.3	4		7	8, 9	B	60	5	Pentode
6JC6	6.3	4	1	2	7, 8	B	45	5	
6JC8	6.3	4		2	3, 6	B	60	5	Pentode
6JC8	6.3	4		8	9	B	55	5	Triode
6JD6	6.3	4	1	2	7, 8	B	45	5	
6JE8	6.3	4		2	3	B	55	5	Triode
6JE8	6.3	4		7	8, 9	B	60	5	Pentode
6JH6	6.3	3		1	5, 6	B	55	4	
6JH8	6.3	5		6	3, 8, 9	D	30	4	Sheet Beam Tube
6JT6	6.3	4	1	2	7, 9	B	35	5	Use NO adapter
6JT8	6.3	4	6, 7, 8, 9	2	3	D	50	5	Triode
6JT8	6.3	4	1, 2, 3	7	8, 9	C	45	5	Pentode
6JU6	6.3	4	6, 7	2	1, TC	E	35	5	Use NO adapter
6JX8	6.3	4	1, 2, 6, 7	9	8	B	70	5	Triode
6JX8	6.3	4	8, 9	2	1, 6, 7	B	45	5	Heptode
6K5	6.3	2		T.C	3	B	65	7	
6KA8	6.3	4	6, 7, 8, 9	2	1	D	35	5	Triode
6KA8	6.3	4	1, 2	6	8, 9	C	75	5	Pentode
6KD8	6.3	4	2, 3, 6, 7	9	1	C	75	5	Triode
6KD8	6.3	4	1, 8, 9	2	3, 6	D	25	5	Pentode
6KE8	6.3	4		2	3, 6	B	50	5	Pentode Section
6KE8	6.3	4		9	1	B	55	5	Triode Section
6KL8	6.3	4	-	-	8	A	40	5	Diode Section
6KL8	6.3	4	-	2	6, 7	B	65	5	Pentode Section
6KM8	6.3	4			3	A	40	5	Diode
6KM8	6.3	4		7	1, 8	B	50	5	Tetrode #1
6KM8	6.3	4		7	2, 8	B	50	5	Tetrode #2
6KM8	6.3	4		7	9, 8	B	50	5	Tetrode #3

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6KR8	6.3	4	-	2	3	B	45	5	Triode Section
6KR8	6.3	4	-	7	8, 9	B	35	5	Pentode Section
6KT8	6.3	4		2	3	B	45	5	Triode Section
6KT8	6.3	4		7	8, 9	B	45	5	Pentode Section
6KU8	6.3	5	1, 2, 3, 6	7	8, 9	A	15	4	Pentode Section
6KU8	6.3	5	6, 7, 8, 9		3	A	35	4	Diode #1
6KU8	6.3	5	6, 7, 8, 9		2	A	35	4	Diode #2
6KV8	6.3	4		7	8, 9	B	40	5	Pentode
6KV8	6.3	4		2	3	B	60	5	Triode
6KW6	6.3	4	8	1	3, 6	B	35	5	Use NO adapter
6LC8	6.3	4	-	2	1	B	50	5	Triode Section
6LC8	6.3	4	-	6	8, 9	B	45	5	Pentode Section
6LF8	6.3	4	-	2	3	B	70	5	Triode Section
6LF8	6.3	4	-	7	8, 9	B	40	5	Pentode Section
6LQ8	6.3	4	-	2	3	B	40	5	Triode Section
6LQ8	6.3	4	-	7	8, 9	B	40	5	Pentode Section
6M3	6.3	2	1, 3, 7		5	B	35	3	
6P7	6.3	2		T.C.	4, 5	A	50	3	Pentode
6P7	6.3	2		7	6	B	80	3	Triode
6P8	6.3	2		T.C.	3, 4	B	50	7	Pentode
6P8	6.3	2		5	6	B	60	7	Triode
6Q6	6.3	2		T.C.	3	B	80	7	Triode
6Q6	6.3	2			4	A	50	7	Diode
6Q6	6.3	2			5	A	50	7	Diode
6R3	6.3	4	1, 2, 3, 6, 7, 8		9	D	40	5	
6R6	6.3	2		T.C.	3, 5	C	50	7	
6R7	6.3	2		T.C.	3	B	80	7	Triode
6R7	6.3	2			4	A	40	7	Diode #1
6R7	6.3	2			5	A	40	7	Diode #2
6SC7	6.3	7		3	2	A	30	8	Triode #1
6SC7	6.3	7		4	5	A	30	8	Triode #2
6SG7	6.3	2	3	4	6, 8	B	60	7	
6SH7	6.3	2	3	4	6, 8	B	50	7	
6SZ7	6.3	7		2	6	B	75	8	Triode
6SZ7	6.3	7			4	A	50	8	Diode #1
6SZ7	6.3	7			5	A	50	8	Diode #2
6T5	6.3	1	Eye Closed	3	2, 4	D	75	6	Quality Test
6T5	6.3	1	Eye Closed	3	4	D	75	6	
6T7	6.3	2		T.C.	3	A	30	7	Triode
6T7	6.3	2			4	A	45	7	Diode #1
6T7	6.3	2			5	A	45	7	Diode #2
6V7	6.3	2		T.C.	3	B	85	7	Triode
6V7	6.3	2			4	A	50	7	Diode #1
6V7	6.3	2			5	A	50	7	Diode #2
6W5	6.3	2			3	B	35	7	Diode #1
6W5	6.3	2			5	B	35	7	Diode #2
6W7	6.3	2		T.C.	3, 4	A	30	7	
6Y3	6.3	2	8		T.C.	D	50	7	
6Y7	6.3	2		4	3	B	80	7	Triode #1
6Y7	6.3	2		5	6	B	80	7	Triode #2
6Z7	6.3	2		4	3	B	80	7	Triode #1
6Z7	6.3	2		5	6	B	80	7	Triode #2
7AB7	6.3	1	4, 6	5	1, 3	B	60	8	
7AJ7	6.3	1		6	2, 3	B	60	8	

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
7B8 *	6.3	1		4	3.5	B	65	8	Osc. Section
7B8 *	6.3	1		6	2.5	A	50	8	Pentode Section
7DJ8	6.3	4		2	1	B	60	5	Triode #1
7DJ8	6.3	4		7	6	B	60	5	Triode #2
7ED7	6.3	4	1, 6	2	7, 8	B	50	5	
7ES8	7.5	4		2	1	C	40	5	Triode #1
7ES8	7.5	4		7	6	C	40	5	Triode #2
7EY6	7.5	2		5	3, 4	C	75	7	
7G8	6.3	1		4	2, 3	B	50	8	Pentode #1
7G8	6.3	1		5	3, 7	B	50	8	Pentode #2
7HG8	7.5	4	1	2	8, 9	B	45	5	Pentode Section
7HG8	7.5	4	-	6	7	B	40	5	Triode Section
7T7	6.3	1		6	2, 3	B	60	8	
8A8	7.5	4		2	3, 6	B	60	5	Pentode
8A8	7.5	4		5	1	B	55	5	Triode
8B8	7.5	4		1	9	D	60	5	Triode Section
8B8	7.5	4		3	6, 7	B	40	5	Pentode Section
8BQ5	7.5	4	1, 6, 8	2	7, 9	C	75	5	
8CY7	7.5	4	2	3	1	B	60	5	Triode #1
8CY7	7.5	4	2	7	6	B	60	5	Triode #2
8DX8	7.5	4		8	6, 9	B	50	5	Pentode
8DX8	7.5	4		1	2	B	60	5	Triode
8EB8	7.5	4		2	3	B	55	5	Triode
8EB8	7.5	4		7	8, 9	B	60	5	Pentode
8EM5	7.5	4	6, 8	3	1, 9	B	45	5	
8ET7	7.5	4			2	A	40	5	Diode #1
8ET7	7.5	4			3	A	40	5	Diode #2
8ET7	7.5	4		7	8, 9	B	60	5	Pentode
8FQ7	7.5	4		2	1	B	60	5	Triode #1
8FQ7	7.5	4		7	6	B	60	5	Triode #2
8GJ7	7.5	4	3	9	8	B	40	5	Triode Section
8GJ7	7.5	4	3	2	6, 7	B	50	5	Pentode Section
8GN8	7.5	4		2	3	B	55	5	Triode
8GN8	7.5	4		7	8, 9	B	60	5	Pentode
8HA6	7.5	5	6, 9	2	7, 8	B	40	4	
8HG8	7.5	4		2	8, 9	B	60	5	Pentode
8HG8	7.5	4		6	7	B	50	5	Triode
8JE8	7.5	4		2	3	B	55	5	Triode
8JE8	7.5	4		7	8, 9	B	60	5	Pentode
8KA8	7.5	4	6, 7, 8, 9	2	1	D	35	5	Triode
8KA8	7.5	4	1, 2	6	8, 9	C	75	5	Pentode
8KS8	7.5	4	-	2	3	B	55	5	Triode Section
8KS8	7.5	4	-	7	8, 9	B	40	5	Pentode Section
8LC8	7.5	4	-	2	1	B	50	5	Triode Section
8LC8	7.5	4	-	6	8, 9	B	45	5	Pentode Section
9A8	7.5	4		9	1	D	25	5	Triode Section
9A8	7.5	4		2	3, 6	D	30	5	Pentode Section
9AK8	7.5	4		8	9	B	65	5	Triode
9AK8	7.5	4			1	A	40	5	Diode #1
9AK8	7.5	4			2	A	40	5	Diode #2
9AK8	7.5	4			6	A	40	5	Diode #3

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
9AQ8	7.5	1	-	7	6	B	50	5	Triode No. 1
9AQ8	7.5	1	-	2	1	B	50	5	Triode No. 2
9BR7	7.5	4	9	2	1	B	60	5	Triode
9BR7	7.5	4	9		6	B	30	5	Diode #1
9BR7	7.5	4	9		7	B	30	5	Diode #2
9BR8	7.5	4		1	2	B	45	5	Triode
9BR8	7.5	4		9	6, 7	B	50	5	Pentode
9DZ8	7.5	4		3	6, 7	B	60	5	Pentode
9DZ8	7.5	4		1	9	B	55	5	Triode
9EF6	7.5	2		5	3, 4	C	75	7	
9JW8	12.6	4	2, 3, 6, 7	9	1	B	50	5	Triode
9JW8	12.6	4	1, 8, 9	2	3, 6	B	45	5	Pentode
9X8	7.5	4		2	3	B	55	5	Triode
9X8	7.5	4		7	8, 9	B	65	5	Pentode
10BQ5	12.6	4	1, 6, 8	2	7, 9	C	70	5	
10DE7 *	12.6	4	3	2	1	B	30	5	Triode #1
10DE7 *	12.6	4	3	7	6	B	50	5	Triode #2
10DR7	12.6	2		5	4, 6	C	60	7	Pentode #1
10DR7	12.6	2		1	3, 4	C	60	7	Pentode #2
10EB8	12.6	4		7	8, 9	B	60	5	Pentode
10EB8	12.6	4		2	3	B	55	5	Triode
10EG7	12.6	7		1	2	B	30	8	Triode #1
10EG7	12.6	7		4	5	B	50	8	Triode #2
10EM7	12.6	7		1	2	B	30	8	Triode #1
10EM7	12.6	7		4	5	B	60	8	Triode #2
10EW7	12.6	4	3	2	1	B	30	5	Triode #1
10EW7	12.6	4	3	7	6	B	50	5	Triode #2
10FD7	12.6	4	3	2	1	B	30	5	Triode #1
10FD7	12.6	4	3	7	6	B	50	5	Triode #2
10FR7	12.6	4	3	2	1	B	30	5	Triode #1
10FR7	12.6	4	3	7	6	B	50	5	Triode #2
10GK6	7.5	5	3	2	7, 8	A	20	4	
10GN8	12.6	4	-	2	3	B	60	5	Triode Section
10GN8	12.6	4	-	7	8, 9	B	40	5	Pentode Section
10HF8	12.6	4		2	3	B	50	5	Triode
10HF8	12.6	4		7	8, 9	B	60	5	Pentode
10JA8	12.5	4	1, 2, 3	7	8, 9	B	40	5	Tetrode
10JA8	12.5	4	6, 7, 8, 9	2	3	B	50	5	Triode
10JT8	12.6	4	-	2	3	B	60	5	Triode Section
10JT8	12.6	4	-	7	8, 9	B	45	5	Pentode Section
10JY8	12.6	4		2	3	C	60	5	Triode
10JY8	12.6	4		7	8, 9	C	55	5	Pentode
10KR8	12.6	4	-	2	3	B	45	5	Triode Section
10KR8	12.6	4	-	7	8, 9	B	35	5	Pentode Section
10KU8	7.5	5	1, 2, 3	7	8, 9	A	15	4	Pentode Section
10KU8	7.5	5	6, 7, 8, 9		3	A	35	4	Diode #1
10KU8	7.5	5	6, 7, 8, 9		2	A	35	4	Diode #2
11CY7 *	12.6	4	2	3	1	B	50	5	Triode #1
11CY7 *	12.6	4	2	7	6	B	50	5	Triode #2
11JE8	12.6	4		2	3	B	55	5	Triode
11JE8	12.6	4		7	8, 9	B	60	5	Pentode
12A5	12.6	1	6	4	2, 3	B	50	7	
12A6	12.6	2		5	3, 4	B	65	7	

★ Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
12B8	12.6	2		T.C.	3, 4	B	50	7	Pentode
12B8	12.6	2		8	5	B	50	7	Triode
12BR7 *	12.6	4	9	2	1	B	60	5	Triode
12BR7 *	12.6	4	9		6	B	30	5	Diode #1
12BR7 *	12.6	4	9		7	B	30	5	Diode #2
12BW4	12.6	4			1	B	40	5	Diode #1
12BW4	12.6	4			7	B	40	5	Diode #2
12BX4	12.6	4	1	2	7, 8	B	60	5	
12BZ6	12.6	3		1	5, 6	B	50	4	
12C8 *	12.6	2		T.C.	3, 6	A	50	7	Pentode
12C8 *	12.6	2			4	A	40	7	Diode #1
12C8 *	12.6	2			5	A	40	7	Diode #2
12CN5	12.6	3	5	2	6, 7	B	50	4	
12CK5	12.6	4	1, 2, 8	3	7, TC	B	40	5	
12CS7	12.6	4		3	1	B	50	5	Triode #1
12CS7	12.6	4		7	6	B	50	5	Triode #2
12CT8	12.6	4		2	1	B	50	5	Triode
12CT8	12.6	4		8	6, 7	B	60	5	Pentode
12CX6	12.6	3		1	5, 6	B	50	4	
12CY6	12.6	3		1	5, 6	B	65	4	
12DB5 *	12.6	4	3, 7, 8	6	1, 9	C	40	5	
12DF5	12.6	4	9		1	B	45	5	Diode #1
12DF5	12.6	4	9		6	B	45	5	Diode #2
12DF7	12.6	4	9	2	1	B	50	5	Triode #1
12DF7	12.6	4	9	7	6	B	50	5	Triode #2
12DJ8	12.6	4	6, 7, 8, 9	2	1	B	40	5	Triode #1
12DJ8	12.6	4	1, 2, 3, 9,	7	6	B	40	5	Triode #2
12DK5	12.6	4	6	2	7, 8	B	65	5	
12DK6	12.6	3		1	5, 6	B	55	4	
12DL8	12.6	4		3	6, 7	B	60	5	Tetrode
12DL8	12.6	4			1	A	50	5	Diode #1
12DL8	12.6	4			9	A	50	5	Diode #2
12DM5	12.6	3	5	2	6, 7	B	45	4	
12DM7	12.6	4	9	2	1	B	60	5	Triode #1
12DM7	12.6	4	9	7	6	B	60	5	Triode #2
12DQ4	12.6	7	2		5	B	30	8	
12DQ7	12.6	4	6, 9	2	7, 8	B	50	5	
12DS7	12.6	4		3	6, 7	B	60	5	Tetrode
12DS7	12.6	4			1	A	50	5	Diode #1
12DS7	12.6	4			9	A	50	5	Diode #2
12DT5	12.6	4	6, 8	3	1, 9	B	55	5	
12DT8	12.6	4		2	1	B	50	5	Triode #1
12DT8	12.6	4		7	6	B	50	5	Triode #2
12DU7	12.6	4	8	1	3, 6	B	60	5	Tetrode
12DU7	12.6	4	8		7	B	35	5	Diode #1
12DU7	12.6	4	8		9	B	35	5	Diode #2
12DV7	12.6	4	9		2	A	40	5	Diode #1
12DV7	12.6	4	9		3	A	40	5	Diode #2
12DV7	12.6	4	9	7	6	B	80	5	Triode
12DW5	12.6	4	6	3	1, 9	B	50	5	
12DW7	12.6	4	9	2	1	B	50	5	Triode #1
12DW7	12.6	4	9	7	6	B	50	5	Triode #2
12DW8	12.6	4		2	1	B	60	5	Triode #1
12DW8	12.6	4		7	6	B	60	5	Triode #2

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
12DW8	12.6	4			9	A	40	5	Diode
12DY8	12.6	4		1	3, 6	B	65	5	Pentode
12DY8	12.6	4		9	8	B	55	5	Triode
12DZ6	12.6	3		1	5, 6	B	60	4	
12DZ7	12.6	2		1	3, 4	B	50	7	Pentode #1
12DZ7	12.6	2		5	4, 6	B	50	7	Pentode #2
12DZ8	12.6	4		3	6, 7	B	60	5	Pentode
12DZ8	12.6	4		1	9	B	55	5	Triode
12E5	12.6	2		5	3	B	75	7	
12EA6	12.6	3		1	5, 6	B	60	4	
12EC8	12.6	4		1	2	B	50	5	Triode
12EC8	12.6	4		5	6, 7	B	60	5	Pentode
12ED5	12.6	3	5	2	6, 7	B	55	4	
12EF6	12.6	2		5	3, 4	C	75	7	
12EG6	12.6	3		1	6, 7	B	60	4	
12EH5	12.6	3	2	5	6, 7	C	75	4	
12EK6	12.6	3		1	5, 6	B	60	4	
12EL6	12.6	3		1	2	B	80	4	Triode
12EL6	12.6	3			5	A	50	4	Diode #1
12EL6	12.6	3			6	A	50	4	Diode #2
12EM5	12.6	4	6, 8	3	1, 9	B	45	5	
12EN6	12.6	2		5	3, 4	C	75	7	
12EQ7	12.6	4		2	6, 7	B	65	5	Pentode
12EQ7	12.6	4			8	A	40	5	Diode
12EZ6	12.6	3		1	5, 6	B	60	4	
12F5	12.6	2		T. C.	4	B	65	7	
12F8 *	12.6	4		8	2, 3	B	60	5	Pentode
12F8 *	12.6	4			6	B	40	5	Diode #1
12F8 *	12.6	4			1	B	40	5	Diode #2
12FA6	12.6	3		1	6	C	65	4	
12FB5	12.6	4	1, 6, 8	2	7, 9	B	35	5	
12FK6	12.6	3		1	7	B	70	4	Triode
12FK6	12.6	3			5	A	50	4	Diode #1
12FK6	12.6	3			6	A	50	4	Diode #2
12FM6	12.6	3		1	7	B	70	4	Triode
12FM6	12.6	3			5	A	50	4	Diode #1
12FM6	12.6	3			6	A	50	4	Diode #2
12FQ8	12.6	4		2	1	B	65	5	Triode #1
12FQ8	12.6	4		2	3	B	65	5	Triode #2
12FQ8	12.6	4		7	6	B	65	5	Triode #3
12FQ8	12.6	4		7	8	B	65	5	Triode #4
12FR8	12.6	4		3	6, 7	B	65	5	Pentode
12FR8	12.6	4		1	9	B	60	5	Triode
12FR8	12.6	4			8	A	50	5	Diode
12FT6	12.6	3		1	7	B	80	4	Triode
12FT6	12.6	3			5	A	40	4	Diode #1
12FT6	12.6	3			6	A	40	4	Diode #2
12FV7	12.6	4	6, 7, 8, 9	2	1	C	45	5	Triode #1
12FV7	12.6	4	1, 2, 3, 9	7	6	C	45	5	Triode #2
12FX5	12.6	3	5	2	6, 7	B	35	4	
12FX8	12.6	4		2	1, 3	B	65	5	Heptode
12FX8	12.6	4		6	8	B	60	5	Triode
12FY8 *	12.6	4		1	9	B	50	5	Triode
12FY8 *	12.6	4		3	6, 7	B	50	5	Pentode

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
12A7	12.6	1		T.C	2,3	B	75	7	Pentode
12A7	12.6	1			5	B	40	7	Diode
12AB6	12.6	3		1	5,6	B	50	4	
12AD5	12.6	4	7,8	2	1,6	B	40	5	
12AD6 *	12.6	3		1	6	B	40	4	Osc.
12AD6 *	12.6	3		6	5,7	A	60	4	Mixer
12AE7	12.6	4	9	2	1	B	65	5	Triode #1
12AE7	12.6	4	9	7	6	B	60	5	Triode #2
12AF3	12.6	4	1,2,3,6,7,8		9	B	35	5	
12AU8	12.6	4		2	3	B	50	5	Triode
12AU8	12.6	4		7	8,9	B	60	5	Pentode
12AX4 *	12.6	7			5	B	35	8	
12AX7	12.6	4	9	2	1	B	85	5	Triode #1
12AX7	12.6	4	9	7	6	B	85	5	Triode #2
12AY3	12.6	4	1,3,6,7,8		2	B	35	5	
12G4	12.6	3	1,2	6	5	D	30	4	Triode
12GA6	12.6	3		1	5,6	B	65	4	
12GC6	12.6	2	8	5	4,TC	C	60	7	
12GJ5	12.6	4	6,7,8,9	2	1,TC	C	70	5	
12GN7	12.6	4	6	2	3,7,8,9	B	35	5	Make no Leakage test
12GT5	12.6	4	1,2,8	6	7,9	C	40	5	
12GW6	12.6	2		5	4,T C.	C	50	7	
12J8	12.6	4		1	3,6	B	50	5	Tetrode
12J8	12.6	4			8	B	30	5	Diode #1
12J8	12.6	4			9	B	30	5	Diode #2
12JT6	12.6	4	1	2	7,9	B	35	5	Use NO adapter
12KL6	12.6	4	-	-	8	A	55	5	Diode Section
12KL6	12.6	4	-	2	6,7	B	55	5	Pentode Section
12L8	12.6	6		1	4,5	B	60	7	Pentode #1
12L8	12.6	6		3	5,8	B	60	7	Pentode #2
12SW7	12.6	7		2	6	B	65	8	Triode
12SW7	12.6	7			4	A	50	8	Diode #1
12SW7	12.6	7			5	A	50	8	Diode #2
12SX7	12.6	7		1	2	B	55	8	Triode #1
12SX7	12.6	7		4	5	B	55	8	Triode #2
12SY7	12.6	2		5	3,4	C	70	7	
13CM5	12.6	2	1,3	5	T.C.4	C	30	7	
13DE7 *	12.6	4	3	2	1	B	30	5	Triode #1
13DE7 *	12.6	4	3	7	6	B	50	5	Triode #2
13DR7	12.6	4	3	2	1	B	30	5	Triode #1
13DR7	12.6	4	3	7	6	B	50	5	Triode #2
13EC7	12.6	4	1	2	7,8	B	50	5	
13EM7	12.6	7		1	2	B	50	8	Triode #1
13EM7	12.6	7		4	5	B	50	8	Triode #2
13FD7	12.6	4	3	2	1	B	30	5	Triode #1
13FD7	12.6	4	3	7	6	B	50	5	Triode #2
13FR7	12.6	4	3	2	1	B	30	5	Triode #1
13FR7	12.6	4	3	7	6	B	50	5	Triode #2
13GB5	12.6	4	1,3,6	2	7,TC	B	35	5	Use NO adapter
13GC8	12.6	4		2	1	B	55	5	Triode
13GC8	12.6	4		9	6,8	B	65	5	Pentode

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
13GF7	12.6	1	-	9	8	A	30	5	Triode Sec. 1
13GF7	12.6	1	-	2	6	A	20	5	Triode Sec. 2 Use Stark NO adapter
14A4	12.6	1		6	2	B	65	8	
14A5	12.6	1		6	2, 3	B	40	8	
14DA7 *	12.6	4		3	1	B	30	5	Triode #1
14DA7 *	12.6	4		7	6	B	50	5	Triode #2
14E7	12.6	1		6	2, 5	A	45	8	Triode
14E7	12.6	1			3	A	100	8	Diode #1
14E7	12.6	1			4	A	100	8	Diode #2
14G6	12.6	4		2	1	B	50	5	Triode
14G6	12.6	4			6	A	40	5	Diode #1
14G6	12.6	4			8	A	40	5	Diode #2
14GT8	12.6	4		8	9	B	80	5	Triode
14GT8	12.6	4			2	A	50	5	Diode #1
14GT8	12.6	4			6	A	50	5	Diode #2
14GW8	12.6	4	3, 6, 7, 8	1	9	D	90	5	Triode
14GW8	12.6	4	1, 2, 9	8	3, 6	D	70	5	Pentode
14JG8	12.6	4		8	9	B	80	5	Triode
14JG8	12.6	4			2	A	40	5	Diode #1
14JG8	12.6	4			6	A	40	5	Diode #2
14Y7	12.6	4		2	1, 7	B	65	5	Pentode
14Y7	12.6	4		9	8	B	50	5	Triode
15A6	12.6	4	9	2	1, 7	B	45	5	
15DQ8	12.6	4		1	2	B	60	5	Triode
15DQ8	12.6	4		8	6, 9	B	50	5	Pentode
15EW6	12.6	3		1	5, 6	B	40	4	
15HB6	12.6	4	8	2	6, 7	C	60	5	3 & 9 Show short
16A5	12.6	4	1, 8	2	7, 9	B	50	5	
16A8	12.6	4		3	6, 7	B	55	5	Pentode
16A8	12.6	4		1	9	B	60	5	Triode
16AQ3	19	4	1, 3, 6, 8	-	9	B	25	5	Diode rectifier
17AY3	19.0	4	1, 3, 6, 7, 8		2	B	35	5	
17BH3	19.0	4	1, 3, 6, 7, 8		2	B	35	5	
17C8	19.0	4		2	1, 6	B	60	5	Pentode
17C8	19.0	4			7	A	40	5	Diode #1
17C8	19.0	4			8	A	40	5	Diode #2
17CU5	19.0	3	2	5	6, 7	C	40	4	
17D4	19.0	7	1, 2		5	B	35	8	
17DE4	19.0	7	2		5	B	40	8	
17DM4	19.0	7	1, 2, 4, 6		5	B	35	8	
17EW8	19.0	4		2	1	B	50	5	Triode #1
17EW8	19.0	4		7	6	B	50	5	Triode #2
17GJ5	19.0	4	6, 7, 8, 9	2	1, TC	C	70	5	
17GT5	19.0	4	1, 2, 8	6	7, 9	C	40	5	
17GW6	19.0	2		5	4, TC	C	50	7	
17H3	19.0	4			3	C	25	5	Rectifier Diode
17HC8	19.0	4		1	9	B	50	5	Triode
17HC8	19.0	4		3	6, 7	B	60	5	Pentode
17JB6	12.6	4	1, 2	6	7, TC	B	35	5	Use NO adapter
17KW6	19	4	8	1	3, 6	B	35	5	Use NO adapter

* Indicates Correction of Listing on Roll Chart

STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
18DZ8	19.0	4		3	6, 7	B	60	5	Pentode
18DZ8	19.0	4		1	9	B	55	5	Triode
18FW6	19.0	3		1	5, 6	B	60	4	
18FX6	19.0	3		1	6	C	65	4	
18FY6	19.0	3			5	A	50	4	Diode #1
18FY6	19.0	3			6	A	50	4	Diode #2
18FY6	19.0	3		1	7	B	65	4	Triode
18GD6	19.0	3		1	5, 6	B	60	4	
18GE6	19.0	3		1	7	B	65	4	Triode
18GE6	19.0	3			5	A	40	4	Diode #1
18GE6	19.0	3			6	A	40	4	Diode #2
18GV8	19.0	4	6, 7, 8, 9	2	1	B	40	5	Triode
18GV8	19.0	4	1, 2, 3	9	6, 7	B	35	5	Pentode
18HB8	19.0	4		9	6, 7	B	60	5	Pentode
18HB8	19.0	4		1	3	B	55	5	Triode
19	2.0	1		3	2	A	35	6	Triode #1
19	2.0	1		4	5	A	35	6	Triode #2
19CL8	19.0	4		1	2	B	60	5	Triode
19CL8	19.0	4		9	6, 7	B	65	5	Pentode
19CS4	19.0	7			5	B	35	8	
19D8	19.0	4		2	1, 6	B	65	5	Pentode
19D8	19.0	4		9	8	B	60	5	Triode
19DE7	19.0	4	3	2	1	B	30	5	Triode #1
19DE7	19.0	4	3	7	6	B	50	5	Triode #2
19EA8	19.0	4		2	3, 6	B	60	5	Pentode
19EA8	19.0	4		9	1	B	55	5	Triode
19EZ8	19.0	5		2	3	B	55	4	Triode #1
19EZ8	19.0	5		7	6	B	55	4	Triode #2
19EZ8	19.0	5		9	8	B	55	4	Triode #3
19HR6	19.0	3		1	5, 6	B	55	4	
19HS6	19.0	3		1	5, 6	B	50	4	
19HV8	19.0	4		1	2	B	50	5	Triode
19HV8	19.0	4		9	6, 7	B	60	5	Pentode
19JN8	20	4	6, 7, 8, 9,	1	2	B	45	5	Triode
19JN8	20	4	1, 2, 3	9	6, 7	B	50	5	Pentode
20EQ7	19.0	4		2	6, 7	B	65	5	Pentode
20EQ7	19.0	4			8	A	40	5	Diode
20EZ7	19.0	1	3	5	6	B	75	2	Triode #1
20EZ7	19.0	1	3	8	7	B	75	2	Triode #2
21A6	25	4	9	2	8, TC	B	50	5	
21EX6	25	2		5	8, TC	C	40	7	
22	3.0	1		T. C.	2, 3	A	100	4	
22BH3	25	4	1, 3, 6, 7, 8		2	B	35	5	
22DE4	25	7	2		5	B	35	8	
24A	2.5	1		T. C.	2, 3	A	35	5	
25A6	25	2		5	3, 4	B	45	7	
25A7	25	2		5	3, 4	B	55	7	Pentode
25A7	25	2			6	B	30	7	Diode
25B5	25	1		4	2, 3	B	45	6	
25B6	25	2		5	4, 3	B	45	7	
25B8	25	2		T. C.	3, 4	B	50	7	Pentode
25B8	25	2		8	5	B	50	7	Triode
25CR 5	25	4	1, 2, 8	3	7, T. C.	C	45	5	

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
25D4	25	7			5	B	40	8	
25D8	25	2		T. C.	3, 4	B	55	7	Pentode
25D8	25	2		5	6	B	70	7	Triode
25D8	25	2			8	A	40	7	Diode
25DK4	25	3	6		5	B	40	4	
25DT5	25	4	6, 8	3	1, 9	B	50	5	
25EC6	25	2		5	8, TC	B	40	7	
25EH5	25	3	5	2	6, 7	B	55	4	
25FY8	25	4		1	9	B	60	5	Triode
25FY8	25	4		3	6, 7	C	75	5	Pentode
25GC6	25	2	8	4	4, TC	B	50	7	
25N6	25	2		5	3, 4	C	55	7	
25X6	25	2			3	B	30	7	Diode #1
25X6	25	2			5	B	30	7	Diode #2
25Y4	25	2			5	B	30	7	
25Y5	25	1			2	B	35	6	Diode #1
25Y5	25	1			5	B	35	6	Diode #2
25Z3	25	1			2	B	35	4	
25Z4	25	2			5	B	35	7	
27GB5	25	4		1, 2	6, 7, TC	B	35	5	Use Stark No Adapter
28GB5	25	4	2, 6	3	1, 9	C	50	7	
28HA6	25	5	6, 9	2	7, 8	B	40	4	
28Z5	25	1	4		3	B	35	8	Diode #1
28Z5	25	1	4		6	B	35	8	Diode #2
30	2.0	1		3	2	A	60	4	
30AE3	35	4	1, 2, 3, 6, 7, 8		9	B	25	5	T. C. = Cathode
31	2.0	1		3	2	A	40	4	
32	2.0	1		T. C.	2, 3	A	65	4	
32ET5	35	3	2	5	6, 7	C	50	4	
32L7	35	2	3, 4, 5, 8		6	B	30	7	Diode
32L7	35	2	1, 6	5	3, 4	B	45	7	Pentode
Set line at 66 on scale									
33	2.0	1		3	2, 4	A	40	5	
34	2.0	1		T. C.	2, 3	A	60	4	
34GD5	35	3	2	5	6, 7	B	40	4	
35	2.5	1		T. C.	2, 3	A	35	5	
35DZ8	35	4		1	9	B	60	5	Triode
35DZ8	35	4		3	6, 7	C	50	5	Pentode
35EH5	35	3	2	5	6, 7	C	50	4	
35GL6	35	3	6	2	5, 7	C	50	4	
35HB6	35	4		1	3	B	40	5	Pentode
35Z6	35	2			3	B	35	7	Diode #1
35Z6	35	2			5	B	35	7	Diode #2
36	6.3	1		T. C.	2, 3	B	80	5	
37	6.3	1		3	2	B	80	5	
38	6.3	1		T. C.	2, 3	B	80	5	
39	6.3	1		T. C.	2, 3	B	80	5	
40FR5	35	3	5	2	6, 7	B	40	4	
40Z5	35	2	3		5	B	35	7	
44	6.3	1		T. C.	2, 3	B	80	5	
45	2.5	1		3	2	B	35	4	
46	2.5	1		3	2, 4	B	60	5	

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
47	2.5	1		3	2, 4	B	65	5	
49	2.0	1		3	2, 4	B	75	5	
50	7.5	1		3	2	B	50	4	
50CA5	50	3	5	2	6, 7	B	40	4	
50BM 8	50	4		3	6, 7	C	75	5	Pentode
50BM8	50	4		1	9	B	60	5	Triode
50DC4	50	3	6		5	B	35	4	
50EH5	50	3	5	2	6, 7	B	55	4	
50FA5	50	3	5	2	6, 7	B	40	4	
50FE5	50	2		5	3, 4	B	50	7	
50FK5	50	3	2	5	6, 7	B	50	4	
50FY8	50	4		1	9	B	60	5	Triode
50FY8	50	4		3	6, 7	C	75	5	Pentode
50HC6	50	3	6	2	5, 7	B	40	4	
50HK6	50	3	6	2	5, 7	B	30	4	
50Z7	50	2	6		3	B	35	7	Diode #1
50Z7	50	2	6		5	B	35	7	Diode #2
51	2.5	1		T.C.	2, 3	A	35	5	
53	2.5	1		3	2	B	75	7	Triode #1
53	2.5	1		5	6	B	75	7	Triode #2
55	2.5	1		T.C.	2	B	85	6	Triode
55	2.5	1			3	A	50	6	Diode #1
55	2.5	1			3	A	50	6	Diode #2
56	2.5	1		3	2	B	80	5	
57	2.5	1		T.C.	2, 3	A	35	6	
58	2.5	1		T.C.	2, 3	A	35	6	
59	2.5	1		4	2, 3	B	80	7	
60FX5	50	3	2	5	6, 7	C	50	4	
70A7	70	2	6	5	3, 4	B	55	7	Pentode
70A7	70	2	6		1	B	40	7	Diode
(Meter Reverses During Diode Test on A Good Tube)									
75	6.3	1		T.C.	2	A	30	6	Triode
75	6.3	1			3	A	50	6	Diode #1
75	6.3	1			4	A	50	6	Diode #2
81	7.5	1			2	B	70	4	
85	6.3	1		T.C.	2	B	85	6	Triode
85	6.3	1			3	A	45	6	Diode #1
85	6.3	1			4	A	45	6	Diode #2
1626	12.6	2		5	3	B	50	7	
1629	12.6	2	Eye Closed	5	3, 4	D	75	7	Quality Test
1629	12.6	2	Eye Open	5	4	D	75	7	
1654	1.4	1	2, 3, 6		T.C.	D	65	7	
5608	2.5	1		3	2	B	50	7	Triode #1
5608	2.5	1		5	6	B	50	7	Triode #2
5610	6.3	3	1, 7	6	5	B	50	4	
5651	-	-	1, 2, 3, 4, 6		5	D	75	-	Gas Tube No. Filament
5694	6.3	2		4	3	B	50	7	Triode #1
5694	6.3	2		5	6	B	50	7	Triode #2
5838	12.6	2			3	B	40	7	Diode #1
5838	12.6	2			5	B	40	7	Diode #2

* Indicates Correction of Listing on Roll Chart
STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
5842	6.3	9	2, 5, 7, 8	4	1	B	40	5	
5930	2.5	1		3	2	B	40	4	
5992	6.3	2		5	3, 4	C	75	7	
6000	25	2		1	5, 8	C	50	7	
6046	25	2		5	3, 4	C	50	7	
6080	6.3	7		1	2	B	40	8	Triode #1
6080	6.3	7		4	5	B	40	8	Triode #2
6094	6.3	3	1, 2, 4	6	7, 9	B	40	5	
6097	6.3	3			2	B	35	4	Diode #1
6097	6.3	3			7	B	35	4	Diode #2
6100	6.3	3	1, 2	6	5	B	50	4	
6106	5.0	2			4	B	45	8	Diode #1
6113	6.3	7		1	2	B	75	8	Triode #1
6113	6.3	7		4	5	B	75	8	Triode #2
6159	25.0	2	4, 6, 8, 9	5	3, TC	C	30	7	Pentode
6186	6.3	3	2	1	5, 6	B	60	4	
6187	6.3	3		1	5, 6	B	60	4	
6188	6.3	7		1	2	B	75	8	Triode #1
6188	6.3	7		4	5	B	75	8	Triode #2
6215	1.4	2			T.C.	D	60	7	
6267	6.3	4	2	9	1, 6	B	60	5	
6325	6.3	7			3	B	40	8	Diode #1
6325	6.3	7			5	B	40	8	Diode #2
6327	6.3	2	1, 4, 6	5	8, T.C.	B	40	7	
6336	6.3	7		1	2	B	30	8	Triode #1
6336	6.3	7		4	5	B	30	8	Triode #2
6360	12.6	4	9	3	7, 8	B	40	5	Pentode #1
6360	12.6	4	9	1	6, 7	B	40	5	Pentode #2
6384	6.3	6		7	3, 5	C	45	8	
6385	6.3	1	5	3	4	B	60	9	Triode #1
6385	6.3	1	5	7	6	B	60	9	Triode #2
6394	25	7		1	2	B	30	8	Triode #1
6394	25	7		4	5	B	30	8	Triode #2
6486	6.3	4	2, 3	1	5, 7	B	60	6	
6520	6.3	7		1	2	B	50	8	Triode #1
6520	6.3	7		4	5	B	50	8	Triode #2
6528	6.3	7		1	2	B	50	8	Triode #1
6528	6.3	7		4	5	B	50	8	Triode #2
6582	6.3	4	2, 3	1	5, 7	B	60	6	
6664	6.3	3	2, 5	6	1	B	55	4	
6669	6.3	3	7	1	5, 6	B	55	4	
6676	6.3	3		1	5, 6	B	55	4	
6677	6.3	4	8, 9	2	3, 6	C	60	5	
6678	6.3	4		9	1	B	60	5	Triode
6678	6.3	4		2	3, 6	B	65	5	Pentode
6679	12.6	4	9	2	1	B	50	5	Triode #1
6679	12.6	4	9	7	6	B	50	5	Triode #2
6680	12.6	4	9	2	1	B	60	5	Triode #1
6680	12.6	4	9	7	6	B	60	5	Triode #2
6681	12.6	4	9	2	1	B	60	5	Triode #1
6681	12.6	4	9	7	6	B	60	5	Triode #2
6688	6.3	4	3, 6	2	7, 8	B	60	5	
6754	6.3	4	2, 6, 8		1	B	50	5	Diode #1

★ Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
6754	6.3	4	2, 6, 8		9	B	50	5	Diode #2
6792	6.3	2	3, 4, 8	5	6, T. C.	B	40	7	
6840	12.6	4	9	3	1	B	50	5	Triode #1
6840	12.6	4	9	8	6	B	50	5	Triode #2
6851	6.3	4	9	2	1	B	50	5	Triode #1
6851	6.3	4	9	7	6	B	50	5	Triode #2
6854	6.3	1		3	4	B	50	9	Triode #1
6854	6.3	1		7	6	B	50	9	Triode #2
6877	6.3	3	1, 2, 4, 7	6	9	B	50	5	
6883	12.6	1, 4, 8		5	3, T. C.	C	40	7	
6887	6.3	3			2	B	40	4	Diode #1
6887	6.3	2			7	B	40	4	Diode #2
6888	6.3	2		4	6, 8	B	60	7	
6889	6.3	6	2, 3, 4	7	5, TC	C	50	8	
6900	12.6	4	8	2	1	B	60	5	Triode #1
6900	12.6	4	8	7	9	B	60	5	Triode #2
6913	12.6	4	9	2	1	B	60	5	Triode #1
6913	12.6	4	9	7	6	B	60	5	Triode #2
6919	6.3	3			2	B	40	4	Diode #1
6919	6.3	3			7	B	40	4	Diode #2
6954	6.3	3		1	5, 6	B	60	4	
6955	12.6	4	9	2	1	B	60	5	Triode #1
6955	12.6	4	9	7	6	B	60	5	Triode #2
6968	6.3	3	2	1	5, 6	B	60	4	
6973	6.3	4	1, 3	6	8, 9	B	45	5	
7025	12.6	4	9	2	1	B	60	5	Triode #1
7025	12.6	4	9	7	6	B	60	5	Triode #2
7027	6.3	2	1, 6	5	3, 4	C	75	7	
7036	6.3	3		1	6	B	60	4	
7044	12.6	4	8	2	1	B	30	5	Triode #1
7044	12.6	4	8	7	9	B	50	5	Triode #2
7054	12.6	4	3	2	7, 8	C	75	5	
7055	12.6	3			2	B	35	4	Diode #1
7055	12.6	3			7	B	35	4	Diode #2
7056	12.6	3		1	5, 6	B	65	4	
7057	12.6	4		2	1	B	50	5	Triode #1
7057	12.6	4		7	6	B	50	5	Triode #2
7058	12.6	4		2	1	B	50	5	Triode #1
7058	12.6	4		7	6	B	50	5	Triode #2
7059	12.6	4		2	3, 6	B	65	5	Pentode
7059	12.6	4		9	1	B	55	5	Triode
7060	12.6	4		8	6, 7	B	35	5	Pentode
7060	12.6	4		2	1	B	50	5	Triode
7061	12.6	4	1, 6	3	8, 9	B	45	5	
7105	12.6	7		1	2	B	45	8	Triode #1
7105	12.6	7		4	5	B	45	8	Triode #2
7137	6.3	3	5, 6	1	7	B	60	4	
7167	6.3	3	7	1	5, 6	B	50	4	
7189	6.3	4	1, 6, 8	2	7, 9	C	75	5	
7199	6.3	4		7	2, 3	B	55	5	Pentode
7199	6.3	4		9	1	B	50	5	Triode
7212	6.3	2	4, 6	5	3, T. C.	C	60	7	

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
7233	6.3	4	1, 3, 7, 5	2	6	B	30	5	
7234	6.3	2	1, 4, 6, 8	5	3, T.C.	B	40	7	
7235	6.3	2	1, 3, 4, 6	9	T.C.	B	60	7	
7236	6.3	7		1	2	B	50	8	Triode #1
7236	6.3	7		4	5	B	50	8	Triode #2
7239	6.3	4	2, 3, 8	1	6, T.C.	B	55	5	
7244	6.3	3		6	1	B	60	4	Triode #1
7244	6.3	3		5	2	B	60	4	Triode #2
7245	6.3	3	5, 6	1	7	B	60	4	
7247	12.6	4	9	2	1	B	60	5	Triode #1
7247	12.6	4	9	7	6	B	60	5	Triode #2
7258	6.3	4		2	1	B	55	5	Triode
7258	6.3	4		8	6, 7	B	70	5	Pentode
7318	12.6	4	9	2	1	B	60	5	Triode #1
7318	12.6	4	9	7	6	B	60	5	Triode #2
7355	6.3	2		6	3, 8	C	40	7	
7357	25	2	1, 4	5	3, TC	C	40	7	
7360	6.3	4		3	2, 7, 9	B	60	5	Section #1
7360	6.3	4		3	2, 8, 6	B	60	5	Section #2
7370	25	4	8	2	1	B	65	5	Triode #1
7370	25	4	8	7	9	B	65	5	Triode #2
7403	6.3	2		6	4, TC	C	50	1	
7408	6.3	2		5	3, 4	B	45	7	
7534	6.3	2	1, 3	5	4, TC	C	50	7	
7543	6.3	3		1	5, 6	B	65	4	
7551	12.6	4	1, 3	2	6, 8	B	45	5	
7558	6.3	4	1, 3	2	6, 8	B	45	5	
7681	6.3	2		5	3, 4	B	40	7	
7691	6.3	2		6	3, 4	B	40	7	
7697	6.3	2	1, 4	5	3, TC	B	40	7	
7643	6.3	4		9	1	B	50	5	Triode
7643	6.3	4		2	3, 6	B	60	5	Pentode
7689	6.3	4	2, 3, 6	1	8, 9	B	45	5	
7687	6.3	4		2	3, 6	B	65	5	Pentode
7687	6.3	4		9	1	B	60	5	Triode
7695	50	4		6	1, 9	B	45	5	
7701	12.6	4	1, 3, 9	2	6, 7	B	45	5	
7716	12.6	4		2	3	B	50	5	Triode
7716	12.6	4		7	8, 9	B	55	5	Pentode
7717	6.3	3	2	1	5, 6	B	60	4	
7719	12.6	4	1, 2, 3, 9	7	6	B	60	5	
7721	6.3	4	3	2	7, 9	B	55	5	
7722	6.3	4	3	2	7, 9	B	55	5	
7724	12.6	4		8	9	B	80	5	Triode
7724	12.6	4			2	A	40	5	Diode #1
7724	12.6	4			6	A	40	5	Diode #2
7728	12.6	4	9	2	1	B	50	5	Triode #1
7728	12.6	4	9	7	6	B	50	5	Triode #2
7729	12.6	4	9	2	1	B	60	5	Triode #1
7729	12.6	4	9	7	6	B	60	5	Triode #2
7730	12.6	4	9	2	1	B	50	5	Triode #1
7730	12.6	4	9	7	6	B	50	5	Triode #2
7731	6.3	4		9	1	B	55	5	Triode

* Indicates Correction of Listing on Roll Chart
 STARK ELECTRONIC INSTRUMENTS LIMITED

TUBE	FIL VOLTS	F	N	G	P	CIR	SENS	FIL CONT	NOTES
7731	6.3	4		2	3, 6	B	65	5	Pentode
7732	6.3	3		1	5, 6	B	65	4	
7733	12.6	4	3, 6	2	7, 8	B	65	5	
7734	6.3	4		3	6	B	55	5	Triode
7734	6.3	4		8	1, 9	B	65	5	Pentode
7737	6.3	4	3, 6	2	7, 9	B	60	5	
7738	6.3	3	6, 7	2	1	B	55	4	
7751	6.3	2		5	3, 4	B	45	7	
7754	6.3	4		6	1, 9	B	40	5	
7757	6.3	3	1, 2	6	7, TC	C	45	5	
7763	6.3	4		6	1, 3, 8	B	60	5	Section #1
7763	6.3	4		6	7, 8, 9	B	60	5	Section #2
7788	6.3	4	3, 9	2	6, 7	B	50	5	
7802	6.3	7		1	2	B	50	8	Triode #1
7802	6.3	7		4	5	B	50	8	Triode #2
7803	6.3	4		2	1	B	50	5	Triode #1
7803	6.3	4		7	6	B	50	5	Triode #2
7851	2.5	3		1 C.	5, 6	B	55	4	
7861	12.6	1		3	4	B	65	9	Triode #1
7861	12.6	1		7	6	B	65	9	Triode #2
7867	6.3	2		5	8, TC	B	45	7	
7868	6.3	4	6, 7, 8	2	1, 9	C	50	5	
7892	12.6	4	8	2	1	B	60	5	Triode #1
7892	12.6	4	8	7	9	B	60	5	Triode #2
7898	12.6	4	9	2	1	B	75	5	Triode Sec. 2
7898	12.6	4	9	7	6	B	75	5	Triode Sec. 1
8032	12.6	2	4, 6, 8	5	3, TC	C	35	7	Pentode
									Set line at 72 on scale
8068	6.3	2	-	5	8, TC	B	45	7	
8077	12.6	4	3, 9	2	7, 8	D	20	5	Pentode
									Set line at 72 on scale
8084	12.6	4		1	5, 6	B	40	3	
8102	12.6	4	-	3	1	B	40	5	Triode Section
8102	12.6	4	-	9	6, 7	B	50	5	Pentode Section
8106	12.6	4	2, 3, 6	7	1, 8	C	55	5	Pentode
8417	6.3	7	1, 6	5	3, 4	B	35	2	
9006	6.3	3	1, 2		5	B	40	4	
KT66	6.3	2	-	5	3, 4	B	45	7	Pentode
KT88	6.3	2		5	3, 4	C	70	7	